

[Manuals.plus](#) /

› [V-Guard](#) /

› V-Guard Spinny Pro 180 mm Table & Wall Fan Instruction Manual

V-Guard Spinny Pro

V-Guard Spinny Pro 180 mm Table & Wall Fan

Instruction Manual

INTRODUCTION

The V-Guard Spinny Pro 180 mm is a versatile and energy-efficient fan designed for personal cooling. It can be used as both a table fan and a wall-mounted fan, offering powerful airflow with three speed settings and adjustable tilt. This manual provides essential information for the safe and efficient operation of your fan.



Image: The V-Guard Spinny Pro fan, highlighting its compact design and suitability for personal use.

Safety Instructions

Please read these safety instructions carefully before using the appliance to prevent injury and damage.

- Always unplug the fan from the power outlet before cleaning, performing maintenance, or when not in use.
- Do not insert fingers or any other objects through the fan guards when the fan is operating.
- Do not use the fan near water or in excessively humid environments.
- Ensure the voltage indicated on the rating label matches your local power supply before connecting the appliance.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Keep children under supervision to ensure they do not play with the appliance.
- Do not operate any fan with a damaged cord or plug. Discard fan or return to an authorized service facility for examination and/or repair.

Package Contents

Verify that all components are present in the package:

- Fan motor unit (1)
- Base (1)
- Front & rear guard (1 set)
- Guard Ring (1)
- Warranty guide (1)

SETUP

The V-Guard Spinny Pro offers dual mounting options: tabletop and wall mount.

Tabletop Installation

1. Carefully unpack all components.
2. Attach the fan motor unit to the provided base. Ensure it clicks securely into place.
3. Place the fan on a stable, flat surface.

Wall Mount Installation

1. Identify a suitable wall location, ensuring it is sturdy and near a power outlet.
2. Detach the base from the fan motor unit if it was previously assembled for tabletop use.
3. Use appropriate screws and wall plugs (not included) to securely mount the fan's bracket to the wall. Ensure the bracket is level.
4. Attach the fan motor unit to the wall-mounted bracket, ensuring it is firmly secured.

SMOOTH ADJUSTABLE AIRFLOW



Image: Demonstrates the fan's versatility for both tabletop and wall mounting, along with its adjustable tilt feature.

OPERATING INSTRUCTIONS

Follow these steps to operate your V-Guard Spinning Pro fan:

1. **Power Connection:** Plug the power cord into a standard 230V AC electrical outlet.
2. **Power On/Off:** Locate the control knob on the fan. Turn the knob to the 'ON' position to start the fan. Turn it to 'OFF' to switch off the fan.
3. **Speed Settings:** The fan features 3 speed settings. Rotate the control knob to select your desired airflow intensity:
 - **Low:** For gentle air circulation.
 - **Medium:** For moderate cooling.
 - **High:** For maximum airflow and rapid cooling.
4. **Adjustable Tilt:** The fan head can be manually tilted up to 90 degrees vertically. Gently adjust the fan head to direct the airflow precisely where needed.

MAXIMUM AIRFLOW

AERODYNAMICALLY DESIGNED BLADES



Image: The fan's control dial for selecting one of the three available speed settings.

MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your fan.

Cleaning

1. Always unplug the fan before cleaning.
2. Use a soft, damp cloth to wipe the exterior surfaces of the fan. Do not use abrasive cleaners or solvents.
3. To clean the fan blades, carefully remove the front guard by following the assembly instructions in reverse. Wipe the blades with a soft cloth. Ensure the blades are dry before reattaching the guard.
4. Do not immerse the fan in water or allow water to drip into the motor housing.

Storage

When not in use for extended periods, store the fan in a cool, dry place, preferably in its original packaging, to protect it from dust and damage.

TROUBLESHOOTING

If you encounter any issues with your V-Guard Spinny Pro fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not turn on.	No power supply. Fan not plugged in correctly. Power outlet faulty.	Check if the power cord is securely plugged into a working outlet. Test the outlet with another appliance.
Weak or insufficient airflow.	Incorrect speed setting. Obstruction in front or behind the fan. Dust accumulation on blades/guards.	Increase the speed setting. Ensure there are no objects blocking the airflow. Clean the fan blades and guards as per maintenance instructions.
Fan is noisy during operation.	Loose parts. Fan not on a stable surface. Dust/debris on blades.	Ensure all parts are securely assembled. Place the fan on a stable, flat surface. Clean the fan blades and guards. Note that some operational noise is normal, especially at higher speeds.

If the problem persists after attempting these solutions, please contact V-Guard customer service for assistance.

SPECIFICATIONS

Key technical specifications for the V-Guard Spinny Pro 180 mm fan:

Feature	Detail
Brand	V-Guard
Model Name	Spinny Pro
Colour	Black
Fan Design	Table Fan (convertible to Wall Mount)
Power Source	Corded Electric
Product Dimensions (D x W x H)	21D x 18.2W x 30H Centimeters
Special Features	Adjustable Tilt (90°)
Mounting Type	Tabletop, Wall
Controller Type	Button Control
Number Of Speeds	3
Wattage	30 Watts
Number of Blades	3
Air Flow Capacity	353 Cubic Feet Per Minute

Feature	Detail
Speed	2100 RPM
Voltage	230 Volts (AC)
Indoor Outdoor Usage	Indoor
Motor Type	Induction Motor (100% Copper)
Material Type	Acrylonitrile Butadiene Styrene (ABS)
Item Weight	1.5 Kilograms
Country of Origin	India

EASY TO CARRY

PORTABLE DESIGN



BEDROOM



LIVING ROOM



KITCHEN



OFFICE

Image: Illustration of the fan's 100% copper motor, emphasizing its robust build.

WARRANTY AND SUPPORT

Your V-Guard Spinny Pro fan comes with a comprehensive warranty and dedicated customer support.

Warranty Information

The product is covered by a **2 Year Company Warranty** from the date of purchase. Please retain your purchase receipt for warranty claims.

Customer Support

For any consumer complaints, service requests, or technical assistance, please contact V-Guard Customer Service:

- **Address:** Senior Engineer - Customer Service at V-Guard Industries Ltd. 42/962, Vennala High School Road, Vennala, Kochi- 682028, Kerala, India.
- **Phone:** 012 0485 0100, 1860 180 3000
- **Email:** customercare@vguard.in

PAN INDIA SERVICE
24 - 48 HOUR QUICK INSTALLATION SUPPORT*

24 MONTH COVERAGE

350+ SERVICE CENTERS

*24-48 hrs for Metro cities and 48-72 hrs for other cities.

Image: V-Guard's Pan India Service network, illustrating widespread support and coverage.