

[Manuals.plus](#) /

› [V Guard](#) /

› V Guard Esfera Plus BLDC Pedestal Fan 400 mm Instruction Manual

V Guard Esfera Plus BLDC 5 Blade

V Guard Esfera Plus BLDC Pedestal Fan 400 mm Instruction Manual

Model: Esfera Plus BLDC 5 Blade

1. INTRODUCTION

Thank you for choosing the V Guard Esfera Plus BLDC Pedestal Fan. This fan is designed to provide efficient cooling with its advanced BLDC motor and aerodynamic 5-blade design. It features convenient remote control operation, oscillation, and a timer function for enhanced comfort. Please read this manual carefully before use to ensure proper installation, operation, and maintenance.



Image: The V Guard Esfera Plus BLDC Pedestal Fan, black in color, standing in a modern living room next to a sofa, highlighting its sleek design and remote control functionality.

2. SAFETY INSTRUCTIONS

To reduce the risk of fire, electric shock, or injury, always follow these basic safety precautions:

- Ensure the power supply voltage matches the rating indicated on the fan.
- Do not operate the fan with a damaged cord or plug. If damaged, contact authorized service personnel.
- Keep fingers, pencils, or any other objects out of the fan guard when it is operating.
- Unplug the fan from the outlet when not in use, when moving it from one location to another, and before cleaning.
- Do not use the fan in wet locations such as bathrooms or laundries.
- Place the fan on a stable, level surface to prevent it from tipping over.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

- The fan is equipped with a thermal overload protector to prevent overheating. If the fan shuts off unexpectedly, unplug it and allow it to cool before restarting.

3. PACKAGE CONTENTS

Carefully unpack the box and ensure all the following items are present:

- Fan motor unit
- Front guard
- Guard ring
- Spinner
- Blade
- Guard tightening nut
- Rear guard
- Poles (stand pipes)
- Base
- Remote Control
- Warranty Guide / Instruction Manual

4. SETUP AND ASSEMBLY

Follow these steps to assemble your V Guard Esfera Plus BLDC Pedestal Fan:

1. **Assemble the Base:** Attach the pole(s) securely to the fan base. Ensure it is stable.
2. **Attach the Motor Unit:** Mount the fan motor unit onto the top of the assembled pole. Tighten any securing screws or nuts.
3. **Install the Rear Guard:** Place the rear guard onto the motor unit, aligning the notches. Secure it with the guard tightening nut.
4. **Attach the Blade:** Slide the fan blade onto the motor shaft, ensuring it is properly seated. Secure it with the spinner by turning it clockwise until tight.
5. **Install the Front Guard:** Position the front guard over the blade and align it with the rear guard. Secure both guards together using the guard ring and any clips or screws provided.
6. **Adjust Height (if applicable):** The fan features adjustable height. Loosen the height adjustment knob on the pole, set to desired height, and tighten securely.



Image: A visual representation of the fan's adjustable height feature and its sturdy, wider base, indicating ease of customization and stability.

5. OPERATING INSTRUCTIONS

Your V Guard Esfera Plus BLDC Pedestal Fan can be operated using the control panel on the fan unit or the included remote control.

Remote Control Functions:

REMOTE COMFORT



Image: The remote control for the fan, displaying buttons for power, speed, mode, oscillation, and timer, emphasizing convenient operation from a distance.

- **Power Button:** Turns the fan ON or OFF.
- **Speed Button:** Cycles through 3 speed settings (Low, Medium, High).
- **Mode Button:** Selects between different wind modes:
 - **Normal Mode:** Provides a steady, consistent airflow.
 - **Natural Mode:** Simulates a natural breeze with varying fan speeds.
 - **Sleep Mode:** Offers gentle airflow that gradually decreases for comfortable sleep.
- **Oscillation Button:** Activates or deactivates the 70° horizontal oscillation feature, allowing the fan head to sweep side-to-side.
- **Timer Button:** Sets the fan to automatically turn off after a specified duration (e.g., 0.5 to 7.5 hours). Press repeatedly to cycle through timer settings.

The fan also features a 30° vertical tilt (up & down) which can be adjusted manually.

6. MAINTENANCE

Regular cleaning and maintenance will ensure optimal performance and longevity of your fan.

- **Cleaning:** Always unplug the fan before cleaning. Use a soft, damp cloth to wipe the exterior surfaces. Do not use abrasive cleaners or solvents.
- **Blade Cleaning:** Periodically remove the front guard and clean the fan blades with a soft cloth to remove dust buildup. Ensure the blades are completely dry before reassembling the guard.
- **Storage:** When not in use for extended periods, store the fan in a cool, dry place, preferably in its original packaging.



Image: An exploded diagram showing the internal components of the fan's motor, including the 100% copper motor, overload protection, and rust-free ABS body, illustrating its durable construction.

7. TROUBLESHOOTING

If you encounter any issues with your fan, refer to the following table:

Problem	Possible Cause	Solution
Fan does not turn on.	No power supply; Power cord not plugged in; Thermal overload protector activated.	Check power outlet; Ensure plug is fully inserted; Unplug fan, wait 10 minutes, then plug back in.
Weak airflow.	Fan speed set too low; Blades are dirty; Obstruction in front/rear guard.	Increase fan speed; Clean fan blades; Remove any obstructions.
Fan makes unusual noise.	Loose parts; Fan not on a level surface; Blades are dirty or damaged.	Check for loose components and tighten; Place fan on a stable surface; Clean or inspect blades for damage.
Remote control not working.	Batteries are dead or incorrectly inserted; Obstruction between remote and fan sensor.	Replace batteries; Ensure correct battery polarity; Remove obstructions and point remote directly at the fan.

If the problem persists after trying these solutions, please contact V Guard customer support.

8. SPECIFICATIONS

Brand	V Guard
Model Name	Esfera Plus BLDC 5 Blade
Electric Fan Design	Pedestal Fan
Color	Black
Power Source	Corded Electric
Product Dimensions (D x W x H)	44.5D x 44.5W x 133H Centimeters
Wattage	35 Watts
Number of Blades	5
Air Flow Capacity	2295 Cubic Feet Per Minute
Speed	1350 RPM
Voltage	230 Volts
Control Method	Remote Control
Material Type	Acrylonitrile Butadiene Styrene (ABS)
Item Weight	6.5 Kilograms
Country of Origin	India

9. WARRANTY AND SUPPORT

Your V Guard Esfera Plus BLDC Pedestal Fan comes with a**24-month warranty** from the date of purchase. V Guard offers an extensive service network across India to provide dependable support for installation and maintenance.

Service Support:

- **Installation Support:** 24-48 hour quick installation support in metro cities and 48-72 hours in other cities (paid installation).
- **Service Centers:** Over 350 service centers across India.

PAN INDIA SERVICE

24 – 48 HOUR QUICK INSTALLATION SUPPORT*

24
MONTH
COVERAGE

350+
SERVICE
CENTRES

*24-48 HRS FOR METRO CITIES AND 48-72 HRS FOR OTHER CITIES.(PAID INSTALLATION)



Image: A V Guard service technician in uniform holding a smartphone displaying a map of India, symbolizing the widespread service network and support available.

For any service requests or queries, please refer to the contact information provided in your warranty guide or visit the official V Guard website.

