

Manuals.plus / > Wonderchef / > Wonderchef Nutri-Blend Thunder 1000W Mixer-Grinder User Manual

Wonderchef 63153689

Sign in to save this manual Sign in to bookmark this manual and keep private notes.

Wonderchef Nutri-Blend Thunder 1000W Mixer-Grinder User Manual

Model: 63153689

Advertisements

1. INTRODUCTION

Thank you for choosing the Wonderchef Nutri-Blend Thunder 1000W Mixer-Grinder. This appliance is designed to provide efficient blending and grinding for a variety of ingredients, helping you prepare nutrient-rich meals and beverages. Please read this manual carefully before first use to ensure safe and optimal operation.

2. IMPORTANT SAFETY INSTRUCTIONS

- Always ensure the appliance is unplugged before assembly, disassembly, or cleaning.
- Do not immerse the motor base in water or any other liquid. Clean with a damp cloth only.
- Keep hands and utensils out of the jar while blending to reduce the risk of severe personal injury.
- Blades are sharp. Handle with extreme care during assembly, disassembly, and cleaning.
- Do not operate the appliance with a damaged cord or plug, or after the appliance malfunctions or is dropped or damaged in any manner.
- Ensure the jar and blade assembly are securely locked onto the motor base before operation.
- Do not blend hot liquids as pressure buildup can cause the jar to burst. Allow hot ingredients to cool before blending.
- Never operate the appliance empty.
- This appliance is for household use only. Do not use outdoors.

- Supervise children closely when the appliance is in use.

Advertisements

3. PRODUCT OVERVIEW AND COMPONENTS

The Wonderchef Nutri-Blend Thunder comes with the following components:

- **Motor Base:** The main power unit.
- **Long Jar (1000ml):** For larger blending tasks.
- **Short Jar (800ml):** For smaller blending or grinding tasks.
- **6-Blade Assembly:** Stainless steel blades for efficient blending and grinding.
- **Sipper Lid:** For on-the-go consumption from the jar.
- **Storage Lid:** To seal jars for storage.



The Wonderchef Nutri-Blend Thunder 1000W Mixer-Grinder, designed for efficient blending and grinding.



An exploded view showing the various components of the Nutri-Blend Thunder, including jars, lids, and blade assembly.

4. SETUP

1. **Unpack:** Carefully remove all components from the packaging.
2. **Clean:** Wash the jars, lids, and blade assembly with warm soapy water before first use. Rinse thoroughly and dry. Wipe the motor base with a damp cloth.
3. **Placement:** Place the motor base on a clean, dry, and stable surface. Ensure it is away from the edge of the countertop and out of reach of children.

5. OPERATING INSTRUCTIONS

Follow these steps for safe and effective operation:

1. **Prepare Ingredients:** Cut ingredients into small pieces (approximately 1-2 inches) to facilitate blending. Do not overfill the jar beyond the maximum fill line.

2. **Assemble Jar:** Place the ingredients into the desired jar (Long or Short).
3. **Attach Blade Assembly:** Screw the 6-blade assembly firmly onto the open end of the jar until it is tightly sealed. Ensure the UV-bonded silicon gasket is properly seated to prevent leaks.
4. **Place on Motor Base:** Invert the assembled jar and blade, then place it onto the motor base. Align the tabs on the jar with the slots on the motor base and twist clockwise until it locks securely into place.
5. **Connect Power:** Plug the power cord into a suitable electrical outlet (230 Volts).
6. **Operate:** Press down on the jar to start the motor. Release pressure to stop. For optimal results and to prevent overheating, run the Nutri-Blend for a maximum of **one minute at a time**. After one minute of continuous operation, give the appliance a **three-minute gap** to cool down. For most tasks, **20-40 seconds** of operation is sufficient.
7. **Select Correct Blade:** Always use the appropriate blade for the desired operation. The 6-blade assembly is versatile for both blending and grinding.
8. **Finish:** Once blending/grinding is complete, release pressure, unplug the appliance, and carefully remove the jar by twisting counter-clockwise. Unscrew the blade assembly and attach the sipper or storage lid as needed.

For Best Results:



1. Run Nutriblend for one minute at a time.



2. Give 3 minute gap.



3. With the powerful motor, 20-40 seconds of operation is enough.



Grind/Chutney

≠



Blend

4. Always use the correct blade for the desired operation.



Guidelines for operating the Nutri-Blend Thunder, including recommended run times and blade selection.

Advertisements



The Nutri-Blend Thunder can be used for a wide range of preparations, from smoothies to dry spice grinding.

6. MAINTENANCE AND CLEANING

- **Motor Base:** Wipe the motor base with a damp cloth. Do not immerse in water.
- **Jars and Lids:** The jars and lids are dishwasher safe. For manual cleaning, wash with warm soapy water, rinse thoroughly, and dry.
- **Blade Assembly:** Carefully rinse the blade assembly under running water immediately after use. Use a brush to remove any food residue. Handle blades with extreme caution due to their sharpness.
- **Storage:** Store the appliance and its components in a clean, dry place when not in use.

Advertisements

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Appliance does not start	Not plugged in; Jar not securely locked; Overload protection activated.	Ensure power cord is plugged in. Twist jar clockwise until it locks. Unplug, wait 15 minutes for motor to cool, then try again. Reduce ingredients.
Leakage from jar	Blade assembly not tightened; Gasket not properly seated; Jar overfilled; Ingredients too watery.	Ensure blade assembly is tightly screwed. Check gasket position. Do not exceed max fill line. Adjust liquid content.
Unusual noise/vibration	Jar not properly seated; Hard ingredients; Overload.	Ensure jar is locked correctly. Cut hard ingredients smaller. Do not overload. Follow run/rest cycle.
Motor stops during operation	Overload protection activated; Continuous operation exceeded.	Unplug, wait 15 minutes for motor to cool. Reduce ingredients. Adhere to 1-minute run, 3-minute rest cycle.

8. SPECIFICATIONS

- **Brand:** Wonderchef

Advertisements

- **Model Number:** 63153689
- **Power:** 1000 Watts
- **Motor Speed:** 22000 RPM
- **Voltage:** 230 Volts
- **Jars Included:** 1 x 1000ml (Long Jar), 1 x 800ml (Short Jar)
- **Blade Material:** Stainless Steel (6-blade assembly)
- **Control Type:** Manual (Press-to-operate)
- **Product Dimensions:** 18D x 30W x 38H Centimeters
- **Item Weight:** 2000 Grams
- **Material:** Plastic (body), Glass (container material - note: product description states 'unbreakable jars' which typically implies plastic, but specifications list 'Glass'. For safety, assume jars are durable plastic as per product title and feature bullets.)
- **Special Feature:** Compact
- **Dishwasher Safe:** Yes (Jars and Lids)



Detailed view of the powerful 1000W motor with 22000 RPM and 100% copper winding for durability.

9. WARRANTY AND SUPPORT

Your Wonderchef Nutri-Blend Thunder 1000W Mixer-Grinder comes with a **2-year warranty** from the date of purchase. This warranty covers manufacturing defects under normal household use.

Advertisements

For warranty claims, service, or any product-related inquiries, please contact Wonderchef Customer Support:

- **Customer Service Number:** 18602660788
- **Manufacturer:** Wonderchef Home Appliances Pvt. Ltd.

Please retain your purchase receipt as proof of purchase for warranty validation.

Advertisements