

Manuals.plus / > Morphy Richards / > Morphy Richards Glide 1250W Steam Iron User Manual

Morphy Richards Glide

Sign in to save this manual Sign in to bookmark this manual and keep private notes.

Morphy Richards Glide 1250W Steam Iron User Manual

Model: Glide

1. IMPORTANT SAFETY INSTRUCTIONS

Please read these instructions carefully before using your Morphy Richards Glide Steam Iron and retain them for future reference. Failure to follow these instructions may result in electric shock, fire, or serious injury.

- Always ensure the iron is unplugged from the power outlet before filling or emptying the water tank, or when not in use.
- Do not immerse the iron, power cord, or plug in water or any other liquid.
- Keep the iron and its cord out of reach of children and pets when it is switched on or cooling down.
- Use the iron only for its intended purpose, which is ironing clothes.
- To prevent water leakage, keep the iron horizontal when not in use.
- Do not fill the water tank completely; leave some gap to allow for steam generation.
- Always wait for the iron to heat up sufficiently before using the steam function. Using steam before adequate heating can lead to water leakage.

- Do not operate the iron with a damaged cord or plug, or if the iron has been dropped or damaged. Contact authorized service personnel for repair.
- Place the iron on a stable, heat-resistant surface when resting.
- Exercise caution when handling hot surfaces and steam.
- This appliance is for household use only.

2. PRODUCT OVERVIEW

The Morphy Richards Glide 1250W Steam Iron is designed for efficient and smooth ironing, featuring a non-stick coated soleplate and powerful steam functions.



Image: Morphy Richards Glide 1250W Steam Iron with non-stick soleplate and steam burst capability.

Key Features:

- **1250 Watts Power:** Ensures quick heating and efficient performance.
- **Non-Stick Coated Soleplate:** For smooth gliding over various fabrics.
- **Extra Large 300ml Water Tank:** Reduces the need for frequent refills.
- **Variable Steam Control:** Adjust steam output to suit different fabric types.
- **15gm Continuous Steam:** Effectively removes tough creases.

- **Powerful Steam Shots (100gm/min):** For stubborn wrinkles.
- **Vertical Ironing:** Allows for steaming hanging garments and curtains.
- **Self-Cleaning Function:** Helps maintain the iron's performance and longevity.
- **Long 360-Degree Swivel Cord:** Provides flexibility and ease of movement.
- **Fine Water Spray:** Assists in dampening fabrics for easier ironing.
- **19 Steam Holes:** For even steam distribution.

3. SETUP AND FIRST USE

3.1 Filling the Water Tank

1. Ensure the iron is unplugged from the power outlet and has cooled down.
2. Set the steam control to the 'Dry Ironing' position (usually indicated by a '0' or a crossed-out steam symbol).
3. Open the water filler cap.
4. Using a measuring cup, carefully pour clean tap water into the water tank up to the 'MAX' fill line. Do not overfill.
5. Close the water filler cap securely.




Image: Illustration showing the water tank and variable steam control dial.

3.2 Initial Heating

1. Place the iron on its heel rest on a stable, heat-resistant surface.
2. Plug the iron into a suitable power outlet (230V, 50Hz).
3. Set the temperature dial to the desired setting for your fabric type. The indicator light will illuminate.
4. Allow the iron to heat up until the indicator light turns off, signaling that the set temperature has been reached. This may take a few minutes.
5. For the first use, it is recommended to iron an old piece of fabric to remove any manufacturing residues.

4. OPERATING INSTRUCTIONS

4.1 Dry Ironing

For dry ironing, ensure the water tank is empty or the steam control is set to the 'Dry Ironing' position. Select the appropriate temperature for your fabric and wait for the iron to heat up.

4.2 Steam Ironing

Steam ironing is suitable for most fabrics, especially those requiring moisture to remove creases effectively. Ensure the water tank is filled as described in Section 3.1.

1. Set the temperature dial to the 'Steam' range (usually indicated by three dots or a steam symbol).
2. Wait for the iron to heat up completely (indicator light turns off).
3. Adjust the variable steam control to the desired steam output.
4. Begin ironing. The iron will continuously emit steam as you move it.

4.3 Steam Shot / Steam Burst

The steam shot function provides an extra burst of steam for stubborn creases.

- Ensure the iron is at its maximum temperature setting.
- Press the steam shot button (usually located on the handle) to release a powerful burst of steam.
- Wait a few seconds between bursts to allow the iron to reheat and build up steam pressure.

4.4 Vertical Ironing / Vertical Steam

This feature allows you to remove creases from hanging garments, drapes, or curtains.

1. Hang the garment on a hanger.
2. Fill the water tank and set the iron to its maximum temperature.
3. Hold the iron vertically, a few centimeters away from the fabric.
4. Press the steam shot button repeatedly while moving the iron up and down the garment.



Image: Demonstrating both vertical steaming for hanging clothes and traditional horizontal ironing.

4.5 Water Spray Function

The fine water spray helps to moisten dry areas of fabric, making it easier to remove stubborn creases.

- Ensure the water tank is filled.
- Point the spray nozzle towards the fabric and press the spray button (usually located on the handle).

5. MAINTENANCE AND CLEANING

Regular maintenance ensures optimal performance and extends the life of your iron.

5.1 After Each Use

1. Unplug the iron and allow it to cool down completely.
2. Empty any remaining water from the tank.
3. Wipe the soleplate with a damp cloth to remove any residue. Do not use abrasive cleaners or scourers.
4. Store the iron upright on its heel rest.

5.2 Self-Cleaning Function

The self-cleaning function helps to flush out mineral deposits and impurities from the steam vents.

1. Fill the water tank to the 'MAX' line.
2. Plug in the iron and set the temperature dial to maximum.
3. Allow the iron to heat up until the indicator light turns off.
4. Unplug the iron.
5. Hold the iron horizontally over a sink.
6. Press and hold the self-clean button (refer to your iron's markings for exact location).
Hot water and steam will be expelled from the soleplate, carrying impurities with it.
7. Gently rock the iron back and forth until the water tank is empty.
8. Plug the iron back in and allow it to heat up again to dry the soleplate.
9. Unplug and store once cooled.

**Morphy
Richards**
Happiness Engineered

**Built with care,
for the clothes you love**



Image: Close-up view of the iron highlighting the self-clean mechanism.

6. TROUBLESHOOTING

Refer to this section for common issues and their solutions.

Problem	Possible Cause	Solution
Water leakage from soleplate.	Iron not hot enough for steam. Water tank overfilled. Iron left horizontal with water.	Allow iron to heat completely before using steam. Do not overfill water tank. Keep iron horizontal only when in use; store upright.
No steam or insufficient steam.	Water tank empty. Temperature setting too low. Steam control set to 'Dry'. Mineral deposits blocking vents.	Fill water tank. Set temperature to steam range. Adjust steam control. Perform self-cleaning.
Iron not heating up.	Not plugged in. Power outlet faulty. Faulty thermostat.	Check power connection. Test outlet with another appliance. Contact customer support if issue persists.
Soleplate sticking or leaving marks.	Residue on soleplate. Incorrect temperature for fabric.	Clean soleplate with a damp cloth. Ensure correct temperature setting for fabric type.

7. SPECIFICATIONS

Brand	Morphy Richards
Model Name	Glide
Model Number	500009
Wattage	1250 Watts
Operating Voltage	230 Volts
Frequency	50 Hz
Water Tank Capacity	300 ml
Continuous Steam Output	15 gm/min
Steam Shot Output	100 gm/min

Soleplate Type	Non-Stick Coated
Product Dimensions (L x W)	30.7L x 12.4W Centimeters
Item Weight	1200 Grams
Country of Origin	India
Included Components	Steam Iron

8. WARRANTY AND SUPPORT

For warranty information, service, or support, please refer to the warranty card included with your product or contact Morphy Richards customer service.

- **Manufacturer:** Imported and Marketed by Bajaj Electricals Ltd, 45/47, Veer Nariman Road, Mumbai, 400001, Morphy Richards.
- **Customer Service:** Please visit the official Morphy Richards India website for the latest contact information and service center details.
- **Online Resources:** For additional support and FAQs, you may visit the [Morphy Richards Store on Amazon](#).

© 2026 Morphy Richards. All rights reserved.

Related Documents - Glide

	Morphy Richards TURBOSTEAM Steam Iron User Manual Comprehensive user manual for the Morphy Richards TURBOSTEAM Steam Iron, covering operation, features, maintenance, and troubleshooting. Includes safety instructions and guarantee information.
	Morphy Richards Precise Steam Iron User Manual User manual and safety guide for the Morphy Richards Precise Steam Iron. Includes instructions on filling, temperature settings, maintenance, and warranty information.

	Morphy Richards Light Glide 100 Steam Iron User Manual Comprehensive user manual for the Morphy Richards Light Glide 100 Steam Iron, including safety instructions, operation guides, maintenance, and troubleshooting.
	Morphy Richards Steam Generator Iron FAQs Frequently asked questions about Morphy Richards steam generator irons, covering common issues like faulty appliances, guarantees, descaling, BPA content, registration, and specific iron problems such as no power, overheating, or steaming issues.
	Morphy Richards easyCHARGE Power+ Cordless Steam Iron Instruction Manual Instruction manual for the Morphy Richards easyCHARGE Power+ Cordless Steam Iron. Includes setup, operation, maintenance, and troubleshooting.
	Morphy Richards Steam Iron 2200W - User Manual and Warranty Comprehensive user manual and warranty information for the Morphy Richards Steam Iron 2200W, including safety instructions, operating guide, care, and troubleshooting.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

MORPHY RICHARDS GLIDE

KEEP EXPLORING MANUALS, GUIDES, AND SUPPORT DOCS.

Search model numbers, browse help resources, and jump straight into the next PDF manual or troubleshooting page without losing your place.

Morphy Richards Glide m:

Search Manuals+

EXPLORE

Deep Search

Upload

Login

MANUALS+

Home

About Us

Privacy Policy

Login

GUIDES

Amazon Manuals

[AliExpress Manuals](#)

[Video Guides](#)

[Login](#)

FOLLOW

[@manualsplus](#)

[YouTube](#)

[LinkedIn](#)

[Facebook](#)

[Login](#)

Manuals+

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners.

SAVE MANUALS, NOTES, UPLOADS, AND QUESTIONS

Sign in with Google, X, or a passkey to keep private notes on saved manuals, track public uploads, and revisit questions you posted.

Open login options

[Privacy Policy](#) · [DMCA](#)