

Manuals.plus / > Bajaj / > Bajaj MX 3 Neo Steam Iron User Manual

Bajaj MX 3 Neo (Model Number 440508)

Sign in to save this manual

Sign in to bookmark this manual and keep private notes.

Bajaj MX 3 Neo Steam Iron User Manual

Model: MX 3 Neo (Model Number 440508)

INTRODUCTION

Thank you for choosing the Bajaj MX 3 Neo Steam Iron. This manual provides essential information for the safe and efficient use of your appliance. Please read these instructions carefully before first use and keep them for future reference.

Your Bajaj MX 3 Neo Steam Iron is designed for both steam and dry ironing, featuring a 1250 Watts power output for quick heating, an anti-bacterial non-stick soleplate, and a 360-degree swivel cord for ease of use.

IMPORTANT SAFETY INSTRUCTIONS

- Always ensure the iron is unplugged before filling or emptying the water tank, and before cleaning.
- Do not immerse the iron, cord, or plug in water or other liquids.
- Keep the iron out of reach of children and pets.
- Never leave a hot iron unattended.
- Use the iron only for its intended purpose.
- Do not operate the iron with a damaged cord or plug, or if the iron has been dropped or damaged. Contact customer service for repair.
- Place the iron on a stable, heat-resistant surface when not in use.
- Do not touch hot surfaces. Use handles or knobs.

- Always unplug after use and allow to cool completely before storing.

PRODUCT OVERVIEW

Familiarize yourself with the components of your Bajaj MX 3 Neo Steam Iron.



Image: Front view of the Bajaj MX 3 Neo Steam Iron, showing the handle, temperature dial, and soleplate.

- **Water Inlet:** For filling the water tank.
- **Spray Nozzle:** Dispenses a fine mist of water.
- **Steam Control Knob:** Adjusts steam output or selects dry ironing.
- **Temperature Control Dial:** Selects the appropriate temperature for different fabrics.
- **Indicator Light:** Illuminates when the iron is heating and turns off when the set temperature is reached.
- **Soleplate:** Anti-bacterial and non-stick German coated surface for smooth gliding.

- **Water Tank:** 180ml capacity for steam generation.
- **360° Swivel Cord:** Provides flexibility and prevents tangling during ironing.



SETUP

1. **Unpacking:** Carefully remove the iron from its packaging. Retain the packaging for storage or future transport.
2. **Initial Cleaning:** Wipe the soleplate with a soft, damp cloth to remove any manufacturing residues.
3. **Water Filling (for Steam Ironing):**
 - Ensure the iron is unplugged and the steam control is set to 'OFF' or 'Dry Ironing'.
 - Open the water inlet cover.
 - Using the provided water measuring cup, fill the water tank with clean tap water up to the 'MAX' level (180ml). Do not overfill.
 - Close the water inlet cover securely.
4. **Placement:** Place the iron on a stable, heat-resistant ironing board or surface.

OPERATING INSTRUCTIONS

1. Dry Ironing

1. Ensure the water tank is empty or the steam control is set to 'OFF'.
2. Plug the iron into a suitable power outlet.
3. Set the temperature control dial to the desired fabric setting (e.g., Silk, Wool, Cotton, Linen). Refer to the fabric care label on your garment.
4. The indicator light will illuminate, indicating the iron is heating. It will turn off when the set temperature is reached.
5. Begin ironing.



2. Steam Ironing



Image: Close-up view of the iron's soleplate emitting steam, demonstrating the steam burst function.

1. Fill the water tank as described in the 'Setup' section.
2. Plug the iron into a suitable power outlet.
3. Set the temperature control dial to the 'Steam' range (usually indicated by a steam symbol or higher temperature settings).
4. Wait for the indicator light to turn off, signifying the iron has reached the correct temperature for steam generation.
5. Adjust the steam control knob to the desired steam level.
6. Begin ironing. For stubborn creases, use the steam burst function by pressing the steam burst button.
7. After use, unplug the iron, empty any remaining water, and allow it to cool completely before storing.

3. Vertical Ironing



Image: A person using the Bajaj MX 3 Neo Steam Iron to vertically iron a blue shirt hanging on a hanger, demonstrating the vertical ironing feature.

The Bajaj MX 3 Neo Steam Iron supports vertical ironing for hanging garments or drapes.

1. Hang the garment on a hanger.
2. Fill the water tank and set the iron to a high steam temperature as for regular steam ironing.
3. Hold the iron vertically a few centimeters away from the fabric.
4. Press the steam burst button repeatedly to release steam onto the fabric, moving the iron up and down.
5. Avoid direct contact with delicate fabrics.

4. Spray Function

The spray function helps to moisten stubborn creases for easier removal.

- Ensure the water tank is filled.
- Point the spray nozzle towards the fabric.
- Press the spray button to release a fine mist.

MAINTENANCE AND CLEANING

1. After Each Use:

- Unplug the iron and allow it to cool completely.
- Empty any remaining water from the tank.

2. Cleaning the Soleplate:

- When the soleplate is cool, wipe it with a damp cloth and a non-abrasive cleaner if necessary.
- Do not use harsh scouring pads or metallic cleaners as they can damage the non-stick coating.

3. Cleaning the Exterior:

- Wipe the outer casing with a soft, damp cloth.
- Do not use abrasive cleaners or solvents.

4. Storage:

- Store the iron upright on its heel rest to protect the soleplate.
- Wrap the cord loosely around the heel rest or use the cord clip if provided.
- Store in a dry, safe place.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Iron does not heat up.	Not plugged in; power outlet faulty; temperature dial set to 'OFF' or too low.	Check power connection; try another outlet; adjust temperature dial to desired setting.
No steam or insufficient steam.	Water tank empty; temperature too low for steam; steam control set to 'OFF'; mineral buildup.	Fill water tank; set temperature to steam range; adjust steam control; perform descaling if necessary.
Water leakage from soleplate.	Temperature too low for steam; water tank overfilled; steam control left open when iron is cold.	Ensure iron is hot enough for steam; do not overfill tank; close steam control when not in use or when cooling.
Soleplate sticking to fabric.	Temperature too high for fabric type; soleplate dirty.	Adjust temperature according to fabric care label; clean soleplate.

SPECIFICATIONS



Image: The Bajaj MX 3 Neo Steam Iron shown with its approximate dimensions: 27cm (L), 15cm (H), 11.8cm (B).

- **Model Name:** MX 3 Neo
- **Model Number:** 440508
- **Brand:** Bajaj
- **Power:** 1250 Watts
- **Voltage:** 240 Volts
- **Frequency:** 50 Hz
- **Water Tank Capacity:** 180 ml
- **Soleplate:** Anti-bacterial & Non-Stick German Coated (Stainless Steel or Aluminium base)
- **Special Features:** Temperature Control, Vertical Ironing, Spray Function, 360° Swivel Cord, Cool Touch Body
- **Item Weight:** 1000 Grams
- **Included Components:** 1N water measuring cup, 1N Instruction manual, 1N Warranty card
- **Country of Origin:** India

WARRANTY AND SUPPORT

Your Bajaj MX 3 Neo Steam Iron comes with a **2-year manufacturer warranty** from the date of purchase.

For warranty claims, technical assistance, or any product-related inquiries, please contact Bajaj customer support:

- **Manufacturer:** M/S. Bajaj Electricals Ltd

- **Address:** #45/47 Veer Nariman Road, Mumbai - 40001
- **Phone:** 022-41280000
- **Email:** customercare@bajajelectricals.com

Please retain your purchase receipt and warranty card as proof of purchase for any warranty services.

© 2026 Bajaj Electricals Ltd. All rights reserved.

Documents - Bajaj – MX 3 Neo
no relevant documents

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question