

[Manuals.plus](#) /

› [Braun](#) /

› Braun Face Mini Hair Remover FS1000 User Manual

Braun FS1000

Braun Face Mini Hair Remover FS1000 User Manual

Brand: Braun | Model: FS1000

INTRODUCTION

The Braun Face Mini Hair Remover FS1000 is an elegantly designed, mini-sized electric facial hair remover for women, engineered to deliver fast and gentle hair removal results. It cuts hair close to skin level, leaving your face smooth, consistent, and free of peach fuzz. This device is designed for quick and gentle hair removal, whenever and wherever you need it.

Key Features:

- **Smooth Skin:** Shaves hair cleanly and close to the skin, facilitating easier makeup application.
- **Gentle & Discreet:** Built for efficient and sensitive facial hair removal.
- **Quick & Easy:** Mini-sized design for portability, enabling efficient facial hair removal anytime, anywhere.
- **Precise:** Features a built-in Smartlight to spot and isolate even the finest hairs.
- **Versatile:** This facial shaver is easily usable on tricky areas of the face.



Image: The Braun Face Mini Hair Remover FS1000 shown alongside its product packaging, highlighting its compact design.

SAFETY INFORMATION

Electric shavers can cause mild skin irritation such as redness, dryness, or tightness, particularly for individuals with sensitive skin. Always perform a patch test on a small area of skin before full use if you have known skin sensitivities. Do not use on irritated, broken, or sunburned skin. Keep out of reach of children.

WHAT'S IN THE BOX

Your Braun Face Mini Hair Remover FS1000 package includes the following components:

- 1 x Mini Hair Remover (FS1000 device)
- 1 x White Cap (Protective cap for the shaver head)
- 1 x Cleaning Brush
- 1 x AA Battery (for immediate use)

SETUP

The Braun Face Mini Hair Remover FS1000 operates on a single AA battery, which is included in the box. Follow these steps to set up your device:

1. **Unpack:** Carefully remove the Mini Hair Remover and its accessories from the packaging.
2. **Insert Battery:** Twist the lower part of the device counter-clockwise to open the battery compartment. Insert the provided AA battery, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
3. **Close Compartment:** Twist the lower part clockwise until it clicks securely into place, sealing the battery compartment.
4. **Attach Cap:** Place the white protective cap over the shaver head when the device is not in use to protect the rotary blades.



Image: A diagram illustrating the key components of the Braun Face Mini Hair Remover, including the rotary head, protective foil, smartlight, and waterproof design.

OPERATING INSTRUCTIONS

The Braun Face Mini Hair Remover is designed for quick, gentle, and effective facial hair removal. Follow these steps for optimal results:

1. **Prepare Skin:** Ensure your skin is clean and dry before use. Avoid using creams or lotions that might clog the shaver head.
2. **Turn On:** Twist the middle section of the device to the 'ON' position. The Smartlight will illuminate, helping you to see even the finest hairs.
3. **Position Device:** Gently place the shaver head flat against your skin.
4. **Remove Hair:** Move the device in small, circular motions over the desired area. The rotary cutting system will efficiently remove hair close to the skin.
5. **Target Areas:**
 - **Cheeks:** Glide the device gently across your cheeks to remove peach fuzz.
 - **Chin:** Use small, precise movements around the chin area.
 - **Upper Lip:** Carefully maneuver the device over the upper lip for smooth results.
6. **Use Smartlight:** Utilize the built-in Smartlight to identify and target any stray or fine hairs that might otherwise be missed.
7. **Turn Off:** Once finished, twist the middle section back to the 'OFF' position.
8. **Clean Device:** Refer to the "Maintenance and Cleaning" section for instructions on how to clean the shaver head after each use.

Precision & Beauty at your fingertips





Smartlight
For spotting & removing peach fuzz



Protective Foil
For extra safety

Rotary Cutting System

Contours your skin for quick, effective hair removal, even in the toughest areas

Image: A woman demonstrating the quick and pain-free facial hair removal process using the Braun Face Mini Hair Remover.

How to Use





Image: Visual guide showing how the device can be used effectively on the cheek, chin, and upper lip areas.

"It's a great investment in self-care & a one-time purchase that delivers years of salon-quality, pain-free results, saving you the time and hassle."

- Prajakta Koli



Image: A visual representation of the three-step routine: Twist to activate, Rotate for hair removal, and Glow for smooth skin.

MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and hygiene of your Braun Face Mini Hair Remover. It is recommended to clean the device after each use.

- 1. **Turn Off:** Ensure the device is turned off before cleaning.
- 2. **Remove Shaver Head:** Gently twist and pull off the shaver head from the main body of the device.
- 3. **Brush Clean:** Use the provided cleaning brush to remove any trapped hairs from the rotary blades and the inside of the shaver head.
- 4. **Rinse (Optional):** The device is 100% waterproof. You may rinse the shaver head under running water for a more thorough clean. Ensure it is completely dry before reattaching. Do not rinse the main body of the device if the battery compartment is open.
- 5. **Reattach Shaver Head:** Align the shaver head with the main body and push it back on until it clicks into place.
- 6. **Store:** Store the device with its protective cap on in a clean, dry place.

TROUBLESHOOTING

If you encounter issues with your Braun Face Mini Hair Remover, please refer to the following common troubleshooting tips:

Problem	Possible Cause	Solution
Device does not turn on.	Battery is dead or incorrectly inserted.	Check battery orientation. Replace with a new AA battery.
Reduced hair removal performance.	Shaver head is clogged with hair or debris.	Clean the shaver head thoroughly using the cleaning brush. Rinse if necessary and ensure it's dry.
Device feels warm during use.	Normal operation, especially during prolonged use.	This is normal. If it becomes excessively hot or causes discomfort, turn off and allow to cool.

Problem	Possible Cause	Solution
Skin irritation after use.	Sensitive skin, improper technique, or using on irritated skin.	Ensure skin is clean and dry. Use gentle pressure. Avoid using on already irritated skin. Apply a soothing moisturizer after use.

SPECIFICATIONS

Feature	Detail
Model Name	FS1000
Power Source	Battery Powered (1 x AA battery included)
Recommended Uses	Face
Included Components	Cleaning Brush, Battery
Item Weight	97 Grams
Product Dimensions (LxWxH)	10 x 4 x 19 Centimeters
Country of Origin	China
Manufacturer	Procter & Gamble

WARRANTY AND SUPPORT

For warranty information, product support, or any queries regarding your Braun Face Mini Hair Remover FS1000, please contact Braun Customer Care.

- **Importer:** Procter & Gamble Home Products Private Limited, P&G Plaza, Cardinal Gracious Rd, Chakala, Andheri East, Mumbai, Maharashtra 400099
- **Braun Customer Care (India):** 1800 – 202 – 1364
- **Email Support:** intouch.im@pg.com

Please retain your proof of purchase for any warranty claims.



