



[Manuals.plus](#) /

› [Bombay Shaving Company](#) /

› [Bombay Shaving Company Blo Body Groomer User Manual](#)

Bombay Shaving Company Blo Body Groomer (APPLIANCES_BLO_BALLS_BODY_GROOMER)

Bombay Shaving Company Blo Body Groomer User Manual

Model: Blo Body Groomer (APPLIANCES_BLO_BALLS_BODY_GROOMER)

Introduction	What's in the Box	Features	Setup	Operation	Maintenance	Troubleshooting
		Specifications		Warranty & Support		

1. INTRODUCTION

This manual provides detailed instructions for the safe and effective use of your Bombay Shaving Company Blo Body Groomer. Designed for precision and comfort, this groomer features ceramic blades, IPX7 waterproofing, and convenient Type-C flash charging. Please read this manual thoroughly before first use and retain it for future reference.

2. WHAT'S IN THE BOX

Upon unpacking, ensure all items listed below are present and in good condition:

- Bombay Shaving Company Blo Body Groomer
- 0.5mm Comb Attachment
- 1mm Comb Attachment
- Type-C Charging Cable
- Cleaning Brush
- User Manual (This document)



Image: Contents of the Blo Body Groomer package, including the groomer, two comb attachments, and the Type-C charging cable.

3. KEY FEATURES

- **Ceramic Blades:** Engineered to generate 75% less heat than traditional stainless steel blades, providing a safer and gentler grooming experience, especially for sensitive skin.
- **90-Minute Runtime:** Offers extended cordless operation on a single full charge, suitable for multiple grooming sessions.
- **IPX7 Waterproof Design:** Fully submersible, allowing for convenient use in the shower and easy cleaning under running water.
- **Safe for Sensitive Areas:** Specifically designed for use on delicate body areas such as private parts, underarms, and chest, minimizing the risk of nicks and irritation.
- **Type-C Flash Charging:** Enables rapid charging, reaching full capacity in approximately 90 minutes. Compatible with standard Type-C phone chargers for added convenience.
- **Integrated LED Torch:** Provides illumination for enhanced visibility during grooming, ensuring no hair is missed.



Image: Visual representation of the groomer's key features, including battery life, charging speed, blade type, and waterproof rating.




Image: Detailed view of the ceramic blade, emphasizing its design for reduced heat and cuts.

4. SETUP AND INITIAL USE

4.1 Charging the Groomer

1. Before first use, fully charge the groomer.
2. Connect the provided Type-C charging cable to the charging port at the bottom of the groomer.
3. Plug the other end of the cable into a compatible USB power adapter (not included) or a Type-C port.
4. The charging indicator light will illuminate. A full charge takes approximately 90 minutes.
5. Once fully charged, the indicator light may change or turn off (refer to specific light behavior in troubleshooting if unsure).



Image: The groomer connected to a Type-C charging cable, illustrating the charging process.

4.2 Attaching and Removing Comb Attachments

1. To attach a comb: Align the comb attachment with the trimmer head and gently push until it clicks into place.
2. To remove a comb: Hold the groomer firmly and gently pull the comb attachment away from the trimmer head.

Your browser does not support the video tag.

Video: Demonstration of attaching and removing the comb attachment from the Blo Body Groomer, and turning the device on and off.

5. OPERATING INSTRUCTIONS

5.1 Powering On/Off

- To turn on: Press the power button located on the front of the groomer.
- To turn off: Press the power button again.

5.2 Using the LED Torch

The integrated LED torch automatically activates when the groomer is turned on, providing illumination for precise grooming in dimly lit areas.

5.3 Grooming Tips

- For best results, ensure your skin is clean and dry before grooming.
- When trimming sensitive areas, use the groomer without a comb attachment for the closest trim, or with the 0.5mm comb for a slight length.
- Always hold the groomer flat against the skin and move it slowly against the direction of hair growth.
- Use short, gentle strokes to avoid pulling or irritation.
- The IPX7 waterproof design allows for wet grooming, which can be more comfortable for some users.




Image: Illustrates the recommended areas for using the body groomer, including chest, underarms, and groin.

6. MAINTENANCE AND CLEANING

6.1 Cleaning the Blades

1. Turn off the groomer before cleaning.
2. Remove any comb attachment.
3. Rinse the trimmer head and blades under running water. The IPX7 waterproof rating allows for thorough rinsing.
4. Use the provided cleaning brush to remove any trapped hairs from the blades.
5. Allow the groomer to air dry completely before storing or reattaching combs.

6.2 Storage

Store the groomer in a cool, dry place, away from direct sunlight and out of reach of children.



Image: The groomer shown in water, highlighting its waterproof capability for easy cleaning.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Groomer does not turn on.	Battery is depleted.	Charge the groomer fully using the Type-C cable.

Problem	Possible Cause	Solution
Poor trimming performance.	Blades are clogged with hair or dull.	Clean the blades thoroughly. Ensure the groomer is fully charged.
Skin irritation after use.	Incorrect technique or sensitive skin.	Ensure you are using gentle strokes against hair growth. Consider wet grooming. If irritation persists, consult a dermatologist.
Charging indicator not working.	Cable or adapter issue, or groomer already fully charged.	Try a different Type-C cable or power adapter. Check if the groomer is already fully charged.

8. PRODUCT SPECIFICATIONS

Feature	Detail
Model Name	Blo Balls And Body Groomer for Men
Item Model Number	APPLIANCES_BLO_BALLS_BODY_GROOMER
Brand	Bombay Shaving Company
Blade Material	Ceramic
Waterproof Rating	IPX7
Power Source	Battery Powered
Battery Type	Lithium-Ion
Battery Life (Runtime)	90 Minutes
Charging Time	Approximately 90 Minutes (Type-C Flash Charging)
Special Features	Ceramic Blades, IPX7 Waterproof Design, LED Torch
Recommended Uses	Armpit, Chest, Pubic Area
Item Weight	350 Grams
Product Dimensions (LxWxH)	10 x 7 x 10 Centimeters
Country of Origin	China

9. WARRANTY AND SUPPORT

The Bombay Shaving Company Blo Body Groomer comes with a standard manufacturer's warranty. For specific warranty terms and conditions, please refer to the warranty card included with your product or visit the official Bombay Shaving Company website.

9.1 Extended Warranty Options

Extended warranty plans may be available for purchase through authorized retailers or service providers. For example, 1-Year and 2-Year Extended Warranty plans by OneAssist are offered.

- **1 Year Extended Warranty plan by OneAssist:** Additional 12 months of coverage.

- **2 Year Extended warranty by OneAssist:** Additional 24 months of coverage.

9.2 Customer Support

For any questions, technical assistance, or service requests, please contact Bombay Shaving Company customer support. Contact details can typically be found on the product packaging or the official brand website.

Manufacturer Contact: Visage lines personal care Pvt. Ltd, 5th Floor, plot no 272, udhyog vihar, phase II, gurugram, Haryana - 122008. Contact details: 7303488233.