

Havells HC4045

Havells 5-in-1 Multi Styling Kit HC4045 Instruction Manual

Model: HC4045

1. INTRODUCTION

The Havells 5-in-1 Multi Styling Kit HC4045 is a versatile hair styling appliance designed to provide multiple styling options with a single device. This kit includes interchangeable attachments for straightening, curling, crimping, conical curling, and adding volume to your hair. It features ceramic-coated plates for even heat distribution and reduced hair damage, ensuring smooth and shiny results.

2. SAFETY INFORMATION

WARNING: To reduce the risk of electric shock, burns, fire, or injury to persons:

- Keep out of the reach of children.
- Do not use this appliance near water, such as bathtubs, showers, basins, or other vessels containing water.
- Always unplug the appliance immediately after use and before cleaning.
- Do not use the appliance with wet hands or on wet hair.
- Do not place or store the appliance where it can fall or be pulled into a tub or sink.
- Never operate this appliance if it has a damaged cord or plug, if it is not working properly, or if it has been dropped or damaged.
- Keep the cord away from heated surfaces. Do not wrap the cord around the appliance.
- Allow the appliance to cool completely before storing.
- Use this appliance only for its intended use as described in this manual.

3. PRODUCT OVERVIEW AND COMPONENTS

The Havells 5-in-1 Multi Styling Kit HC4045 comes with a main body and several interchangeable attachments to create various hairstyles.

5-IN-1 MULTI-STYLING KIT HC4045



MAXIMUM TEMPERATURE
Optimal temperature for
damage-free healthy hair



WORLDWIDE VOLTAGE
Use the product safely
anywhere in the world



**CERAMIC-COATED
ATTACHMENTS**
Ensures frizz-free shiny hair



**2-YEAR
GUARANTEE**

Image: The Havells 5-in-1 Multi Styling Kit HC4045 main unit with all its interchangeable attachments laid out.

Included Components:

- 1 x Main Body
- 1 x 2-in-1 Changeable Head (Straightener/Crimper)
- 1 x Conical Curler Attachment
- 1 x 19mm Curler Attachment
- 1 x Brush Comb Attachment
- 1 x Instruction Manual

Key Features:

- **Ceramic Coated Plates:** Ensures even heat distribution and smooth gliding for frizz-free, shiny hair.
- **Maximum Temperature:** Heats up to 190°C for effective styling.
- **Worldwide Voltage:** Designed for use globally.

- **Cool Insulated Tip:** Provides a safe area to hold during styling.
- **ON/OFF Power Button:** For convenient operation.
- **360-degree Swivel Cord:** Prevents tangling during use.

4. SETUP

1. **Unpack:** Carefully remove all components from the packaging.
2. **Choose Attachment:** Select the desired styling attachment (straightener, crimper, 19mm curler, conical curler, or brush comb).
3. **Attach:** Align the chosen attachment with the main body and gently push until it clicks securely into place. Ensure it is firmly attached before use.
4. **Connect to Power:** Plug the appliance into a suitable electrical outlet. The appliance is designed for worldwide voltage.

5. OPERATING INSTRUCTIONS

Always ensure your hair is clean and dry before styling. For best results and hair protection, consider using a heat protectant spray.

General Operation:

1. After attaching the desired head and plugging in the device, press the ON/OFF power button to turn on the appliance.
2. Allow the appliance to heat up for a few minutes until it reaches its optimal temperature of 190°C.
3. Once styling is complete, press the ON/OFF button to turn off the appliance and unplug it from the power outlet.
4. Allow the appliance and attachments to cool down completely before detaching or storing.

5.1. Straightener

STRAIGHTENER



**Smooth and straight
hair in minutes**

Image: The straightener attachment being used to achieve smooth, straight hair.

Use the flat plates of the 2-in-1 changeable head for straightening.

1. Ensure the straightener plates are clean and free from hair products.
2. Divide your hair into small, manageable sections.
3. Take one section of hair and place it between the heated plates, close to the roots.
4. Gently clamp the plates together and glide the straightener slowly down the hair section, from roots to ends.
5. Repeat until the desired straightness is achieved for all sections.

5.2. Crimper

5-IN-1 MULTI-STYLING KIT HC4045



CRIMPER

Easy and stylish
crimped look



Image: The crimper attachment creating a textured, crimped look.

Use the corrugated plates of the 2-in-1 changeable head for crimping.

1. Ensure the crimper plates are clean.
2. Divide your hair into small sections.
3. Place a section of hair between the heated crimping plates, close to the roots.
4. Clamp the plates together for a few seconds (do not hold for too long to avoid damage).
5. Release and move down the same section of hair, overlapping slightly with the previously crimped area, and repeat the clamping action.
6. Continue until the entire section is crimped. Repeat for all desired sections.

5.3. 19mm Curler

5-IN-1 MULTI-STYLING KIT HC4045

19mm CURLER

Beautiful and
bouncy hair



Image: The 19mm curler attachment creating beautiful, bouncy curls.

Attach the 19mm curler for classic, bouncy curls.

1. Ensure the curler is clean.
2. Take a section of hair, approximately 1-inch wide.
3. Open the clamp, place the end of the hair section under the clamp, and close it.
4. Roll the hair section upwards around the barrel towards the roots, ensuring even distribution.
5. Hold for 5-10 seconds, depending on hair type and desired curl intensity.
6. Release the clamp and gently slide the curler out, allowing the curl to form. Repeat for all sections.

5.4. Conical Curler

5-IN-1 MULTI-STYLING KIT HC4045

CONICAL CURLER

Unique curls and waves
from tight to loose ringlets



Image: The conical curler attachment creating unique curls and waves, from tight to loose ringlets.

Attach the conical curler for varied curls, from tight ringlets to loose waves.

1. Ensure the conical curler is clean.
2. Take a section of hair. For tighter curls, use smaller sections and wrap closer to the tip. For looser waves, use larger sections and wrap closer to the base.
3. Wrap the hair section around the conical barrel, starting from the wider base and moving towards the narrower tip. Use the cool tip for support.
4. Hold for 5-10 seconds.
5. Unwrap the hair gently from the barrel. Repeat for all sections.

5.5. Volume Brush

5-IN-1 MULTI-STYLING KIT HC4045

BRUSH COMB

Voluminous and
bouncy hair



Image: The brush comb attachment used to add volume and bounce to hair.

Attach the brush comb for adding volume and soft waves.

1. Ensure the brush comb is clean.
2. Take a section of hair and place it over the brush comb.
3. Gently roll the brush comb through the hair section, lifting from the roots to add volume.
4. For soft waves, wrap sections of hair around the brush comb and hold for a few seconds before unwrapping.

6. MAINTENANCE

Cleaning:

- Always ensure the appliance is turned off, unplugged, and completely cool before cleaning.
- Wipe the exterior of the main body and attachments with a soft, damp cloth.
- Do not use abrasive cleaners, solvents, or harsh chemicals.
- Ensure no water enters the appliance.

- Remove any hair strands from the attachments after each use.

Storage:

- Store the appliance and its attachments in a cool, dry place.
- Do not wrap the power cord around the appliance, as this can damage the cord.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in correctly; Power outlet issue; Appliance fault.	Ensure the plug is fully inserted into a working outlet. Test the outlet with another device. If the problem persists, contact customer support.
Appliance not heating up.	Appliance not turned on; Internal fault.	Press the ON/OFF button. Allow sufficient time for heating. If still not heating, contact customer support.
Poor styling results (e.g., hair not straight/curly).	Hair too wet; Sections too large; Not enough heat time.	Ensure hair is completely dry. Use smaller, thinner sections of hair. Hold the appliance on hair for the recommended duration.
Attachments are loose.	Attachment not properly secured.	Ensure the attachment is fully aligned and clicked into place on the main body.

8. SPECIFICATIONS

- **Model:** HC4045
- **Power Source:** Electric
- **Max Temperature Setting:** 190 Degrees Celsius
- **Heater Surface Material:** Ceramic
- **Cord Length:** 1.8 meters
- **Wattage:** 40 W
- **Voltage:** Worldwide Voltage
- **Product Dimensions (LxWxH):** 24 x 5 x 27 Centimeters
- **Item Weight:** 318 Grams
- **Country of Origin:** China

9. WARRANTY AND SUPPORT

Warranty:

This Havells product comes with a **2-year manufacturer's guarantee** from the date of purchase. Please retain your purchase receipt for warranty claims.

Customer Support:

For any service-related queries or assistance, please contact Havells customer support:

- **WhatsApp:** +91-9711773333
- **Toll-Free Customer Care:** 1800 103 1313 or 08045 77 1313



Image: Havells Care 360 contact details for customer support.

Havells Sync Application:

Enhance your experience by downloading the Havells Sync Application. This app can help you manage your smart devices, enhance your shopping experience, and provide hassle-free service assistance.



Reach us on WhatsApp @ **+91-9711773333**
for any service related query.

**For CARE 360, Call us at :
Customer Care No.: 08045 77 1313**

All trademarks used herein are property of their respective owners.
Any use of third party trademarks is for identification purposes only and does not imply endorsement.

Image: Information about the Havells Sync Application, including QR code and links to download from app stores.

Download the Havells Sync App: <http://onelink.to/3sdqa7>