

[Manuals.plus](#) /

› [Havells](#) /

› Havells HD3191 1600W Foldable Hair Dryer Instruction Manual

Havells HD3191

Havells HD3191 1600W Foldable Hair Dryer User Manual

1. INTRODUCTION

Thank you for choosing the Havells HD3191 1600W Foldable Hair Dryer. This manual provides essential information for the safe and efficient operation, maintenance, and care of your new appliance. Please read these instructions thoroughly before first use and retain them for future reference.



Image 1.1: The Havells HD3191 1600W Foldable Hair Dryer, showcasing its compact design.

2. IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, especially when children are present, basic safety precautions should always be followed, including the following:

- **DANGER:** Keep out of reach of children.
- Always unplug the appliance immediately after use and before cleaning.
- Do not use while bathing or in a shower.
- Do not place or store the appliance where it can fall or be pulled into a tub or sink.
- Do not place in or drop into water or other liquid.
- Do not reach for an appliance that has fallen into water. Unplug immediately.
- Do not operate any appliance with a damaged cord or plug, or if the appliance malfunctions or has been dropped or damaged in any manner.
- Keep the power cord away from heated surfaces.
- Never block the air openings of the appliance or place it on a soft surface, such as a bed or couch, where the air openings may be blocked. Keep the air openings free of lint, hair, and the like.

- Never use while sleeping.
- Never drop or insert any object into any opening.
- Do not use outdoors or operate where aerosol (spray) products are being used or where oxygen is being administered.
- Do not use an extension cord with this appliance.
- Do not direct hot air towards eyes or other heat-sensitive areas.
- The air inlet filter must be cleaned regularly to prevent overheating.

3. PRODUCT COMPONENTS

The Havells HD3191 hair dryer package includes the following components:

- Havells HD3191 Hair Dryer Unit
- Concentrator Nozzle



Image 3.1: Contents of the Havells HD3191 hair dryer package, including the main unit and concentrator.

4. SETUP

Before using your hair dryer for the first time, follow these simple setup steps:

1. **Unpack:** Carefully remove all components from the packaging.
2. **Attach Concentrator (Optional):** Align the concentrator nozzle with the front of the hair dryer and push it firmly into place. This accessory helps direct airflow for precise styling.
3. **Inspect:** Check the appliance and cord for any signs of damage. Do not use if damaged.
4. **Plug In:** Insert the power plug into a suitable electrical outlet (240V).

FOLDABLE HANDLE

Ensures easy storage
while traveling



Image 4.1: Illustration of attaching the detachable thin nozzle for concentrated airflow.

5. OPERATING INSTRUCTIONS

Follow these steps to operate your Havells HD3191 hair dryer:

5.1 Power On/Off and Speed Settings

- Ensure the hair dryer is plugged into a power outlet.
- Use the slide switch on the handle to select your desired speed setting:
 - **OFF:** Turns the appliance off.
 - **LOW:** Provides a gentle airflow for delicate drying or styling.
 - **HIGH:** Delivers powerful airflow for quick drying.

5.2 Heat Settings

- The hair dryer features two heat settings:
 - **WARM:** For general drying and styling.
 - **HOT:** For faster drying and setting styles.
- Select the appropriate heat setting based on your hair type and desired style.

5.3 Cool Shot Function

- Press and hold the 'Cool Shot' button (snowflake icon) to instantly switch to cool air.
- This function is used to set your hairstyle and add shine after drying with warm or hot air. Release the button to return to the previously selected heat setting.

DETACHABLE **THIN NOZZLE**

Ensures concentrated &
focused styling for
men & women



Image 5.1: Close-up of the Havells HD3191 controls, highlighting the 2 heat settings and the cool shot button.

SWIVEL CORD AND **HANGING LOOP**

Hanging loop with 360°
tangle free swivel cord
for hassle free use



6. MAINTENANCE AND STORAGE

Proper maintenance ensures the longevity and optimal performance of your hair dryer.

6.1 Cleaning

- **Always unplug the appliance before cleaning.**
- Wipe the exterior of the hair dryer with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- **Clean the Air Inlet Filter:** Regularly check and clean the honeycomb air inlet filter at the back of the dryer. Remove any accumulated lint, dust, or hair using a soft brush or by gently wiping. A clogged filter can lead to overheating.



Image 6.1: Close-up view of the honeycomb air inlet, which should be kept clean for optimal performance.

6.2 Storage

- Ensure the appliance is completely cool before storing.
- The Havells HD3191 features a foldable handle for compact storage, making it ideal for travel. Fold the handle by gently pushing it towards the main body until it locks into place.

- Utilize the hanging loop located at the base of the handle for convenient storage on a hook.
- Do not wrap the power cord around the appliance as this can damage the cord. Store the cord loosely coiled.



Image 6.2: The foldable handle feature of the Havells HD3191, demonstrating its compact storage capability for travel.

HONEYCOMB INLET

Ensures safe handling
and do not allow hair
tangling



Image 6.3: Detail of the swivel cord and integrated hanging loop for convenient storage.

7. TROUBLESHOOTING

If you encounter any issues with your Havells HD3191 hair dryer, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Hair dryer does not turn on.	No power supply. Damaged power cord/plug.	Check if the plug is securely inserted into the outlet. Test the outlet with another appliance. If cord/plug is damaged, do not use and contact customer support.
Low airflow.	Clogged air inlet filter.	Unplug the dryer and clean the air inlet filter as described in Section 6.1.
Hair dryer overheats and shuts off.	Air inlets/outlets blocked. Prolonged use.	Unplug the dryer and allow it to cool down. Clean the air inlet filter. Ensure air outlets are not blocked during use. Reduce usage time if necessary.

Problem	Possible Cause	Solution
Unusual noise or smell.	Internal malfunction.	Immediately unplug the appliance. Do not use. Contact customer support.

8. SPECIFICATIONS

Key technical specifications for the Havells HD3191 1600W Foldable Hair Dryer:

Feature	Detail
Model Number	HD3191
Wattage	1600W
Voltage	240 Volts
Product Dimensions (LxWxH)	18.3 x 7.7 x 25.2 cm
Item Weight	335 g
Power Cord Length	1.6 meters
Heat Settings	2 (Warm, Hot)
Speed Settings	2 (Low, High)
Special Features	Cool Shot, Foldable Handle, Hanging Loop, Concentrator
Material	Plastic
Country of Origin	India

9. WARRANTY AND SUPPORT

9.1 Warranty Information

The Havells HD3191 1600W Foldable Hair Dryer comes with a**2-year manufacturer's guarantee** from the date of purchase. This warranty covers manufacturing defects under normal use. Please retain your purchase receipt as proof of purchase for warranty claims. The warranty does not cover damage caused by misuse, accident, unauthorized modification, or normal wear and tear.

9.2 Customer Support

For any product-related queries, service requests, or warranty claims, please contact Havells customer support:

- **Manufacturer:** Havells India Limited

- **Address:** QRG Tower 2D Sector 126 Noida - 201304, India
- Please refer to the official Havells website or your product packaging for the most current contact details, including phone numbers and email support.