

[Manuals.plus](#) /

› [DREAME](#) /

› Dreame Gleam Hair Dryer User Manual

DREAME Gleam

Dreame Gleam Hair Dryer User Manual

Model: Gleam

1. INTRODUCTION

Welcome to the user manual for your new Dreame Gleam Hair Dryer. This manual provides essential information on the safe and effective use, maintenance, and troubleshooting of your device. Please read it thoroughly before operating the hair dryer and retain it for future reference.

2. SAFETY INSTRUCTIONS

WARNING: To reduce the risk of electric shock, fire, or injury, please observe the following safety precautions:

- Keep out of reach of children.
- Do not use while bathing or near water.
- Keep the power cord away from heated surfaces.
- Unplug the hair dryer when not in use.
- In case of a malfunction, stop using immediately and contact customer service.
- Do not block the air inlet or outlet during operation.
- Do not modify or attempt to repair the appliance yourself.

3. PACKAGE CONTENTS

Verify that all items are present in your package:

- Dreame Gleam Hair Dryer
- Smoothing Nozzle Attachment
- User Manual

1. Smoothing Nozzle
2. Hair Dryer
3. Packing Box
4. User Manual



Package List

Image: The Dreame G16 Hair Dryer, smoothing nozzle, and user manual laid out next to the product packaging.

4. PRODUCT FEATURES

The Dreame G16 Hair Dryer is designed for efficient and gentle hair drying with advanced technology:

- **Powerful and Fast Drying:** Features a wind speed of 65m/s and an air volume of 55m³/h for quick drying.
- **Lightweight Design:** Weighs approximately 0.73 lbs (excluding power cord and nozzle) for comfortable handling.
- **Intelligent Temperature Control:** Maintains a safe temperature of 134.6°F (57°C) to minimize heat damage.
- **Frizz-Free Shine with Ions:** Releases up to 200 million negative ions to smooth hair and enhance natural shine.
- **Whisper-Quiet Operation:** Advanced air duct system minimizes noise to just 59 dB.
- **Versatile Temperature Settings:** Offers 4 temperature levels for customized styling.
- **Adjustable Airflow Speeds:** Provides 2 airflow speeds (High-Speed and Low-Speed).

5. GETTING STARTED (SETUP)

1. **Unpack:** Carefully remove all components from the packaging.
2. **Attach Nozzle:** Align the smoothing nozzle with the magnetic attachment point on the front of the hair dryer. The nozzle will snap into place securely.
3. **Connect Power:** Plug the power cord into a suitable electrical outlet. Ensure the voltage matches the specifications of the hair dryer.




Image: A diagram illustrating how to magnetically attach the smoothing nozzle to the front of the hair dryer.

6. OPERATING INSTRUCTIONS

Familiarize yourself with the controls and settings for optimal use:

Power On/Off

- Press the power button (usually located on the handle) to turn the hair dryer on or off.

Adjusting Temperature

The hair dryer offers 4 temperature levels:

- **Cool Air:** Approximately 77°F (25°C)
- **Warm Air:** Approximately 134.6°F (57°C)
- **Hot Air:** Approximately 185°F (85°C)
- **Natural & Hot Circulation:** Alternates between natural and hot air for balanced drying.

Press the temperature control button (often indicated by a thermometer icon) to cycle through the available settings.

Adjusting Airflow Speed

The hair dryer has 2 airflow speeds:

- **Low-Speed Airflow**
- **High-Speed Airflow**

Press the airflow control button (often indicated by fan icons) to switch between low and high speeds.

2 Airflow Speeds

-  High-Speed Airflow
-  Low-Speed Airflow

4 Temperature Levels

-  Cool Air (77°F)
-  Warm Air (134.6°F)
-  Hot Air (185°F)
-  Natural & Hot Circulation

2 Airflow Speeds 4 Temperature Levels

Image: A close-up view of the Dreame G16 Hair Dryer's handle, showing the power, temperature, and airflow control buttons.

7. MAINTENANCE AND CLEANING

Regular maintenance ensures optimal performance and longevity of your hair dryer.

Cleaning the Air Filter

1. **Unplug:** Always unplug the hair dryer from the power outlet before cleaning.
2. **Remove Filter Cover:** Gently twist or pull the air inlet filter cover (located at the bottom of the handle) to remove it.
3. **Clean Filter:** Use a soft brush or cloth to remove any dust, lint, or hair accumulated on the filter mesh. Do not use water or harsh chemicals.
4. **Reattach Cover:** Once clean, align the filter cover and reattach it securely.




Image: An illustration showing how to remove and clean the air filter at the base of the hair dryer handle.

General Cleaning

- Wipe the exterior of the hair dryer with a soft, damp cloth.
- Do not immerse the hair dryer in water or any other liquid.
- Ensure the hair dryer is completely dry before storing or using again.

8. TROUBLESHOOTING

If you encounter issues with your Dreame Gleam Hair Dryer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Hair dryer does not turn on.	No power supply; Power button not pressed.	Check if the power cord is securely plugged in. Press the power button firmly.
Weak airflow.	Air inlet filter is blocked.	Unplug the device and clean the air inlet filter as described in Section 7.
Hair dryer overheats and shuts off.	Overheating protection activated; Airflow blocked.	Unplug the device and allow it to cool down for several minutes. Ensure air inlets and outlets are clear. Clean the air filter.
Unusual noise or smell.	Internal malfunction.	Immediately unplug the device and discontinue use. Contact customer support.

9. TECHNICAL SPECIFICATIONS

- **Model:** Gleam
- **Brand:** DREAME
- **Product Dimensions:** 14 x 3.5 x 7 inches
- **Weight:** 2.71 Pounds (including packaging)
- **Wattage:** 1600 watts
- **Power Source:** Corded Electric
- **Special Features:** 4 temperature levels, Fast drying, Lightweight, Low Noise, Portable

10. WARRANTY AND CUSTOMER SUPPORT

For warranty information, please refer to the warranty card included with your product or visit the official DREAME website. If you require assistance, have questions, or need to report an issue, please contact DREAME customer support.

You can find more information and support resources by visiting the [DREAME Store on Amazon](#).



