



Manuals.plus / > AGARO / > AGARO SM3675 Scalp Massager Instruction Manual

AGARO SM3675

Sign in to save this manual Sign in to bookmark this manual and keep private notes.

AGARO SM3675 Scalp Massager Instruction Manual

Model: SM3675 | Brand: AGARO

1. INTRODUCTION

The AGARO SM3675 Scalp Massager is a rechargeable electric head kneading massager designed to provide stress relief, promote hair growth, and offer deep scalp cleaning. This handheld and portable device features three speed modes for a customized massage experience.



Image 1: AGARO SM3675 Scalp Massager.

2. PACKAGE CONTENTS

Please check the box for the following items:

- 1 x AGARO SM3675 Scalp Massager
- 1 x Charging Base
- 1 x Power Adaptor
- 1 x User Manual

3. KEY FEATURES

- **360° Rotation & 3 Speed Modes:** The massager features four rotating heads that move in both clockwise and anti-clockwise directions, imitating human fingers for a soothing massage. It offers 3 speed settings (Slow Forward, Slow Alternate, Alternating in Positive Direction) to customize your experience.



Image 2: Three automatic speed modes for varied massage intensity.

- **Soft Silicone Heads:** Equipped with soft silicone bristles, the massage heads prevent hair pulling or tangling and are gentle on the skin. The heads are detachable for easy cleaning and maintenance.



Image 3: Detachable silicone heads for comfort and hygiene.

- **Rechargeable & Cordless Design:** Powered by a rechargeable lithium-ion battery, the massager is cordless for convenient use anywhere. It comes with a charging base and power adaptor.




Image 4: Rechargeable design with magnetic USB charging.

- **Portable:** Its compact and cordless design makes it easy to carry, allowing for massage on-the-go.

Take Your
Portable Massager
Anywhere!




Image 5: Compact and portable for use anywhere.

- **Multi-purpose Use:** Suitable for head, neck, arm, leg, and back massage. It can be used for hair growth stimulation, stress relief, and deep cleaning.



Image 6: Versatile use for different body areas.

Advertisements

4. SETUP AND CHARGING

4.1 Initial Charging

Before first use, fully charge the AGARO SM3675 Scalp Massager. Connect the charging cable to the massager and the power adaptor, then plug it into a power outlet. The indicator light will show charging status. A full charge provides approximately 60 minutes of runtime.

4.2 Attaching the Massage Heads

Ensure the massage heads are securely attached to the main unit before use. They are designed for easy attachment and detachment for cleaning.

Advertisements

5. OPERATING INSTRUCTIONS

5.1 Power On/Off and Speed Selection

- **To Power On:** Press and hold the power button for a few seconds until the massager starts.
- **To Change Speed Mode:** Briefly press the power button to cycle through the 3 available speed modes.
- **To Power Off:** Press and hold the power button again for a few seconds until the massager stops.

5.2 Usage Guidelines

The massager can be used on dry, wet, or oil-based scalps. Apply gentle pressure and move the massager in circular motions across the desired area. Recommended usage is 5-10 minutes per session. The device features a 15-minute auto shut-off for safety and convenience.

5.3 Video Demonstration




Video 1: Demonstrating the 3 speed modes and 360° rotation for head and scalp massage.

Advertisements



Video 2: Highlighting benefits such as stress relief, blood circulation, and hair growth.



Video 3: Showcasing the massager's waterproof design, ease of cleaning, and portability.

6. MAINTENANCE AND CLEANING

To ensure longevity and hygiene of your massager:

Advertisements

- **Cleaning Massage Heads:** The silicone massage heads are detachable. After each use, remove them and rinse under running water. Use a mild soap if necessary. Ensure they are completely dry before reattaching.
- **Cleaning Main Unit:** Wipe the main unit with a damp cloth. Do not submerge the main unit in water as it is not water resistant beyond the massage heads.
- **Storage:** Store the massager in a cool, dry place away from direct sunlight.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Massager does not turn on	Low battery or no charge	Charge the device fully using the provided charging base and adaptor.
Massage heads stop rotating	Excessive pressure applied	Reduce pressure on the scalp. The massager is designed for gentle use.
Reduced massage intensity	Low battery	Recharge the massager.

8. SPECIFICATIONS

Feature	Detail
Product Dimensions	10.5L x 9W x 7.5H Centimeters
Item Weight	189 Grams
Power Source	Battery Powered
Material	Silicone
Color	White
Special Feature	Body massage, Scalp massage, Rechargeable
Massage Therapy Technique	Kneading
Water Resistance Level	Not Water Resistant (main unit)
Model Name	SM3675
Battery Runtime	60 minutes (approx.)
Auto Shut-off	15 minutes

9. WARRANTY AND SUPPORT

The AGARO SM3675 Scalp Massager comes with a **1 Year Warranty**. This warranty covers manufacturing defects of the product during the warranty period.

For any queries or concerns, you can connect with AGARO customer support:

Advertisements

- **Email:** info@uclindia.com
- **Customer Support:** 9821486487
- **Timings:** 10:00 AM to 6:00 PM (IST) Mon-Sat (Excluding Holidays)

10. IMPORTANT SAFETY INFORMATION

- Do not use the massager on broken, inflamed, or irritated skin.
- Keep out of reach of children.
- Do not use while charging.
- Consult a doctor before use if you have any medical conditions, especially related to the scalp or head.
- Use only the provided charging cable and adaptor.
- Avoid extreme temperatures and direct sunlight.

Advertisements

Related Documents - SM3675

	AGARO Marvel 48L Oven Toaster Griller User Manual Comprehensive user manual for the AGARO Marvel 48L Oven Toaster Griller. This guide covers safety precautions, included accessories, component identification, control operations, detailed usage instructions for rotisserie and grilling, maintenance, technical specifications, and warranty information. Also briefly mentions AGARO Marvel 25L and 38L models.
	Agaro HD1120 Professional Hair Dryer User Manual User manual for the Agaro HD1120 Professional Hair Dryer, detailing its features, settings, usage instructions, and warranty information.
	AGARO HD-1120 Professional Hair Dryer User Manual & Specifications Comprehensive user manual for the AGARO HD-1120 2000 Watts Professional Hair Dryer. Includes features, operating instructions, safety precautions, specifications, and warranty information.
	AGARO Grand-30L Oven Toaster Griller Instruction Manual This manual provides detailed instructions for operating and maintaining the AGARO Grand-30L Oven Toaster Griller. It covers safety precautions, component identification, various cooking functions, cleaning, storage, specifications, and warranty information.
	Agaro Humidifier Verge 2.5Ltr User Manual and Specifications This document provides the user manual, operating instructions, maintenance guide, and product specifications for the Agaro Humidifier Verge 2.5Ltr. Learn how to safely operate, clean, and maintain your humidifier for optimal performance.
	AGARO Regal Electric Multi Cooker 3L User Manual and Warranty Information Comprehensive user manual and warranty details for the Agaro Regal Electric Multi Cooker 3L (Model AG 31, Item No. 33959). Includes cleaning, safety, operating instructions, specifications, and warranty card.

ASK A QUESTION ABOUT THIS MANUAL