
[Manuals.plus](#) /

› [Dyson](#) /

› Dyson Airstrait™ Straightener User Manual (Model 453951-01)

Dyson 453951-01

Dyson Airstrait™ Straightener User Manual

Model: 453951-01

INTRODUCTION

This manual provides comprehensive instructions for the safe and effective use of your Dyson Airstrait™ Straightener. The Dyson Airstrait™ is engineered to dry and straighten hair simultaneously from wet to dry, creating a natural straight finish for various hair types. This device operates without hot plates, aiming to minimize heat damage during styling. The Airstrait™ precisely heats and projects air evenly through the hair tress during styling. It includes sensors that detect hair between the arms, automatically reducing airflow when not in use for quieter and more efficient operation. The design aims to maintain hair strength and protect shine.

PRODUCT OVERVIEW



Image: The Dyson Airstrait™ Straightener in Ceramic Pink, shown from two angles (closed and open).

The Dyson Airstrait™ Straightener is designed for efficient hair styling, combining drying and straightening functions. It utilizes focused airflow to achieve a straight finish.

Key Features:

- **Wet-to-Dry Styling:** Dries and straightens hair simultaneously, eliminating the need for separate drying.
- **No Hot Plates:** Styles hair using air, reducing direct heat contact.
- **Intelligent Heat Control:** Sensors monitor hair presence, adjusting airflow for optimal performance and energy efficiency.
- **Hair Health Focus:** Engineered to help maintain hair strength and enhance natural shine.



Image: An internal diagram illustrating the airflow path within the Dyson Airstrait™ Straightener.

In the Box

Upon unboxing your Dyson Airstrait™ Straightener, verify that all components are present:




Image: Contents of the Dyson Airstrait™ package, including the straightener and a non-slip heat mat.

- Dyson Airstrait™ Straightener
- Non-slip Heat Mat

SETUP

1. **Unpack:** Carefully remove the straightener and all accessories from the packaging.
2. **Placement:** Place the non-slip heat mat on a flat, heat-resistant surface where you intend to style your hair.
3. **Power Connection:** Plug the power cord into a suitable electrical outlet. Ensure the voltage matches your region's requirements.
4. **Initial Check:** Before first use, ensure the air inlets at the base of the straightener are clear of any obstructions.

OPERATING INSTRUCTIONS

The Dyson Airstrait™ offers two primary styling modes: Wet mode for damp hair and Dry mode for touch-ups or refreshing styles.

Straightening from Wet Hair

This mode is designed to dry and straighten hair simultaneously. Begin with towel-dried hair.



Image: Illustration of the Dyson Airstrait™ in wet mode, demonstrating how air is used to straighten damp hair.

1. **Prepare Hair:** Gently towel-dry your hair to remove excess water.
2. **Select Wet Mode:** Turn on the device and select the "Wet" mode. The display will show a wet hair icon.
3. **Pre-dry Roots:** For optimal results, lock the arms of the straightener and use the maximum airflow and high temperature settings to rough dry your roots.
4. **Section Hair:** Unlock the arms. Divide your hair into manageable sections.
5. **Style:** Select your desired airflow and temperature settings. Pass the straightener through each section of damp hair from roots to ends. The device will dry and straighten simultaneously.

6. **Cold Shot (Optional):** Use the cold shot function to set your style.



Image: A visual guide demonstrating the four key steps for styling with the Dyson Airstrait™: towel drying, pre-drying roots, sectioning and styling, and finishing with a cold shot.

Straightening from Dry Hair

Use this mode to touch up or refresh your existing style.

Straighten from dry

Touches up dry hair with directional airflow to smooth and align hair for a refreshed style.



Image: Illustration of the Dyson Airstrait™ in dry mode, demonstrating how air is used to smooth and align dry hair.

1. **Select Dry Mode:** Turn on the device and select the "Dry" mode.
2. **Adjust Settings:** Choose your desired airflow and temperature settings. A "Boost" mode is available if additional heat is required.
3. **Style:** Pass the straightener through sections of dry hair to smooth and align for a refreshed look.

MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your Dyson Airstrait™ Straightener.

- **Cleaning the Filter:** Periodically check and clean the filter located at the base of the handle. Refer to the full user manual for detailed instructions on filter removal and cleaning.
- **Wipe Down:** After each use, ensure the device is unplugged and cool. Wipe the exterior surfaces with a soft, damp cloth to remove any hair product residue.
- **Storage:** Store the straightener in a dry, safe place, preferably on its non-slip heat mat, away from direct sunlight.

and moisture.

- **Cord Care:** Avoid wrapping the power cord tightly around the device, as this can cause damage over time.

TROUBLESHOOTING

If you encounter issues with your Dyson Airstrait™ Straightener, consult the following common troubleshooting steps:

Problem	Possible Cause	Solution
Device not turning on	No power supply; loose connection	Ensure the power cord is securely plugged into a working outlet. Check the circuit breaker.
Reduced airflow or performance	Blocked air filter; internal obstruction	Clean the air filter. Ensure air inlets are clear. If the problem persists, contact support.
Hair not straightening effectively	Incorrect mode selected; hair too wet/dry; sections too large	Ensure "Wet" mode for damp hair and "Dry" mode for dry hair. Use smaller sections. Adjust temperature/airflow settings.
Unusual noise or smell	Internal issue; foreign object	Immediately unplug the device. Do not attempt to repair. Contact Dyson customer support.

For further assistance, refer to the official Dyson support website or contact customer service.

SPECIFICATIONS

Brand: Dyson

Model Number: 453951-01

UPC: 885609034881

Product Dimensions: 13 x 1.6 x 2.4 inches

Weight: 2.2 Pounds

Material: Aluminum, Ceramic, Polycarbonate

Color: Ceramic Pink

Manufacturer: Dyson

WARRANTY AND SUPPORT

Your Dyson Airstrait™ Straightener is covered by a limited warranty. Please refer to the warranty card included with your product for specific terms and conditions, including coverage duration and exclusions.

For product registration, warranty claims, technical support, or to purchase replacement parts, please visit the official Dyson support website or contact their customer service department.

Dyson Official Website: www.dyson.com

