Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Elica SAPPHIRE CT VETRO (DT SERIES)

Elica SAPPHIRE 594 CT VETRO 1J (DT SERIES) 60cm 4 Burner Gas Stove User Manual

Model: SAPPHIRE CT VETRO (DT SERIES)

1. Product Overview

The Elica SAPPHIRE 594 CT VETRO 1J (DT SERIES) is a 60cm 4-burner gas stove designed for efficient and convenient cooking. It features a durable toughened glass top, high-efficiency vertical flame brass burners, and a double drip tray for easy cleaning. This manual provides essential information for the safe and effective use of your gas stove.



Image 1.1: Top view of the Elica SAPPHIRE 594 CT VETRO 1J (DT SERIES) 60cm 4 Burner Gas Stove.

Key Features:

- **High-Efficiency Vertical Flame Burners:** Precision-engineered for optimal air-gas mixture, ensuring faster cooking and even heat distribution.
- **High Efficiency Brass Burners:** Includes 1 Jumbo, 1 Medium, and 2 Small burners for versatile cooking needs.
- **Double Drip Tray Design:** Effectively traps spills and liquids for easy cleaning.
- **Toughened Glass Top:** Durable black glass that resists stains and heat discoloration.
- **Euro-Coated Pan Supports:** Round grids provide stability for various pot and pan sizes.

- **Stainless Steel Frame:** Offers sturdiness and a modern aesthetic.

2. Safety Information

Read all instructions carefully before using the appliance. Keep this manual for future reference. Failure to follow these instructions could result in fire, explosion, electric shock, or other hazards, causing property damage, personal injury, or death.

General Safety Precautions:

- Ensure proper ventilation in the kitchen area during operation.
- Do not store flammable materials near the gas stove.
- Keep children and pets away from the appliance during use.
- Never leave cooking unattended.
- Use only appropriate cookware for gas stoves.
- Do not use the gas stove as a space heater.
- In case of a gas leak, immediately turn off the gas supply, open windows, and do not operate any electrical switches or appliances. Contact a qualified technician.

3. Setup and Installation

Proper installation is crucial for the safe and efficient operation of your Elica gas stove. It is highly recommended to have the appliance installed by a qualified service technician.

Unpacking:

1. Carefully remove the gas stove from its packaging.
2. Check for any damage during transit. If damage is found, do not install and contact customer service.
3. Ensure all included components are present: 1 Unit Gas Stove, User Manual, and Warranty Card.

Placement:

- Place the gas stove on a stable, level, and heat-resistant surface.
- Ensure adequate clearance from walls and overhead cabinets as per local regulations.

- The product dimensions are 56 cm (D) x 60 cm (W) x 11 cm (H), making it suitable for most modular kitchens.



Image 3.1: Illustration of the 60cm 4 Burner Gas Stove with its dimensions (60cm width, 56cm depth, 11cm height).

Gas Connection:

- Connect the gas stove to a suitable gas supply (LPG or PNG, depending on the model and local regulations) using an approved gas hose and regulator.
- Ensure all connections are tight and leak-free. Use soapy water to check for leaks; bubbles indicate a leak.

- This step should ideally be performed by a certified gas technician.

4. Operating Instructions

Your Elica gas stove is equipped with high-efficiency burners and user-friendly knob controls for precise cooking.

Burner Configuration:

The stove features a versatile 4-burner setup:

- 1 Jumbo Burner
- 1 Medium Burner
- 2 Small Burners



Image 4.1: Diagram illustrating the 4-burner setup with one Jumbo, one Medium, and two Small burners.

Igniting a Burner:

1. Ensure the gas supply is open.
2. Place your cookware on the Euro-Coated Pan Supports over the desired burner.
3. Push and turn the corresponding control knob counter-clockwise to the 'Ignite' position.
4. Hold the knob in the 'Ignite' position for a few seconds until the flame is stable.
5. Adjust the flame intensity by turning the knob between the 'High' and 'Low' settings.



Image 4.2: The Elica gas stove with all four burners actively producing a blue flame.

Vertical Flame Technology:

The vertical flame design optimizes the air-gas mixture, directing heat upwards more efficiently. This results in faster cooking, reduced gas consumption, and even heat distribution, ideal for various Indian cooking styles.




Image 4.3: Close-up illustration of the vertical flame technology, showing the optimized air-gas mix and upward flame direction.

5. Maintenance and Cleaning

Regular cleaning and maintenance will ensure the longevity and optimal performance of your Elica gas stove.

Daily Cleaning:

- Allow the stove to cool completely before cleaning.

- Wipe the toughened glass top with a soft cloth and mild detergent. Avoid abrasive cleaners that can scratch the surface.
- The double drip tray can be easily removed and cleaned with soap and water.




Image 5.1: Exploded view illustrating the layers of the toughened glass top, including tempered glass, high-temperature resistant ink, explosion-proof layer, and cushion.

Burner and Pan Support Cleaning:

- Remove the Euro-Coated Pan Supports and brass burners.
- Clean them with warm soapy water and a non-abrasive brush. Ensure all food residues are removed.
- Dry all parts thoroughly before reassembling. Ensure burner holes are not clogged.



Image 5.2: Illustration highlighting the Euro-Coated Pan Supports, designed for stability of heavy pots and pans.

6. Troubleshooting

This section addresses common issues you might encounter with your gas stove. For problems not listed here, or if solutions do not work, contact authorized service personnel.

Common Issues and Solutions:

- **Burner not igniting:**

- Check if the gas supply is open.
- Ensure the burner cap and crown are correctly placed.
- Clean any food debris from the burner holes and igniter pin.
- Hold the knob in the 'Ignite' position for a longer duration.

- **Irregular or yellow flame:**
  - Clean the burner holes to ensure proper gas flow.
  - Ensure the burner is dry and correctly assembled.
  - Check for proper ventilation in the kitchen.

- **Gas smell:**
  - Immediately turn off the gas supply.
  - Open windows and doors for ventilation.
  - Do not operate any electrical switches or appliances.
  - Contact a qualified gas technician immediately.

7. Specifications

Feature	Specification
Brand	Elica
Model Number	SAPPHIRE CT VETRO (DT SERIES)
Colour	Black
Material Type	Glass
Heating Elements	4 (1 Jumbo, 1 Medium, 2 Small)
Special Feature	Vertical Flame Technology
Controls Type	Knob
Item Dimensions (D x W x H)	56D x 60W x 11H Centimeters
Item Weight	8.8 Kilograms
Recommended Uses	Cooking

Included Components	1 Unit Gas Stove, User Manual and Warranty Card
Manufacture Year	2025
Country of Origin	India

8. Warranty and Support

Elica provides comprehensive support for your gas stove. Please retain your purchase receipt for warranty claims.

Warranty Details:

- **7 Years Warranty on Glass:** Covers manufacturing defects in the toughened glass top.
- **2 Years Comprehensive Warranty:** Covers other manufacturing defects from the date of purchase.



Image 8.1: Visual representation of the 7-year warranty on glass, 2-year comprehensive product warranty, and ISI certification.

Customer Support:

For service, installation, or any queries regarding your Elica gas stove, please contact:

ELICA PB WHIRLPOOL KITCHEN APPLIANCES PRIVATE LIMITED
(Formerly known as - Elica PB India Private Limited)
32/5 A1 Kondhwa-Pisoli Road, Pisoli, Pune 411060 Maharashtra India

Please refer to the warranty card included with your product for specific terms and conditions and contact information.