

Manuals.plus / > Wonderchef / > Wonderchef Luxe Multi Cook Kettle User Manual

Wonderchef 63154900

Sign in to save this manual Sign in to bookmark this manual and keep private notes.

Wonderchef Luxe Multi Cook Kettle User Manual

Model: 63154900

Advertisements

1. INTRODUCTION

The Wonderchef Luxe Multi Cook Kettle is a compact and versatile kitchen appliance designed to simplify your daily cooking. With its 1.2-liter capacity and 600W power, it is perfect for preparing a variety of dishes, from boiling water and milk to cooking noodles, steaming vegetables, and boiling eggs. Its elegant design and robust safety features make it a valuable addition to any kitchen.



Figure 1.1: Wonderchef Luxe Multi Cook Kettle, showcasing its compact design and included steamer.

Advertisements

2. IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the appliance in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts, and before cleaning the appliance.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions, or has been damaged in any manner.
- The appliance is equipped with an **Automatic Shut-Off** feature for safety. It also includes **Overheat Protection** and **Boil-Dry Protection** to prevent damage and ensure safe operation.
- Ensure the heating element is always concealed and not exposed during operation.

Advertisements



Safe to Use



Automatic Shut-off



Overheat Protection



Boil-dry Protection



Concealed Heating Element



Figure 2.1: Key safety features of the Multi Cook Kettle.

3. PRODUCT COMPONENTS

Your Wonderchef Luxe Multi Cook Kettle package includes the following components:

Advertisements



- 1 x Multi Cook Electric Kettle Unit

- 1 x Glass Lid
- 1 x Steamer Pot
- 1 x Egg Stand



Figure 3.1: The Multi Cook Kettle with its included egg stand and steamer pot, demonstrating its versatility for preparing healthy breakfasts.

4. SETUP

4.1 Initial Cleaning

1. Before first use, wipe the exterior of the kettle with a damp cloth.
2. Wash the interior of the kettle, glass lid, steamer pot, and egg stand with warm, soapy water. Rinse thoroughly and dry.
3. Do not immerse the main kettle unit (with electrical components) in water.

4.2 Placement

- Place the kettle on a stable, flat, heat-resistant surface.
- Ensure there is adequate ventilation around the appliance.
- Keep away from direct sunlight and heat sources.

5. OPERATING INSTRUCTIONS

5.1 General Operation

1. Fill the kettle with the desired amount of water or ingredients. Do not exceed the MAX fill line.
2. Place the lid securely on the kettle.
3. Plug the power cord into a suitable electrical outlet.
4. Turn the control knob to select the desired power mode (low or high) or temperature setting.
5. The indicator light will illuminate, indicating that the kettle is heating.
6. Once cooking is complete or the desired temperature is reached, the kettle will automatically shut off.
7. Unplug the kettle from the power outlet after use.

Advertisements



Custom Cooking Option

With Dual Power Mode



Figure 5.1: Adjusting the custom cooking option with dual power modes.

Advertisements



5.2 Specific Cooking Functions

- **Boiling Water/Milk:** Fill the kettle with water or milk, select the high power mode, and wait for it to boil.
- **Cooking Noodles/Pasta:** Add water and noodles/pasta to the kettle. Use the desired power mode until cooked. Stir occasionally to prevent sticking.
- **Steaming:** Pour water into the main kettle unit (ensure it does not touch the bottom of the steamer pot). Place ingredients in the steamer pot, then place the steamer pot on top of the kettle. Cover with the glass lid and select the desired power mode.
- **Boiling Eggs:** Place the egg stand inside the kettle. Arrange eggs on the stand. Add water to cover the eggs. Select the high power mode.

The Calm To Your Morning Storm

Boil, Steam and Cook, in Just a Few Minutes!



Figure 5.2: The kettle's ability to prepare diverse meals, from hot beverages to steamed vegetables and noodles.

6. CLEANING AND MAINTENANCE

Regular cleaning ensures the longevity and optimal performance of your Multi Cook Kettle.

Advertisements



1. Always unplug the kettle and allow it to cool completely before cleaning.
2. Remove the glass lid, steamer pot, and egg stand. Wash these removable attachments with warm, soapy water and a soft sponge. Rinse thoroughly and dry.
3. For the interior of the main kettle unit, use a soft sponge and mild dish soap. For stubborn stains, a mixture of vinegar and water can be used, then rinse thoroughly.
4. Wipe the exterior of the kettle with a damp cloth. Do not use abrasive cleaners or scouring pads, as they may damage the surface.

5. Ensure all parts are completely dry before storing or next use.



Figure 6.1: The removable attachments are designed for easy cleaning.

Advertisements



7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Kettle does not turn on.	Not plugged in; power outlet not working; kettle overheated.	Ensure plug is securely in outlet; test outlet with another appliance; allow kettle to cool down.
Food burns at the bottom.	Insufficient liquid; cooking at too high a temperature for too long without stirring.	Ensure adequate liquid for cooking; use lower power mode for delicate items; stir frequently.

Problem	Possible Cause	Solution
Kettle shuts off prematurely.	Boil-dry protection activated; kettle overheated.	Add more liquid; allow kettle to cool down before restarting.
Steam leakage from lid.	Lid not properly seated; lid damaged.	Ensure lid is placed correctly and securely; inspect lid for damage.

8. SPECIFICATIONS

Model Number	63154900
Capacity	1.2 Litres
Power	600W
Material	Stainless Steel (Interior), ABS Plastic (Exterior)
Colour	Ivory / White
Product Dimensions (L x W x H)	23L x 16W x 20H Centimeters
Item Weight	1 Kilogram
Included Components	1 Multi Cook Electric Kettle, 1 Glass Lid, 1 Steamer Pot, 1 Egg Stand

9. WARRANTY INFORMATION

The Wonderchef Luxe Multi Cook Kettle comes with a **2-Year Manufacturer's Warranty** from the date of purchase. This warranty covers manufacturing defects and faulty materials under normal household use.

Advertisements

The warranty does not cover:

- Damage caused by misuse, abuse, accident, or alteration.
- Normal wear and tear.
- Damage resulting from failure to follow operating instructions.
- Commercial use.

Please retain your purchase receipt as proof of purchase for warranty claims.

Advertisements

10. CUSTOMER SUPPORT

For any queries, assistance, or warranty claims regarding your Wonderchef Luxe Multi Cook Kettle, please contact Wonderchef Customer Service:

Manufacturer: Wonderchef Home Appliance Pvt. Ltd.

Phone: 18602660788

WhatsApp: 7070595959

Our support team is available to assist you with product inquiries, troubleshooting, and service requests.

Advertisements



© 2024 Wonderchef. All rights reserved.

Advertisements



Related Documents - 63154900

	Wonderchef Automatic Soup Maker 1L - User Manual & Operating Guide Comprehensive user manual for the Wonderchef Automatic Soup Maker (1L, 800W). Get detailed instructions on safe operation, features, cleaning, maintenance, and troubleshooting for your kitchen appliance.
	Wonderchef Power Induction Plate User Manual User manual for the Wonderchef Power Induction Plate, model WCINC02W180001. Includes operating principles, features, instructions for use, safety precautions, troubleshooting, and technical specifications.
	Wonderchef Nutri-blend with Big Mixer Jar User Manual User manual for the Wonderchef Nutri-blend with Big Mixer Jar, detailing important safeguards, parts, operating instructions for blending and grinding, cleaning, maintenance, storage, and specifications.
	Wonderchef OTG 9 Litres Oven Toaster Griller: Instruction Manual & Cooking Guide Comprehensive instruction manual for the Wonderchef OTG 9 Litres Oven Toaster Griller. Find detailed guides on important safeguards, components, usage, grilling, maintenance, and cooking recipes.
	Wonderchef Nutri-blend CKM Complete Kitchen Machine User Manual Comprehensive user manual for the Wonderchef Nutri-blend CKM Complete Kitchen Machine. Includes important safety guards, parts diagram, operating instructions for blending, grinding, juicing, and chopping, cleaning and maintenance guidelines, and detailed specifications.



Wonderchef Nutri-blend CKM User Manual: Complete Kitchen Machine, Blender, Grinder, Chopper

Detailed user manual for the Wonderchef Nutri-blend CKM, a 400W, 22000 RPM complete kitchen machine. Learn about its features, operating instructions for blending, grinding, chopping, juicing, safety guidelines, cleaning, and specifications.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

WONDERCHEF 63154900

KEEP EXPLORING MANUALS, GUIDES, AND SUPPORT DOCS.

Search model numbers, browse help resources, and jump straight into the next PDF manual or troubleshooting page without losing your place.

Wonderchef 63154900 m...

Search Manuals+

EXPLORE

Deep Search

Upload

Login

MANUALS+

[Home](#)

[About Us](#)

[Privacy Policy](#)

[Login](#)

GUIDES

[Amazon Manuals](#)

[AliExpress Manuals](#)

[Video Guides](#)

[Login](#)

FOLLOW

[@manualsplus](#)

[YouTube](#)

[LinkedIn](#)

[Facebook](#)

[Login](#)

Manuals+

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners.

SAVE MANUALS, NOTES, UPLOADS, AND QUESTIONS

Sign in with Google, X, or a passkey to keep private notes on saved manuals, track public uploads, and revisit questions you posted.

[Open login options](#)