

Bajaj 670110

Bajaj KTP 1.7 Litre Electric Kettle Instruction Manual

Model: KTP 1.7 Gold (670110)

1. IMPORTANT SAFEGUARDS

Please read all instructions carefully before using your Bajaj KTP 1.7 Litre Electric Kettle. Retain this manual for future reference.

- Do not immerse the kettle, power base, or power cord in water or any other liquid.
- Ensure the kettle is placed on a stable, flat, heat-resistant surface, away from the edge of the countertop.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Do not operate the kettle if the power cord or plug is damaged, or if the kettle malfunctions or has been damaged in any manner. Contact customer service for assistance.
- Do not fill the kettle above the maximum fill line or below the minimum fill line to prevent boiling dry or water splashing.
- Always unplug the kettle from the power outlet when not in use and before cleaning.
- Avoid contact with steam escaping from the spout or lid during and after boiling.
- Use the kettle only with the provided power base.
- Do not use the kettle for anything other than heating water.

2. PRODUCT OVERVIEW

The Bajaj KTP 1.7 Litre Electric Kettle is designed for efficient and safe water boiling. It features a 1.7-litre capacity, 1500W power, and a durable 304 food-grade stainless steel inner body.



The Bajaj KTP 1.7 Litre Electric Kettle, showcasing its elegant design alongside a cup of tea.



Key features of the kettle including its power, capacity, cool touch exterior, and double wall construction.

Key Features:

- **1.7 Litre Capacity:** Ideal for families or multiple servings.
- **1500 Watts Power:** For rapid boiling.
- **304 Food Grade Stainless Steel Inner Body:** Ensures hygienic and safe boiling.
- **Double Wall Construction:** Keeps the exterior cool to touch and retains heat longer.
- **Automatic Shut-Off:** Kettle automatically turns off once water boils.
- **Dry Boil Protection:** Prevents damage by automatically switching off if the kettle is accidentally switched on without water.
- **One-Touch Lid Opening:** For easy filling and cleaning.

- **360° Rotatable Power Base:** Allows for convenient placement and lifting from any angle.
- **Cord Winder:** Integrated into the power base for neat storage.



The power base with its integrated cord winder for easy storage and 360° rotatable design.



A detailed view of the detachable power base and its electrical connection.

3. SETUP

3.1 Unpacking

1. Carefully remove the kettle and all accessories from the packaging.
2. Check for any damage. If the appliance is damaged, do not use it and contact customer service.
3. Ensure all components listed in the 'What's in the Box' section are present.

3.2 First Use Cleaning

Before using the kettle for the first time, or if it has been stored for a long period, it is recommended to clean it.

1. Fill the kettle with clean water up to the maximum fill line.
2. Boil the water.

3. Discard the boiled water.
4. Repeat this process 2-3 times to remove any manufacturing residues.

3.3 Placement and Power Connection

1. Place the power base on a dry, flat, and stable surface.
2. Unwind the power cord to the desired length from the cord winder at the base.
3. Plug the power cord into a grounded electrical outlet.
4. Place the kettle securely onto the power base.

4. OPERATING INSTRUCTIONS

4.1 Filling the Kettle

1. Remove the kettle from its power base.
2. Press the lid release button to open the lid.
3. Fill the kettle with the desired amount of fresh water. Ensure the water level is between the MIN and MAX marks indicated inside the kettle.
4. Close the lid firmly until it clicks into place.

4.2 Boiling Water

1. Place the filled kettle back onto its power base.
2. Press the ON/OFF switch downwards. The indicator light will illuminate, signifying that the kettle is heating.
3. The kettle will automatically switch off once the water has boiled, and the indicator light will turn off.
4. You can manually switch off the kettle at any time by lifting the ON/OFF switch upwards.

4.3 Automatic Shut-Off and Dry Boil Protection

- The kettle is equipped with an automatic shut-off feature that activates when the water reaches boiling point, ensuring energy efficiency and safety.
- In case the kettle is accidentally switched on without sufficient water, the dry boil protection feature will automatically turn off the heating element to prevent damage. If this occurs, unplug the kettle and allow it to cool down for 15-20 minutes before refilling with water.

5. CLEANING AND MAINTENANCE

Regular cleaning and maintenance will prolong the life of your kettle and ensure optimal performance.

5.1 Exterior Cleaning

1. Always unplug the kettle from the power outlet and allow it to cool completely before cleaning.
2. Wipe the exterior of the kettle with a soft, damp cloth. Do not use abrasive cleaners or scouring pads, as these can scratch the surface.
3. Ensure no water enters the electrical components.

5.2 Interior Cleaning and Descaling

Over time, mineral deposits (limescale) may build up inside the kettle, especially in hard water areas.

Descaling is recommended periodically.

1. Fill the kettle with 1 part white vinegar and 2 parts water (or use a commercial descaling solution according to its instructions).
2. Boil the mixture.
3. Allow the solution to soak in the kettle for at least 30 minutes, or longer for heavy scale.
4. Discard the solution and rinse the interior thoroughly with fresh water several times.
5. If necessary, boil clean water once or twice and discard to remove any residual vinegar smell.

5.3 Storage

When not in use, ensure the kettle is clean and dry. The power cord can be neatly wound around the cord winder at the base for compact storage.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Kettle does not turn on.	No power supply. Kettle not properly seated on base. ON/OFF switch not pressed.	Check power outlet. Ensure kettle is correctly placed on the power base. Press the ON/OFF switch firmly.
Kettle switches off before boiling.	Dry boil protection activated (insufficient water).	Unplug, allow to cool for 15-20 minutes, then refill with water and restart. Ensure water level is above MIN mark.
Water has an unusual taste or odor.	First use residues. Limescale buildup.	Perform first use cleaning steps (boil and discard water several times). Descale the kettle as per cleaning instructions.
Kettle exterior is hot.	This model features a double wall for cool touch, but the lid and spout area can still get hot.	Always handle the kettle by the handle. Avoid touching the lid or spout during and immediately after boiling.

7. SPECIFICATIONS

- **Model:** KTP 1.7 Gold (670110)
- **Capacity:** 1.7 Litres
- **Power:** 1500 Watts
- **Material:** Stainless Steel 304 (Inner Body), Plastic (Outer Body)
- **Dimensions (L x W x H):** 22.6L x 16.5W x 24.8H Centimeters
- **Weight:** 1000 Grams
- **Special Features:** Automatic Shut-Off, Dry Boil Protection, Double Wall, Concealed Element, 360° Rotatable Base, Cord Winder.

8. WARRANTY AND SUPPORT

8.1 Warranty Information

Your Bajaj KTP 1.7 Litre Electric Kettle comes with a **2-year warranty** from the date of purchase. This warranty covers manufacturing defects under normal household use. It does not cover damage resulting from misuse, neglect, accidental damage, unauthorized repairs, or normal wear and tear.

Please retain your purchase receipt as proof of purchase for warranty claims.

8.2 Customer Support

For any queries, service requests, or warranty claims, please contact Bajaj customer support:

- **Manufacturer:** BAJAJ ELECTRICALS LTD.
- **Contact Number:** 022-41280000
- **Address:** 45/47, Veer Nariman Road, Mumbai, 400001

You may also visit the official Bajaj website for more information and support resources.