

AGARO Delite

AGARO Delite Portable Electric Kettle

INSTRUCTION MANUAL

1. Introduction

Thank you for choosing the AGARO Delite Portable Electric Kettle. This 500ml capacity kettle is designed for convenience and versatility, offering quick boiling, adjustable temperature settings, and functions like keeping warm, dechlorination, and porridge preparation. Please read this manual carefully before use to ensure safe and optimal operation.



Image: The AGARO Delite Portable Electric Kettle, showcasing its compact and modern design.

2. Product Features

- **500ml Capacity:** Ideal for single servings or travel.
- **Fast Boiling:** Quickly heats water to desired temperatures.
- **Adjustable Temperature Settings:** Customize water temperature from 45°C to 95°C.
- **Keep Warm Function:** Maintains desired temperature for extended periods.
- **Dechlorination Function:** Helps reduce chlorine content in water.
- **Porridge Function:** Specialized setting for preparing porridge.
- **Double Layer Body:** Features a 304 stainless steel interior and plastic exterior for cool-touch handling.
- **LED Touch Control:** Intuitive interface for easy operation.
- **Safety Lock:** Lid-lock mechanism ensures safe operation.
- **Dry-Boil Protection:** Automatically shuts off if water level is too low.

One kettle

Many possibilities



Image: The kettle displaying various functions like dechlorination, boil water, keep warm, porridge, and temperature adjustment.

Compact & Smart



Dry-boil protection



LED Touch Control



Steam outlet



Power Port



Safety lock

Image: Detailed view of the kettle's features including dry-boil protection, LED touch control panel, steam outlet, power port, and safety lock mechanism.

Double Wall Cool Touch Design

304 Stainless steel inside
& plastic outside

Food
Grade



Image: Top-down view of the kettle's interior, highlighting the 304 stainless steel and double-wall cool-touch design.

Portable Convenience Anywhere

Home



Travel



Image: The kettle demonstrating its versatility for boiling water, making porridge, tea, and coffee.

3. Package Contents

Upon unpacking, please ensure all items are present and in good condition:

- AGARO Delite Portable Electric Kettle
- Power Adapter
- USB Charging Cable
- Instruction Manual (this document)

Video: A brief overview of the kettle and its accessories, including the power adapter and charging cable.

Note: This is a short preview video.

4. Safety Information

To prevent injury or damage, always follow these basic safety precautions:

- Do not immerse the kettle, power cord, or plug in water or other liquids.

- Ensure the kettle is placed on a stable, flat, heat-resistant surface away from edges.
- Do not operate the kettle without water to prevent dry-boil damage.
- Do not overfill the kettle beyond the maximum fill line to avoid boiling water overflow.
- Keep the kettle out of reach of children and pets.
- Always ensure the lid is securely closed and locked before operating. The kettle features a lid-lock safety mechanism and operates only when the lid is in the locked position.
- Unplug the kettle from the power outlet when not in use and before cleaning.
- Do not touch hot surfaces. Use handles or knobs.
- Do not use the kettle if the power cord or plug is damaged.

5. Setup

Follow these steps to set up your AGARO Delite Portable Electric Kettle:

1. **Unpack:** Carefully remove all components from the packaging.
2. **Clean:** Before first use, clean the interior of the kettle with warm water and a soft cloth. Rinse thoroughly.
3. **Connect Power:** Plug the USB charging cable into the kettle's power port and connect the adapter to a suitable power outlet.
4. **Open Lid:** Twist the lid counter-clockwise to unlock and open.
5. **Add Water:** Fill the kettle with water, ensuring it is between the minimum and maximum fill lines. Do not overfill.
6. **Close Lid:** Place the lid back on the kettle and twist clockwise to close and lock it securely.

How to Use



Twist to open the lid



Add water



Twist to close the lid



Twist the top to lock and start heating

Note: The kettle features a lid-lock safety mechanism and operates only when the lid is in the locked position.

Image: A visual guide demonstrating how to open the lid, add water, close the lid, and lock it for heating.

Video: Demonstrates plugging in the kettle, powering it on, and the initial setup process.

6. Operating Instructions

Once the kettle is set up and filled with water, you can begin operation:

1. **Power On:** Press the power button on the control panel to turn on the kettle. The display will illuminate.
2. **Select Function:** Use the touch controls to select your desired function:
 - **Boil Water:** Heats water to 100°C.
 - **Adjust Temperature:** Select a specific temperature between 45°C and 95°C.
 - **Keep Warm:** Maintains the selected temperature.
 - **Dechlorination:** Boils water and continues for an additional 3 minutes to reduce chlorine.
 - **Porridge:** Specialized heating cycle for porridge.
3. **Start Heating:** Press the 'Start' button to begin the selected function. The display will show the current temperature.

- 4. **Cancel:** To stop the heating process at any time, press the 'Cancel' button.
- 5. **Serving:** Once the desired temperature is reached or the function is complete, carefully unlock and open the lid to pour. Be cautious of hot steam.

7. Maintenance

Regular cleaning and maintenance will prolong the life of your kettle:

- **Cleaning:** Always unplug the kettle and allow it to cool completely before cleaning. Wipe the exterior with a damp cloth. The interior can be hand washed with warm, soapy water and a soft sponge. Rinse thoroughly.
- **Descaling:** Over time, mineral deposits (limescale) may build up inside the kettle, especially in hard water areas. To descale, fill the kettle with a mixture of equal parts water and white vinegar. Boil the mixture and let it stand for 30 minutes to an hour. Empty the kettle and rinse several times with fresh water. Repeat if necessary.
- **Storage:** When not in use, ensure the kettle is clean and dry. Store it in a cool, dry place.

8. Troubleshooting

If you encounter issues with your kettle, refer to the following common problems and solutions:

- **Kettle does not turn on:**
 - Ensure the power cable is securely plugged into both the kettle and the wall outlet.
 - Check if the power outlet is functioning correctly by testing it with another appliance.
- **Kettle does not heat water:**
 - Verify that the lid is properly closed and locked. The safety mechanism prevents heating if the lid is not secured.
 - Ensure there is sufficient water in the kettle (above the minimum fill line).
 - Confirm that a function has been selected and the 'Start' button has been pressed.
- **Water tastes unusual or has white flakes:**
 - This is likely due to mineral deposits (limescale). Refer to the 'Descaling' section under Maintenance.
- **Water overflows during boiling:**
 - You may have overfilled the kettle. Do not fill above the maximum fill line.

If the problem persists after attempting these solutions, please contact customer support.

9. Specifications

Feature	Specification
Brand	AGARO
Model Name	Delite

Capacity	500 Milliliters
Material	Polypropylene (PP), Stainless Steel
Special Feature	Temperature Control
Product Dimensions	3.66"L x 3.54"W x 8.46"H
Item Weight	1.54 pounds (700 Grams)
Included Components	Main Unit
Product Care Instructions	Hand Wash, Wipe clean with cloth

10. Warranty and Support

For warranty information or technical support, please refer to the warranty card included with your product or visit the official AGARO website. If you have any questions or require assistance, please contact AGARO customer service.