

[Manuals.plus](#) /

› [AGARO](#) /

› AGARO Elite Soup Maker User Manual

AGARO 33998

AGARO Elite Soup Maker User Manual

Model: 33998

INTRODUCTION

Thank you for choosing the AGARO Elite Soup Maker. This appliance is designed to simplify your cooking process, allowing you to create delicious and nutritious soups, purees, and other beverages with ease. Please read this manual thoroughly before first use to ensure safe operation and optimal performance. Keep this manual for future reference.

IMPORTANT SAFETY INSTRUCTIONS

When using electrical appliances, basic safety precautions should always be followed, including the following:

- Read all instructions before using the appliance.
- Do not touch hot surfaces. Use handles or knobs.
- To protect against electrical shock, do not immerse cord, plugs, or the main unit (motor base) in water or other liquid.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug or after the appliance malfunctions or has been damaged in any manner. Contact customer support for examination, repair, or adjustment.
- The use of accessory attachments not recommended by the appliance manufacturer may cause injuries.
- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Extreme caution must be used when moving an appliance containing hot oil or other hot liquids.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to "off", then remove plug from wall outlet.
- Do not use appliance for other than intended use.

- The appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- **Caution:** The heating element surface is subject to residual heat after use.

PRODUCT OVERVIEW

The AGARO Elite Soup Maker combines blending and heating functions in one compact unit, featuring a durable stainless steel jug and powerful motor.



Figure 1: AGARO Elite Soup Maker. This image shows the complete soup maker unit, highlighting its sleek design and integrated handle.

Components:

- **Main Unit:** Contains the motor, heating element, and control panel.

- **Stainless Steel Jug:** 1-litre capacity with MAX/MIN fill lines.
- **Lid with Integrated Blade:** The lid securely fits onto the jug and houses the blending blade.
- **Control Panel:** Features buttons for various preset functions and Start/Stop.

Simple & convenient



900W
Powerful motor



Stainless
steel blade



Quick
heating



Automatic
operation



Figure 2: Disassembled view of the AGARO Elite Soup Maker, showing the 900W powerful motor, stainless steel blade, and the jug. This illustrates the simple and convenient design for easy assembly and cleaning.

SETUP

1. **Unpacking:** Carefully remove all packaging materials and dispose of them responsibly.
2. **Initial Cleaning:** Before first use, clean the jug and lid with warm soapy water. Wipe the main unit with a damp cloth. Ensure all parts are completely dry before assembly. Refer to the "Care and Maintenance" section for detailed cleaning instructions.
3. **Placement:** Place the soup maker on a stable, flat, heat-resistant surface, away from the edge of the counter and out of reach of children. Ensure there is adequate ventilation around the appliance.

4. **Assembly:** Place the stainless steel jug onto the main unit. Ensure it is seated correctly. Then, securely place the lid with the integrated blade onto the jug.
5. **Power Connection:** Plug the power cord into a grounded electrical outlet.

OPERATING INSTRUCTIONS

Basic Operation:

The AGARO Elite Soup Maker features one-touch operation for convenience.

1. **Add Ingredients:** Place your desired ingredients into the stainless steel jug. Ensure the liquid level is between the MIN and MAX marks indicated inside the jug. Do not overfill.
2. **Secure Lid:** Place the lid firmly onto the jug, ensuring it is properly aligned and locked into place.
3. **Select Function:** Press the "MODE" button on the control panel to cycle through the available preset cooking functions until your desired function is selected.
4. **Start Cooking:** Press the "START/STOP" button to begin the selected program. The appliance will automatically blend and heat according to the program.
5. **Completion:** Once the program is complete, the soup maker will typically beep and stop. Carefully unplug the appliance.
6. **Serve:** Carefully remove the lid and pour the contents into a serving bowl. Be cautious as the contents will be hot.

Preset Cooking Functions:

The AGARO Elite Soup Maker offers 6 preset functions to cater to various culinary needs:

- **Smooth:** For creamy soups, purees, and smooth sauces. This setting blends and heats to a fine consistency.
- **Chunky:** Ideal for hearty soups with visible pieces of vegetables or meat. This setting heats and blends minimally to maintain texture.
- **Compote:** Specifically designed for making fruit compotes or fruit sauces.
- **Jam:** For preparing homemade jams with fruit and sugar.
- **Reheat:** To warm up pre-cooked soups or other liquids without further blending.
- **Blend:** A blending-only function for cold preparations like smoothies, milkshakes, or for achieving a desired consistency after cooking.

6 Preset cooking functions




Figure 3: Control panel displaying the 6 preset cooking functions: Smooth, Chunky, Compote, Jam, Reheat, and Blend. This image helps users identify the various program options available on the soup maker.

Making Soup (Example using "Smooth" function):

1. Prepare your ingredients (e.g., chop vegetables, add broth).
2. Add all ingredients to the soup maker jug. Ensure the total volume is between the MIN and MAX fill lines (1L capacity).
3. Secure the lid.
4. Plug in the appliance.
5. Press "MODE" until "Smooth" is selected.
6. Press "START/STOP". The soup maker will automatically blend and heat the ingredients. Fresh soup can be made within 25 minutes.
7. Once complete, unplug and carefully serve.

Automatic blending & heating

Make fresh soup within
25 minutes
whenever you want



Figure 4: Illustration of the automatic blending and heating process within the AGARO Elite Soup Maker. High-speed extraction blades and heating elements work together to prepare fresh soup efficiently.

Meal for 2 or
appetizers for 3
1L capacity



Figure 5: The AGARO Elite Soup Maker with a bowl of soup, demonstrating its 1-litre capacity, suitable for meals for 2 or appetizers for 3.

CARE AND MAINTENANCE

Proper care and maintenance will extend the life of your AGARO Elite Soup Maker.

Cleaning:

1. **Unplug and Cool:** Always unplug the soup maker from the power outlet and allow it to cool completely before cleaning.
2. **Jug and Lid:**
 - Carefully remove the lid.
 - Wash the inside of the stainless steel jug and the lid (including the blade assembly) with warm, soapy water using a non-abrasive sponge or brush.
 - Rinse thoroughly under running water.

- **Caution:** The main unit (motor base) is NOT waterproof. Do not immerse it in water or any other liquid.

3. **Main Unit:** Wipe the exterior of the main unit with a damp cloth. For stubborn stains, use a mild detergent on the cloth, then wipe with a clean damp cloth. Dry thoroughly.
4. **Drying:** Ensure all parts are completely dry before reassembling or storing the appliance.

Storage:

Store the soup maker in a clean, dry place when not in use. Ensure the power cord is neatly wrapped and not kinked.

TROUBLESHOOTING

If you encounter any issues with your AGARO Elite Soup Maker, please refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet not working; lid not properly secured.	Ensure the power cord is securely plugged into a working outlet. Check if the lid is correctly placed and locked.
Blending is weak or inconsistent.	Too many ingredients; ingredients too large; insufficient liquid.	Do not overfill the jug. Cut ingredients into smaller pieces. Ensure sufficient liquid is added (between MIN/MAX lines).
Soup is not hot enough.	Incorrect program selected; program interrupted.	Ensure a heating program (e.g., Smooth, Chunky) was selected. Do not open the lid during operation. Use the "Reheat" function if needed.
Appliance stops mid-cycle.	Overheating protection activated; power interruption.	Unplug the appliance and let it cool down for at least 30 minutes. Check power supply. If problem persists, contact customer support.
Difficulty cleaning the jug.	Food residue dried on.	Clean the jug immediately after use. For stubborn residue, soak with warm soapy water for a few minutes before scrubbing.

TECHNICAL SPECIFICATIONS

Feature	Specification
Brand	AGARO
Model Name	Elite
Item Model Number	33998
Bowl Capacity	1 Litre
Power Source	Corded Electric
Motor Power	900 Watts (Copper Motor)

Feature	Specification
Blade Material	Stainless Steel
Special Feature	Built-in Grinder
Product Dimensions	20.5D x 20.5W x 26H Centimeters
Colour	Grey
Item Weight	1 kg 740 g
Country of Origin	China

WARRANTY AND CUSTOMER SUPPORT

The AGARO Elite Soup Maker comes with a**2-year warranty**, as indicated on product packaging and promotional materials. For warranty claims, technical assistance, or any product-related inquiries, please contact AGARO customer support.

Please retain your purchase receipt as proof of purchase for warranty purposes.

For the most up-to-date contact information, please visit the official AGARO website or refer to the contact details provided with your product packaging.