

[Manuals.plus](#) /

› [IFB](#) /

› IFB 30 L Convection Microwave Oven 30BRC2 User Manual

IFB 30BRC2

IFB 30 L Convection Microwave Oven 30BRC2 User Manual

Model: 30BRC2

1. PRODUCT OVERVIEW

The IFB 30 L Convection Microwave Oven 30BRC2 is a versatile kitchen appliance designed for baking, grilling, reheating, defrosting, and cooking. It features a 30-liter capacity, suitable for large families, and offers a range of cooking modes and safety features.



Image 1.1: Front view of the IFB 30 L Convection Microwave Oven 30BRC2, showcasing its control panel and key features like Rotisserie and Dual Heater Technology.

2. SAFETY INSTRUCTIONS

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, or injury.

- Read all instructions before using the appliance.
- Ensure the appliance is properly grounded.
- Do not operate the oven if the door or door seals are damaged.
- Do not heat liquids or other foods in sealed containers as they are liable to explode.
- Only allow children to use the oven without supervision when adequate instructions have been given so that the child is able to use the oven in a safe way and understands the hazards of improper use.
- Use only utensils suitable for microwave ovens.
- Clean the oven regularly and remove any food deposits.

2.1 Child Safety Lock

The Child Safety Lock feature prevents unintended operation, ensuring safety, especially in homes with young children.



Image 2.1: A child interacting with the microwave oven, illustrating the Child Safety Lock feature which prevents unintended starts.

Activation: Refer to your control panel for specific button combinations, typically a long press on a 'Stop/Reset' or 'Lock' button.

Deactivation: Repeat the activation steps to unlock the control panel.

2.2 Overheating Protection

This microwave oven is equipped with an overheating protection system that automatically shuts off the appliance to prevent damage in case of excessive temperature rise.

Overheating Protection

Safety shut-off prevents damage



Image 2.2: Visual representation of the overheating protection shield inside the microwave cavity, indicating a safety shut-off mechanism.

3. SETUP AND INSTALLATION

3.1 Unpacking

Carefully remove the microwave oven and all packing materials from the carton. Check for any damage. The package includes: 1 Microwave Oven, Warranty Card, User Manual, and a Starter Kit.

3.2 Placement

Place the oven on a flat, stable surface that can support its weight. Ensure adequate ventilation by leaving at least 10 cm of space at the back, 20 cm at the top, and 5 cm on the sides. Do not block any ventilation openings.



Net Dimension (H x W x D)
30 cm x 53.9 cm x 44 cm | 0ft 9in x 1ft 7in x 1ft 4in

Image 3.1: Diagram showing the net dimensions of the IFB 30 L Convection Microwave Oven 30BRC2: 30 cm (H) x 53.9 cm (W) x 44 cm (D).

3.3 Electrical Connection

Plug the oven into a dedicated 230 Volts, 50 Hz, AC outlet. Do not use extension cords or adapters.

4. OPERATING INSTRUCTIONS

The IFB 30BRC2 offers various cooking modes to suit your needs. The touch keypad (membrane) is sensitive to touch and easy to clean.

4.1 Basic Microwave Cooking

Use this mode for reheating, cooking, and defrosting. Place food in a microwave-safe container. Set the desired cooking time and power level using the control panel.

4.2 Convection Cooking

Ideal for baking and roasting. This mode uses a fan to circulate hot air, ensuring even cooking. The convection

temperature can be set from 40°C to 200°C.

IFB

Perfect *Grill & Roasts*




Image 4.1: Interior view of the microwave oven during convection cooking, showing a roasted item and the heating elements.

4.3 Grill Mode

Use for grilling items like paneer, vegetables, or chicken. Place food on the grill rack provided. This mode provides direct heat for browning and crisping.

4.4 Rotisserie Function

The 360° motorized rotisserie ensures even roasting of poultry or other meats. This feature is perfect for achieving uniformly cooked and browned results.

All-Round Roast

No Missed Spots




Image 4.2: A chicken roasting on the motorized rotisserie inside the microwave oven, illustrating even heat distribution.

4.5 Combination Cooking Modes

Combine microwave, grill, and convection functions for faster cooking and varied results. Refer to the user manual for specific combination settings and recipes.

4.6 Auto Cook Menus

The oven features 101 auto cook menus for various dishes. Select the desired menu, enter the weight (if prompted), and the oven will automatically set the cooking time and power level.

Your Instant *Recipe Library*

Auto Cook Options



Image 4.3: The microwave oven surrounded by various cooked dishes, representing the convenience of the auto cook menus.

4.7 Defrost Function

Use the weight defrost function to thaw frozen food. Enter the weight of the food, and the oven will calculate the appropriate defrosting time.

Auto Defrost

Automatically thaws food
by weight/type



Image 4.4: Illustration of the Auto Defrost function, showing frozen chicken thawing into a ready-to-cook state.

4.8 Preheat Function

The preheat function allows the oven to reach a desired temperature before cooking, essential for baking and convection modes.

Convenient *Auto Pre-heat*



Image 4.5: The microwave oven on a kitchen counter with a pizza in the foreground, highlighting the convenient auto pre-heat function.

4.9 Other Functions

- **Auto Reheat:** Reheats food to an optimal temperature.
- **Delay Start:** Program the oven to start cooking at a later time.
- **Keep Warm:** Maintains food at a warm temperature after cooking.
- **Express Cooking:** Starts cooking immediately at full power for a short duration.
- **Power Saving:** Reduces energy consumption during standby mode.

Power Saving

Reduces energy consumption in standby



Image 4.6: The microwave oven displaying a green leaf icon, symbolizing its power-saving capability that reduces energy consumption in standby.

5. MAINTENANCE AND CLEANING

Regular cleaning and maintenance ensure the longevity and efficient operation of your microwave oven.

5.1 Steam Clean

This feature helps loosen food residues inside the cavity, making cleaning effortless.

5.2 Disinfect


The disinfect function helps eliminate harmful microwave bacteria, promoting a hygienic cooking environment.

5.3 Deodorize

Use the deodorize function to remove lingering food odors from the oven cavity.

Steam Clean

Effortless interior cleaning



Disinfect

Eliminates harmful microwave bacteria

Deodorize

Removes lingering food odors



Image 5.1: Visual representation of Steam Clean for effortless interior cleaning, Disinfect to eliminate bacteria, and Deodorize to remove food odors.

5.4 Cleaning the Cavity

The oven features an anti-rust stainless steel cavity. Wipe the interior with a damp cloth and mild detergent after each use. Do not use abrasive cleaners or scouring pads.

6. TROUBLESHOOTING

If you encounter issues with your microwave oven, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Oven does not start	Power cord unplugged, door not closed properly, fuse blown, child lock activated.	Check power connection, ensure door is latched, check household fuse, deactivate child lock.
Food not heating	Incorrect cooking time/power level, unsuitable cookware.	Adjust settings, use microwave-safe dishes.

Problem	Possible Cause	Solution
Light not working	Bulb needs replacement.	Contact customer service for bulb replacement.
Unusual noises	Turntable not correctly placed, foreign object inside.	Re-position turntable, remove any obstructions.
Touch panel unresponsive	Child lock activated, temporary electronic glitch.	Deactivate child lock. Unplug the oven for a few minutes and plug it back in.

If the problem persists after attempting these solutions, please contact IFB customer service.

7. SPECIFICATIONS

Feature	Detail
Brand	IFB
Model	30BRC2
Capacity	30 litres
Oven Cooking Mode	Convection
Wattage (Microwave)	800 Watts
Annual Energy Consumption	1400 Watts
Voltage	230 Volts
Colour	Black
Material	Alloy Steel, Stainless Steel Cavity
Item Dimensions (LxWxH)	44 x 53.9 x 30 Centimeters
Item Weight	9 kg 100 g
Special Features	101 Standard Menus, Various Cooking Mode, Convection Temperature (40~200 °C), Preheat, Keep Warm, Auto Programs, Sound on/off, Ceramic, Auto reheat, Digital Clock, Express cook/Quick start, Intelligent system cooling, Temperature Setting, Timer
Included Components	1 Microwave Oven, Warranty Card, User Manual and Starter Kit

8. WARRANTY AND SUPPORT

8.1 Warranty Information

The IFB 30BRC2 Convection Microwave Oven comes with a comprehensive warranty:

- **1 Year Warranty** on the entire microwave oven.
- **3 Years Warranty** on the Magnetron & Cavity.

Please retain your purchase receipt and warranty card for any warranty claims.

8.2 Customer Support

For any service, support, or queries, please contact IFB customer care. IFB provides doorstep service and support.

A promotional graphic for IFB CARE. The top left features the 'IFB CARE' logo in white on a dark background. The top right features the 'IFB' logo. The main headline reads 'Best in class Service and Support at your DOORSTEP' in yellow and white. Below this, three service points are listed with yellow icons: a headset for '24x7 help on call or AI chat', a location pin for 'On-site repairs', and crossed wrench and screwdriver for '6100+ service experts'. To the left of a large yellow hard hat (which has 'IFB CARE' on it) are the statistics '1250+ Service Centers' and '19000+ Pin-codes'. The bottom of the graphic contains three contact methods: a WhatsApp icon with the number '9231004321', a telephone icon with the number '08045845678', and an email icon with the address 'customerservice@ifbglobal.com'.

IFB CARE

IFB

Best in class Service and Support
at your DOORSTEP

 **24x7 help on call or AI chat**

 **On-site repairs**

 **6100+ service experts**

1250+
Service Centers

19000+
Pin-codes

 **9231004321**

 **08045845678**

 **customerservice@ifbglobal.com**

Image 8.1: Information on IFB CARE, highlighting 24x7 help, on-site repairs, and a wide network of service experts and centers.

You can reach IFB customer service through:

- **Phone:** 0832-3044800/01
- **Email:** Customerservice@ifbglobal.com

