

[Manuals.plus](#) /

› [Elica](#) /

› Elica Vetro Glass Top 3 Burner Gas Stove (703 CT VETRO BLK) User Manual

Elica 703 CT VETRO

Elica Vetro Glass Top 3 Burner Gas Stove (703 CT VETRO BLK) User Manual

Model: 703 CT VETRO

INTRODUCTION

Thank you for choosing the Elica Vetro Glass Top 3 Burner Gas Stove. This manual provides essential information for the safe and efficient use, installation, maintenance, and troubleshooting of your new gas stove. Please read these instructions carefully before operating the appliance and keep them for future reference.



Image: Front view of the Elica Vetro Glass Top 3 Burner Gas Stove.

IMPORTANT SAFETY INFORMATION

Always follow basic safety precautions when using any gas appliance to reduce the risk of fire, electric shock, or injury. This appliance is designed for domestic use only.

General Safety Guidelines:

- Ensure proper ventilation in the kitchen area.
- Do not store flammable materials near the gas stove.
- Keep children and pets away from the appliance during operation.
- Do not leave cooking unattended.
- In case of a gas leak, immediately turn off the gas supply, open windows, and do not operate any electrical switches or appliances. Contact your gas supplier.

5 Tips for Safe Use of Your Glass-Top Gas Stove:

5 TIPS TO SAFELY USE YOUR GLASS-TOP GAS STOVE



Image: Infographic detailing safety tips for glass-top gas stoves.

1. **Do not put hot vessels directly on the glass surface:** Allow the glass top to cool before placing anything on it after cooking.
2. **Do not use abrasive cleaning pads:** Use a soft cloth to wipe the glass surface to prevent scratches.
3. **Avoid using oversized pans:** Use correct pan support trivets and ensure pans do not extend excessively beyond the burner, potentially touching the glass.
4. **Do not put water or wet cloth on the hot glass surface immediately after cooking:** Wait for it to cool down to prevent thermal shock.
5. **Do not use Tandoor Cooker/Baati:** These items may cover the burner trivet entirely and touch the glass, causing damage.

PRODUCT COMPONENTS

Your Elica Vetro Gas Stove is designed with quality components for efficient cooking.

- **Toughened Glass Top:** Enhances aesthetics and ensures durability and safety.
- **Heavy Brass Burners:** Equipped with 3 distinct sized burners (1 Small & 2 Medium) for varied cooking needs, providing consistent flames.
- **Euro Coated Grid Supports:** Help keep pans and pots stable and prevent chipping.
- **High Quality Knobs:** Smoothly operated for flame control.
- **Stainless Steel Support Plate:** Located below the glass, it maintains sturdiness and durability.



EURO COATED GRID

Designed with popular & durable Euro Coated Grid to ensure genuine & rigid performance. The Euro-coated grid supports also prevent the pan from chipping off while providing astonishing care while you cook.



Image: Illustration of the heavy brass burners, indicating one small and two medium burners.



STAINLESS STEEL SUPPORT PLATE

To offer unmatched durability & reliability, the Elica 703 CT VETRO BLK Gas Stove comes with Stainless Steel Support Plates. The plates are perfectly designed to enhance their sturdiness.



Image: Illustration of the Euro coated grid supports.



Image: Close-up view of the high-quality control knobs.

SETUP AND INSTALLATION

Proper installation is crucial for the safe and efficient operation of your gas stove. It is highly recommended to seek professional assistance for installation.

Installation Steps:

1. **Unpacking:** Carefully remove the gas stove from its packaging. Inspect for any damage during transit.
2. **Placement:** Place the stove on a stable, level, and heat-resistant surface. Ensure adequate clearance from walls and other appliances.
3. **Gas Connection:** Connect the gas stove to your LPG cylinder or piped gas supply using a certified gas hose and regulator. Ensure all connections are tight and leak-free. **It is strongly recommended to have this step performed by a qualified technician.**
4. **Leak Test:** After connection, perform a leak test using soapy water on all joints. Bubbles indicate a leak. Do not use an open flame for leak detection.

5. **Burner Assembly:** Place the burner caps and pan supports correctly on each burner.

For detailed installation instructions, please refer to the official [Installation Manual \(PDF\)](#) provided by Elica. Professional installation may incur additional charges (e.g., approximately ₹230 for LPG connection). The product warranty remains valid even if self-installed, provided installation guidelines are followed correctly.

OPERATING INSTRUCTIONS

Follow these steps to safely operate your Elica gas stove.

Lighting a Burner:

1. Ensure the gas supply is open.
2. Place your cooking vessel on the pan support above the desired burner.
3. Push down and turn the corresponding control knob counter-clockwise to the 'Ignite' position. You will hear a clicking sound as the auto-ignition sparks.
4. Once the flame ignites, release the knob. If the flame does not ignite within a few seconds, turn the knob back to the 'OFF' position, wait for a few moments, and try again.
5. Adjust the flame intensity by turning the knob between the 'High' and 'Low' settings.

Turning Off a Burner:

To turn off a burner, simply turn the control knob clockwise to the 'OFF' position until you feel a click and the gas supply is cut off.

MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure the longevity and optimal performance of your gas stove.

Cleaning the Glass Top:

- Always ensure the glass top is completely cool before cleaning.
- Use a soft cloth or sponge with mild detergent and warm water.
- Avoid abrasive cleaners, scouring pads, or harsh chemicals as they can scratch or damage the glass surface.
- Wipe dry with a clean, soft cloth to prevent water spots.

Cleaning Burners and Pan Supports:

- Remove the pan supports and burner components (burner caps and bases) when cool.
- Wash them with warm soapy water. For stubborn stains, a non-abrasive scrubber can be used.
- Ensure all parts are completely dry before reassembling them. Moisture can affect ignition.
- Periodically check burner holes for blockages and clean them gently with a thin wire if necessary.

TROUBLESHOOTING

Before contacting customer service, please refer to the following common issues and their solutions.

Problem	Possible Cause	Solution
Burner does not ignite	No gas supply; Burner components wet or clogged; Ignition electrode dirty or faulty.	Check gas cylinder/supply; Ensure burner parts are dry and clean; Clean ignition electrode.
Uneven flame	Burner holes clogged; Burner cap not seated correctly.	Clean burner holes; Re-seat burner cap properly.
Gas smell	Gas leak.	Immediately turn off gas supply, ventilate area, do not operate electrical switches, contact gas supplier or service.

SPECIFICATIONS

Detailed technical specifications for the Elica Vetro Glass Top 3 Burner Gas Stove.

Feature	Detail
Model Number	703 CT VETRO
Colour	Black
Material	Brass (Burners), Toughened Glass (Top)
Number of Burners	3 (1 Small, 2 Medium)
Controls Type	Knob
Power Source Type	Gas Powered
Item Dimensions (D x W x H)	41D x 70W x 13H Centimeters
Item Weight	8.1 Kilograms
Included Components	Burner
Country of Origin	India



Image: Product dimensions illustration (70 cm Width, 41 cm Depth, 13 cm Height).

WARRANTY INFORMATION

Your Elica Vetro Glass Top 3 Burner Gas Stove comes with a comprehensive warranty.

- **Warranty Period:** Two (2) Years from the Date of Purchase.
- **Covered Components:** Glass, Burner, Mixing Tubes, Micro Switch, Spark Plug, Generator, Valves.
- The warranty remains valid and unaffected even if the product is self-installed, provided installation is done correctly according to the manual.

CUSTOMER SUPPORT

For any further assistance, queries, or service requests, please contact Elica Customer Care.



Customer Care

for more queries, please call us on

18002330007
7447440983/4/5

Additional installation charges upto ₹236/-

The warranty will remain valid and unaffected if it's self-installed.

Image: Elica Customer Care contact details.

- **Toll-Free Customer Care:** 1800 233 0007
- **Additional Contact Numbers:** 7447440983 / 7447440984 / 7447440985
- **Email:** info@elica.in
- **Manufacturer Contact Information:** Elica Pb India Pvt Ltd, 37/1/1, Kondhwa Pisoli Road, Pisoli, Pune, Maharashtra 411060, India.