

Elica 662 CT VETRO BLK

Elica Vetro Glass Top 2 Burner Gas Stove (Model 662 CT VETRO BLK) - Instruction Manual

1. INTRODUCTION

This manual provides essential information for the safe and efficient use of your **Elica Vetro Glass Top 2 Burner Gas Stove**, Model 662 CT VETRO BLK. Please read these instructions carefully before installation and operation, and retain them for future reference. This appliance is designed for domestic cooking purposes only.

2. SAFETY INFORMATION

Your safety and the safety of others are paramount. Please observe all safety precautions.

- Read all instructions thoroughly before using the appliance.
- Ensure adequate ventilation in the kitchen area during operation.
- Use only the specified type of gas (LPG/PNG) for this appliance.
- **Professional installation** by a qualified technician is highly recommended to ensure correct and safe setup.
- Keep flammable materials, such as curtains, paper, and aerosols, away from the gas stove.
- Never leave cooking unattended.
- Keep children and pets away from the appliance during operation.
- Regularly check for gas leaks using soapy water (never an open flame).
- Do not modify the appliance. Any unauthorized modifications may void the warranty and pose safety risks.

3. PACKAGE CONTENTS

Upon unpacking, please verify that all components are present and undamaged:

- 1 x Elica Vetro Glass Top 2 Burner Gas Stove Unit

- 2 x Brass Burners (1 large, 1 small)
- 2 x Euro-Coated Pan Supports
- 2 x Control Knobs
- 1 x Instruction Manual



Image 1: Elica Vetrolux Glass Top 2 Burner Gas Stove (Model 662 CT VETRO BLK)

4. SETUP AND INSTALLATION

Proper installation is crucial for the safe and efficient operation of your gas stove. It is strongly recommended to have the appliance installed by a certified professional.

4.1 Placement

- Place the gas stove on a stable, level, and non-combustible surface.
- Ensure there is adequate clearance from walls and overhead cabinets as per local safety regulations.

4.2 Gas Connection

- Connect the gas stove to your LPG cylinder or PNG supply using a certified gas hose and regulator.
- Ensure all connections are tight and secure.

4.3 Leak Test

After connecting the gas supply, perform a leak test:

1. Mix liquid soap with water to create a thick solution.
2. Apply the solution to all gas connections.
3. Open the gas supply. If bubbles appear, there is a leak. Immediately close the gas supply and tighten the connections. Repeat the test until no bubbles are observed.
4. **Never use an open flame to check for gas leaks.**

4.4 Ventilation

Ensure the kitchen area has proper ventilation, such as an exhaust fan or open windows, to dissipate combustion gases.

5. OPERATING INSTRUCTIONS

This gas stove features manual ignition. Follow these steps for safe operation:

OUTLINED WITH **PREMIUM FINISH GLASS TOP**

it provides a rust resistance texture while delivering long lasting performance.



Image 2: Burners and Control Knobs

5.1 Before Use

- Ensure the gas supply valve is open.
- Place your cooking vessel centrally on the pan support over the desired burner.

5.2 Manual Ignition

1. Push and turn the control knob for the desired burner to the 'ON' position.
2. Immediately bring a lit matchstick or a gas lighter close to the burner.
3. Once the burner ignites, release the knob.

5.3 Flame Adjustment

- Rotate the control knob to adjust the flame intensity. Turn towards 'HIGH' for a stronger flame and towards 'LOW' for a gentler flame.
- Ensure the flame is stable and blue. A yellow or flickering flame may indicate improper combustion or a clogged burner.

5.4 Turning Off

- Turn the control knob fully to the 'OFF' position.
- For extended periods of non-use, it is advisable to close the main gas supply valve.

6. MAINTENANCE AND CLEANING

Regular cleaning and maintenance will ensure the longevity and optimal performance of your gas stove. Always ensure the stove is cool before cleaning.

6.1 Glass Top

- Wipe the toughened glass top with a soft, damp cloth and mild detergent after each use.
- For stubborn stains, use a non-abrasive glass cleaner. Avoid harsh chemicals, abrasive pads, or metallic scrubbers that can scratch the glass.

6.2 Brass Burners

- Periodically remove the brass burners and burner caps.
- Wash them with warm, soapy water and a soft brush to remove food debris and blockages.
- Rinse thoroughly and ensure they are completely dry before placing them back on the stove. Ensure the burner holes are clear.

6.3 Pan Supports

- Remove the Euro-coated pan supports and wash them with warm, soapy water.
- Dry them completely before returning them to their positions.

6.4 General Cleaning

- Wipe the stainless steel body with a damp cloth.
- Do not immerse the entire stove in water.

7. TROUBLESHOOTING

Before contacting customer service, please refer to the following troubleshooting guide for common issues:

Problem	Possible Cause	Solution
Burner not lighting	Gas supply off Burner cap/crown misplaced Clogged burner holes Faulty gas lighter	Open gas supply valve Ensure burner cap and crown are correctly seated Clean burner holes Replace or repair gas lighter

Problem	Possible Cause	Solution
Low or irregular flame	Low gas pressure/cylinder empty Clogged burner holes Improper burner assembly	Check gas cylinder level or PNG supply Clean burner holes thoroughly Reassemble burner components correctly
Smell of gas	Gas leak	Immediately turn off gas supply. Open windows for ventilation. Do not operate electrical switches or ignite flames. Contact your gas supplier or a professional technician immediately.

8. SPECIFICATIONS

Key technical specifications for the Elica Vetro Glass Top 2 Burner Gas Stove:

- **Model Number:** 662 CT VETRO BLK
- **Brand:** Elica
- **Colour:** Black
- **Material:** Stainless Steel (body), Toughened Glass (top)
- **Heating Elements:** 2 (1 large, 1 small brass burner)
- **Controls Type:** Knob
- **Power Source Type:** Gas powered
- **Item Dimensions (D x W x H):** 37D x 66W x 8H Centimeters
- **Item Weight:** 8 Kilograms
- **Manufacturer:** Elica
- **Country of Origin:** India

9. WARRANTY AND SUPPORT

Your Elica Vetro Glass Top 2 Burner Gas Stove comes with a comprehensive warranty and dedicated customer support.

9.1 Warranty Information

The product is covered by a **2-year comprehensive warranty** from the date of purchase. Please retain your purchase receipt as proof of purchase for warranty claims. The warranty covers manufacturing defects under normal domestic use.

9.2 Customer Support

For any service requests, technical assistance, or warranty claims, please contact Elica customer service. Refer to the official Elica website or your purchase documentation for the most current contact details. Professional service is recommended for any repairs or complex issues.

