

[Manuals.plus](#) /

› [Faber](#) /

› Faber Hob SUPERIA HT764 BR AI 4 Burner Gas Stove Instruction Manual

Faber 106.0700.865

Faber Hob SUPERIA HT764 BR AI 4 Burner Gas Stove Instruction Manual

Model: 106.0700.865

INTRODUCTION

Thank you for choosing the Faber Hob SUPERIA HT764 BR AI 4 Burner Gas Stove. This manual provides essential information for the safe and efficient installation, operation, and maintenance of your new appliance. Please read these instructions carefully before use and retain them for future reference.

IMPORTANT SAFETY INFORMATION

Always follow basic safety precautions when using this appliance to reduce the risk of fire, electric shock, burns, or injury. Keep this manual near the appliance for quick reference.

- Ensure proper ventilation in the kitchen area during operation.
- Do not store flammable materials near the hob.
- Keep children and pets away from the appliance during use.
- Do not use abrasive cleaners or sharp objects for cleaning.
- In case of a gas leak, immediately turn off the gas supply, open windows, and do not operate any electrical switches. Contact a qualified technician.
- Only use the appliance with the type of gas specified on the rating plate.

PRODUCT OVERVIEW

The Faber Hob SUPERIA HT764 BR AI is a 76 cm wide, 4-burner gas hob featuring auto-ignition and a toughened black glass surface. It is designed for both hob and hobtop usage.



Figure 1: Front view of the Faber Hob SUPERIA HT764 BR AI 4 Burner Gas Stove. This image shows the black glass surface, four burners with pan supports, and four control knobs at the front.

Key Components:

- **Toughened Black Glass Surface:** 7mm thick, durable, and easy to clean.
- **Burners:** Four brass burners with black coating.
 - 1 x 3.3 Kw burner
 - 1 x 2 Kw burner
 - 2 x 1.6 Kw burners
- **Pan Supports:** Sturdy supports for cookware.
- **Metal Knobs:** Premium control knobs for flame adjustment.
- **Auto-Ignition:** In-built electric ignition (DC 1.5V operated).
- **Spillage Proof Design:** Flat concealed chamber to prevent spills from entering internal components.




Figure 2: Close-up view of the metallic control knobs. These knobs are used to regulate the gas flow to each burner.




Figure 3: Detail of the auto-ignition mechanism. This component generates a spark to ignite the gas.

SETUP AND INSTALLATION

Installation should only be performed by a qualified technician in accordance with local regulations and safety standards. Incorrect installation can lead to hazards.

Pre-Installation Checks:

- Verify that the gas supply type (LPG/PNG) matches the appliance's specifications.
- Ensure adequate ventilation in the installation area.
- Confirm the countertop cutout dimensions are appropriate for the hob (Product Dimensions: 45D x 76W x 5.6H Centimeters).



Figure 4: Diagram illustrating the dimensions of the Faber Hob, showing a width of 760mm and depth of 450mm.

Installation Steps (for qualified technicians):

1. Carefully unpack the hob and inspect for any damage.
2. Place the hob into the prepared countertop cutout.
3. Connect the gas supply hose to the hob's inlet, ensuring a secure, leak-free connection.
4. Install the battery for the auto-ignition system (DC 1.5V).
5. Perform a leak test on all gas connections using soapy water.
6. Test each burner for proper ignition and flame stability.

OPERATING INSTRUCTIONS

Igniting a Burner:

1. Ensure the gas supply valve is open.
2. Place your cookware on the pan support over the desired burner.
3. Push down and turn the corresponding control knob counter-clockwise to the maximum flame position. The auto-ignition will spark, igniting the gas.
4. Hold the knob down for a few seconds after ignition to allow the flame supervision device (if present) to activate.
5. Adjust the flame to the desired intensity by turning the knob between the maximum and minimum flame settings.

Turning Off a Burner:

- Turn the control knob clockwise until it clicks into the "OFF" position.
- Ensure the flame is completely extinguished.



Figure 5: The Faber Hob with two burners actively lit, demonstrating the flame. This image highlights the brass burner combo with varying power outputs (3.3 kW, 2.0 kW, 1.6 kW).

CARE AND MAINTENANCE

Regular cleaning and maintenance will ensure the longevity and optimal performance of your hob.

Daily Cleaning:

- Allow the hob to cool completely before cleaning.
- Wipe the toughened glass surface with a soft cloth and mild detergent or glass cleaner.
- Remove pan supports and wash them with warm soapy water. Dry thoroughly before replacing.
- Clean the burner caps and rings. Ensure burner ports are not clogged.

Preventing Spillage:



Figure 6: Image showing the fully concealed drip tray designed to prevent spillage from entering the hob's internal components, ensuring easier cleaning and maintenance.

- The hob features a flat concealed chamber to minimize spillage issues.
- Immediately clean any spills to prevent them from hardening or staining the surface.

Battery Replacement for Auto-Ignition:

- If the auto-ignition spark becomes weak or fails, replace the 1.5V DC battery. Refer to the battery compartment location, usually underneath the hob or accessible from the side.

TROUBLESHOOTING

Before contacting customer service, please refer to the following common issues and solutions:

Problem	Possible Cause	Solution
Burner does not ignite.	No gas supply, clogged burner ports, weak battery for auto-ignition, faulty igniter.	Check gas supply. Clean burner ports. Replace auto-ignition battery. Contact service if igniter is faulty.
Flame is uneven or yellow.	Clogged burner ports, incorrect gas pressure.	Clean burner ports. Contact a qualified technician to check gas pressure.
Gas smell detected.	Gas leak.	Immediately turn off gas supply, open windows, do not operate electrical switches. Contact emergency services and a qualified technician.
Knobs get hot during use.	Normal operation, especially near larger burners.	This is generally normal. Ensure proper ventilation.

TECHNICAL SPECIFICATIONS

Feature	Specification
Model Number	106.0700.865
Type	Gas Hob / Hobtop
Burners	4 (1 x 3.3 Kw, 1 x 2 Kw, 2 x 1.6 Kw)
Ignition	In-built Auto Electric (DC 1.5V Operated)
Surface Material	Toughened Black Glass, 7mm
Control Type	Metal Knobs
Product Dimensions (D x W x H)	45D x 76W x 5.6H Centimeters
Item Weight	11.2 Kilograms
Power Source	Gas Powered

WARRANTY AND SUPPORT

Faber provides the following warranty for this product:

- **5 Years Warranty:** On Burner & Glass.
- **1 Year Comprehensive Warranty:** On the entire appliance.

For warranty claims, technical assistance, or service requests, please contact Faber customer support. Refer to the contact information provided with your purchase documentation or visit the official Faber website.

Manufacturer: Franke Faber India Pvt Ltd, 1086/1/2,SANASWADI,TAL - SHIRUR, PUNE - 412208,MAHARASHTRA,INDIA, contact no. 1800-209-3484