


+FORBES® *STELLAR*

USER MANUAL



1. Welcome to the World of Forbes	3
2. Product overview	4
3. Product Features	5
4. Safety Information	6
5. Operating your Forbes Stellar	8
- Getting Ready	
- Assembly and Operation	
6. Maintaining your Forbes Stellar	14
7. Trouble Shooting	15
8. Technical Specifications	16
9. Warranty Terms & condition	17
10. Warranty Card	19
11. Customer care	20


Thank you for purchasing Forbes Stellar Vacuum Cleaner. Forbes has been a pioneer and trendsetter in Cleaning Solutions, and all our expertise and research has gone into the superior design of this high-tech home cleaning system.

Your Forbes Stellar Vacuum Cleaner is built with high-performance features, and we back it with our exclusive one year warranty. Consumers are the centre of our business, so should you ever have a problem, you will receive fast, considerate assistance in quick time.

Forbes mission to build a sustainable relationship with customers continues through quality homecare products like the Stellar Vacuum Cleaner.

Thanks again from all of us.

– **Team Eureka Forbes**



Range of Accessories



Extension Tubes



Spray Jar



Floor-cum Carpet Cleaner



Aromiser



Car Wash Adaptor



Grill Cleaner




All-Surface Cleaner




Precision cum
Computer Cleaner




Flexi-Cleaner



Crevice Nozzle



Hose Pipe



2 in 1 Brush



Coat Cleaner

a. Powerful Suction

Forbes Stellar vacuum cleaner is powered with best in class 1600 Watts motor delivering powerful suction of 23 KPA to tackle dirt, dust and dust mites.

b. Powerful Blower

Ensures maximum and powerful airflow delivery.

c. Range of Accessories

Stellar vacuum cleaner comes with range of accessories for different cleaning needs. It provides solution for efficient and hassle-free cleaning. The accessories provided are easy to use and convenient to store.

d. Sliding Vario Power

Stellar gives its user the full control to adjust the power of the unit as per the cleaning requirement.

e. Auto Cord Winder

To protect the power cord from getting cut or damaged, Stellar vacuum cleaner has an in-built storage space which enables the cord to be stored in the unit itself. With the press of a button you can extend the cord for usage and also pull it back into the unit for secure storage

f. Dust Full Indicator

Dust bag full indicator that notifies you when the dust bag is full and needs to be emptied for further use.

g. Twin Parking Position

The twin parking position of the vacuum cleaner facilitates easy storage.

h. Wheels for Easy Manoeuvrability

Stellar is enabled with top-quality wheels to ensure easy handling and mobility.

i. LED Indicator

Forbes stellar comes with LED indicator indicating cleaning speed for added user convenience.

Before using this product, please read the safety instructions and follow all those regular safety precautions.

- This vacuum cleaner is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Children should be supervised to ensure that they do not play with the appliance.

- If the supply cord is damaged, it must be replaced by the Eureka Forbes service centre only.

- Do not use for absorbing detergent, kerosene, glass, needle, cigarette ash, water, match etc.



- The vacuum cleaner should not be exposed to heat.



- Do not vacuum any moist or liquid substances, Never immerse the appliance in water.



- Unplug the vacuum cleaner from the mains supply socket after use and before every cleaning pull the mains cable, in order to disconnect the vacuum cleaner from the mains.



- Do not put any object into openings. Do not use the vacuum cleaner if the suction opening is blocked. Keep the vacuum cleaner free from dust, hair etc.



- Do not use the vacuum cleaner without dust container or dust filter in place.



- Do not vacuum any flour, cement etc, in order to avoid the overload.



- The vacuum cleaner should only be cleaned with a dry or damp cloth, it should never be immersed in water. Do not use any solvents for cleaning.



Getting Ready

1. Remove the Vacuum Cleaner from the box
2. Remove any packaging from the Vacuum Cleaner


Assembling your Stellar vacuum cleaner

Connect the hose pipe with vacuum cleaner

- Insert flexible hose pipe into the suction end:
Press the knob until it clicks into the position
- Remove the flexible hose pipe:
Unplug the appliance and press the knob at the end of the hose pipe
Remove it from the suction end.




Fit the extension tube to the hose pipe



Fit the floor brush to the extension tube




Operating your Forbes stellar Vacuum Cleaner



- A yellow mark on power cord shows the ideal cable length. Do not extend the cable beyond the red mark.
- To rewind the power cord, press the auto cord winder with one hand and guide the cord with the other hand.



- Press the power switch to switch the appliance on.
- Use the vario power to control the suction power of the vacuum cleaner




- The suction power can be adjusted with the sliding control on the angled pipe too.



- If the suction flow is interrupted or the dust bag is full, the indicator lights up red. Turn off the machine immediately, and clean the inlet filter. Empty the dust bag. Turn the unit on again.

Cleaning Tool



Crevice Nozzle:

- For cleaning corner edge and draws etc. Where is difficult to reach, such as gaps and the keyboard, bookshelf and windows.



Upholstery Cleaner:

- For cleaning bed, sofa, couch etc.




Floor cum carpet brush :

Use of the selector on floor brush :

- Bristles extended for carpets.
- Bristles retracted for hard floors.



If the hose pipe has blockage, Insert it into the suction end and switch the vacuum cleaner on.



All-Surface Cleaner

The All surface cleaner


- This is designed to meet all kind of dry dust cleaning requirements. The most unique feature of this accessory is the flexible blades on one end which adjusts according to the object and helps in easy cleaning. Its other side contains bristles for soft surface cleaning.



Flexi-Cleaner

Flexi Cleaner


- This accessory helps in reaching hard to clean areas by creating different angles to match the cleaning requirements.



Computer Cleaner

Computer cleaner

- It contains soft brush which helps in cleaning of delicate surfaces like computer, keyboard & all electronic equipment's



Grill Cleaner

Grill cleaner


- It is designed for removing stubborn dust in between the grills, sills, window channels and vents.



Spray Jar

Spray Jar

- Spray jar helps to spray liquid chemicals, shampooing, watering plants, spray painting and window glass cleaning. To be used at blower end.



Aromiser

The Aromizer


- It helps to fumigate wardrobes and freshens your home with the help of added perfume/ naphthalene balls. To be used at blower end.



Car Wash Adaptor

Car wash adaptor

- This is a blower accessory when connected with crevice nozzle is used to wash exterior of automobile. To be used at blower end.



Coat Cleaner

Coat cleaner



- Use the coat cleaner to remove lint from expensive suits, coats and jackets. Connect the coat cleaner to the hose pipe at the suction end. Run the brush over the coat and blow away lint and dust.

Blower

- Detach the grill by pulling firmly away from the vacuum cleaner.
Attach the blower adaptor.



- Insert the flexible hose pipe choose crevice to use blower function.




Empty the dust container

- A.** After removing the flexible hose pipe, press the cover lock button and open the dust container.
- B.** Remove the dust filter form the container.
- C.** Replace the dust filter in the container.
- D.** Close the dust container until it is locked in the position.



Change filter

- A.** Replacing the filter
 - Open the dust container and remove the filter. Fix the new filter in the position.
- B.** Replace the outlet filter
 - Detach the grill by pulling firmly away the appliance, remove the outlet filter and replace the new filter. Fix the grill again.



Problem	Possible reason	Active
Motor does not start	<ul style="list-style-type: none"> -Power cord not firmly plugged into outlet -Outlet damaged -vacuum Cleaner not switch on 	<ul style="list-style-type: none"> -Plug unit firmly -Check the outlet -Switch on the appliance.
Suction power is weak	<ul style="list-style-type: none"> -unit clogged -Dust filter needs cleaning -Dust container not in position -Filter blocked 	<ul style="list-style-type: none"> -Remove the blockage -Clean the dust filter -Close the dust container -Clean the filter
The wire cannot be winded completely.	The wire may diverge the wire wheel.	Draw the wire a little then rewind.
The wire cannot be draw out.	The wire may wind disorder	Press the re-winder button and try again.
Vario Power doesn't work	Vacuum Cleaner is defective	Repair the Vacuum Cleaner. (only specialist)
Power cord winds unwanted back	Rewind mechanisms is defective	Repair the Vacuum Cleaner. (only specialist)
The dust container cannot be closed	Dust filter is not in the position	Fix the dust filter and try again

Motor Power (IEC)	1600 Watts
Suction Power*	230 cm of WC (23 KPA)
Dimension (L x B x H) in cm	42.8 x 30.9 x 23
Voltage	220-240 V /50 Hz
Noise Level	≤80dB
Dust Bag	2.5 litres

Forbes Vacuum Cleaner are warranted against manufacturing defects for a period of twelve (12) months from the date of original purchase, subject to the following conditions:

- 1.** The customer will notify the company, in writing, promptly of any defect noticed and give the company or its authorised agent sufficient opportunity to inspect, test and remedy them, for which the customer will deposit the goods, if so required by the company, with company's office /Service centre along with the original invoice, in the city where they are sold.
- 2.** Inspection and test report of the company's office /service centre will be treated as final and binding under the warranty for determining defects, repairs/alterations required or carried out, or certifying working of the goods thereafter.
- 3.** The company or its authorised dealer will be entitled to retain any defective parts replaced under the warranty.
- 4.** The company's liability under the warranty will be limited only to defects which occur under the conditions of normal operation and under proper use. It excludes defects occurring because of abuse, faulty care or maintenance, repairs/alterations to goods or parts by others, use on electrical supply for which the goods are not designed or to damage caused by lighting or other electrical disturbances.
- 5.** Components subject to wear, such as flexible cable, carbon brush and accessories, are not covered by this warranty.
- 6.** The customer will have no claims under this warranty in respect of any personal injury, damage to property or consequential damages, or for utilisation of the goods not in accordance with the user manual.

7. Force Majeure: The Company shall not be liable for the non-performance of its obligations under this terms and conditions where such failure is due to force majeure event i.e. due or attributable to any act of God, orders, restrictions or regulation of Government, Central or State, war working conditions, hostilities, riots, civil commotion, strike, lockout, lockdown, pandemic, labour trouble, explosion, or any other cause or circumstance of whatsoever nature beyond control.
8. In case the product needs up-gradation due to reason not under the control of the company, the customer has to accept up-gradation at the prevailing rate.
9. The Company reserves the absolute right to amend/extend/cancel/discontinue the terms and conditions or any part thereof without giving any reasons or prior notice to the customer.
10. All the terms and conditions other than the above criteria on products of the company will have the same effect.
11. Any disputes are subject to Mumbai Court Jurisdiction only.

NOTE: The undernoted expressions should have the following meaning::

- "The goods" shall mean goods described in the invoice.
- "The Customer" shall mean the original purchaser as per the invoice.
- "The company" shall mean "EUREKA FORBES LIMITED".

Post Warranty

The customer has the option of calling our Service Centre and having his Forbes Vacuum Cleaner serviced on an actuals basis i.e. by paying for labour cost and spares needed to attend to that Service/Complaint call at the prevailing company rates. Such services will be rendered by the company in towns/places where the company has its Service Centres.

10. WARRANTY CARD



WARRANTY CARD

1 YEAR
WARRANTY

To be retained by customer:

No.:

Unit / Serial No. (M/C): _____

Customer's Name and Address: _____

Phone (Residence): _____ (Office): _____

Invoice No.: _____

Date of Purchase: _____

Dealer's Stamp & Signature



WARRANTY CARD

1 YEAR
WARRANTY

JUST FILL IN THE WARRANTY CARD AND MAIL IT TO US WITHIN 7 DAYS FROM THE DATE OF PURCHASE.

Date of Purchase : _____

(Please help us to understand you better. Just fill in the details or tick the appropriate boxes, whenever provided. Thank you.)

My Name: _____

My Age (Yrs.): 18-25 | 25-30 | 30+ My Occupation: _____

I own the following household appliances (please specify brand/s).

Air Purifier: _____ Water Purifier: _____ Vacuum Cleaner: _____

Others: _____

My Residential address: _____

City: _____ State: _____ Pin: _____

My Tel. No. (Residence): _____ (Office): _____

My Signature: _____

Dealer's Stamp & Signature



If your Forbes product requires any service or to claim under our Limited One-Year Warranty, please contact us as follows:

Website:

www.eurekaforbes.com

Email:

deepa.customercare@eurekaforbes.com

Toll-free Telephone:

1860 2601177 / 70398 83333

Write to us:

Eureka Forbes Limited
B1/B2, 701, 7th Floor,
Marathon Innova, Marathon NextGen,
Off Ganpatrao Kadam Marg, Lower Parel
Mumbai- 400013, India.



