

Manuals.plus / > ECOVACS / > ECOVACS Deebot Y1 Pro 2-in-1 Robot Vacuum Cleaner User Manual

ECOVACS DEEBOT Y1 PRO

Sign in to save this manual Sign in to bookmark this manual and keep private notes.

ECOVACS Deebot Y1 Pro 2-in-1 Robot Vacuum Cleaner User Manual

Model: DEEBOT Y1 PRO | Brand: ECOVACS

INTRODUCTION

The ECOVACS Deebot Y1 Pro is an advanced 2-in-1 robot vacuum cleaner designed to provide an unparalleled cleaning experience. It features powerful suction, long battery life, and intelligent navigation for efficient and thorough cleaning of various floor types. This manual provides essential information for setting up, operating, and maintaining your Deebot Y1 Pro.



Image: ECOVACS Deebot Y1 Pro Robot Vacuum Cleaner with a smartphone displaying its mapping capabilities.

WHAT'S IN THE BOX

Your ECOVACS Deebot Y1 Pro package includes the following components:

- Side Brush
- Main Roller Brush
- HEPA Filter
- Reusable Mopping Cloth
- Dust Tank
- Water Tank

Advertisements



0:00 / 0:19

Video: Unboxing and initial setup of the ECOVACS Deebot Y1 Pro, showing the included components and how to prepare the robot for first use.

SETUP

Initial Charging

Before first use, ensure your Deebot Y1 Pro is fully charged. Place the robot on its charging dock, ensuring the charging contacts align. The indicator lights will show charging status.

App Connection

Download the ECOVACS HOME app from your smartphone's app store. Follow the in-app instructions to connect your Deebot Y1 Pro to your home Wi-Fi network. The app allows for remote control, scheduling, and advanced cleaning settings.




Image: The ECOVACS Deebot Y1 Pro robot vacuum cleaner alongside a smartphone displaying the ECOVACS Home app interface, highlighting smart control capabilities.

OPERATING INSTRUCTIONS

Cleaning Modes

The DEEBOT Y1 Pro offers simultaneous vacuuming and mopping in a single pass. It is equipped with a powerful 6500 Pa suction for effective dirt and debris removal. The robot intelligently identifies carpets, avoiding them in mopping mode and boosting suction power in vacuuming mode for superior performance.



Video: Demonstration of the ECOVACS DEEBOT 2-in-1 Robot Vacuum Cleaner performing both vacuuming and mopping functions on various floor types.

Navigation and Obstacle Avoidance

Equipped with LiDAR technology and TrueMapping, the Y1 Pro quickly and accurately maps your home, allowing for precise and systematic cleaning routes. A combination of LiDAR and bumper sensors enables the robot to avoid household items and obstacles, ensuring smooth and uninterrupted cleaning.



Image: A smartphone screen displaying a detailed map of a house, indicating the robot vacuum's mapping capabilities and planned cleaning routes.

Advertisements





Image: The ECOVACS Deebot Y1 Pro robot vacuum cleaner navigating around obstacles on a floor, demonstrating its advanced obstacle avoidance technology.

Battery Life and Coverage

Powered by a 5200mAh battery, the Y1 Pro can clean up to 4000 sq. ft. on a single charge, offering up to 320 minutes of continuous cleaning.

SMART APP ENABLED
With ECOVACS Home App clean your home from anywhere, anytime.

The All New Y1 Pro Series
New Launch 2024

DESIGN AWARDS

No.1 Global Cumulative Sales for Robotic Vacuum Cleaners


Image: The ECOVACS Deebot Y1 Pro robot vacuum cleaner on a clean floor, highlighting its powerful 6500 Pa suction and 5200 mAh battery for extensive coverage.

Advertisements



MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your Deebot Y1 Pro. Refer to the video below for detailed cleaning instructions.



Video: A comprehensive guide on regular cleaning and maintenance procedures for the DEEBOT Y1 PRO, including cleaning sensors, brushes, and dustbin.

Cleaning Schedule

- **Laser Scanning Module:** Wipe regularly with a clean, dry cloth.
- **Sensor Lens & Anti-Collision Bumper:** Wipe regularly with a clean, dry cloth.
- **Charging Contacts:** Wipe regularly with a clean, dry cloth.
- **Dustbin & Filter:** Remove the dustbin, empty trash, and clean the filter sponge, filter, and filter net.
- **Side Brush:** Remove and clean the side brush and its slots.
- **Main Brush:** Remove the main brush cover, take out the main brush, clean it, and wipe down the main brush compartment.
- **Universal Wheel:** Clean the universal wheel.
- **Anti-Drop Sensors:** Clean the anti-drop sensors.
- **Driving Wheels:** Clean the driving wheels and wipe the treads.

Advertisements

SPECIFICATIONS

Feature	Detail
Brand	ECOVACS
Model Name	DEEBOT Y1 PRO
Special Feature	Smart Mapping Technology, Wet & Dry Robot Vacuum Cleaner, 6500Pa Suction Power, 5200 mAh Battery Capacity, 320 mins Run Time
Colour	Black
Product Dimensions	30L x 30W x 11H Centimeters

Included Components	Side Brush, Main Roller Brush, HEPA Filter, Reusable Mopping Cloth, Dust Tank, Water Tank
Filter Type	Hepa
Battery Life	330 Minutes
Cleaning Path Width	32.5 Centimeters
Voltage	240 Volts
Capacity	4.2 litres
Power Source	Battery Powered
Are Batteries Included	Yes
Control Method	App
Compatible Devices	Smartphones, Amazon Echo, Tablets, Google Home
Form Factor	Robotic
Manufacture Year	2025
Manufacturer	ECOVACS ROBOTICS
Country of Origin	China
Item model number	6943757619405
Item Weight	4 kg 700 g
Net Quantity	1 Count

WARRANTY AND SUPPORT

Your ECOVACS Deebot Y1 Pro comes with a standard brand warranty. For detailed information on warranty coverage, replacement policies, and EMI options, please refer to the product detail page where you purchased the device.

Customer Support

ECOVACS provides comprehensive customer support with over 90+ dedicated offices across India, offering door-step service for all users. Free installation and home service are available to ensure customer needs are prioritized. For assistance with demonstrations, installations, or any service requirements, please reach out via the toll-free number:

Toll-Free Number: 1800 258 8085

Advertisements



ECOVACS INDIA OFFICES

Support within 24 hours across India
Just call 1800 258 8085



Get product knowledge



Request demonstration before purchase



Ask post purchase installation at your home



Need home service

JUST CALL ON TOLL FREE LINE

1800 258 8085
(Monday to Saturday 10 am to 6 pm)

Image: A map showing ECOVACS India offices across the country, along with icons indicating product knowledge, demonstration requests, installation services, and home service availability.

Advertisements



© 2025 ECOVACS. All rights reserved.

Advertisements



Advertisements



Related Documents - DEEBOT Y1 PRO

Related Documents - DEEBOT Y1 PRO Documents related to the Deebot Y1 Pro 2-in-1 Robot Vacuum Cleaner. These documents provide detailed information about the product's features, usage, and maintenance.	ECOVACS DEEBOT N8 Black User Manual User manual for the ECOVACS DEEBOT N8 Black robot vacuum cleaner, including setup, operation, maintenance, and troubleshooting.
--	---

	ECOVACS DEEBOT Y1 Pro Plus Vacuum Cleaner Instruction Manual Comprehensive instruction manual for the ECOVACS DEEBOT Y1 Pro Plus Vacuum Cleaner, covering setup, operation, maintenance, and troubleshooting.
	ECOVACS DEEBOT mini Family Instruction Manual Comprehensive instruction manual for the ECOVACS DEEBOT mini Family robotic vacuum cleaner, covering setup, operation, maintenance, and safety guidelines.
	ECOVACS DEEBOT IN20 PRO / IN20 Instruction Manual Comprehensive instruction manual for ECOVACS DEEBOT IN20 PRO and DEEBOT IN20 robotic vacuum cleaners, covering setup, operation, safety, and app connectivity.
	ECOVACS DEEBOT T80 Family Instruction Manual Comprehensive instruction manual for the ECOVACS DEEBOT T80 Family robotic vacuum cleaners, covering setup, operation, maintenance, and troubleshooting.
	ECOVACS DEEBOT U2 Series Instruction Manual - User Guide Official instruction manual for the ECOVACS DEEBOT U2 Series robotic vacuum cleaner. Learn about setup, operation, maintenance, safety, and troubleshooting.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

ECOVACS DEEBOT Y1 PRO

KEEP EXPLORING MANUALS, GUIDES, AND SUPPORT DOCS.

Search model numbers, browse help resources, and jump straight into the next PDF manual or troubleshooting page without losing your place.

ECOVACS DEEBOT Y1 PRO

Search Manuals+

EXPLORE

Deep Search

Upload

Login

MANUALS+

Home

About Us

Privacy Policy

Login

GUIDES

Amazon Manuals

AliExpress Manuals

Video Guides

Login

FOLLOW

@manualsplus

YouTube

LinkedIn

Facebook

Login

Manuals+

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners.

SAVE MANUALS, NOTES, UPLOADS, AND QUESTIONS

Sign in with Google, X, or a passkey to keep private notes on saved manuals, track public uploads, and revisit questions you posted.

Open login options

[Privacy Policy](#) · [DMCA](#)