

## USER MANUAL



Thank you for choosing the boAt Enigma Ascend as your fitness transformation companion.

Allow this manual to guide you through the functioning of your smartwatch. Please read it thoroughly before using it for a smooth sail. You may refer to these instructions for later use as well.



### PACKAGE CONTAINS

- boAt Enigma Ascend x1
- USB Magnetic Charging Cable x1
- User Manual x1
- Warranty Card x1

### CHARGING THE WATCH

The smartwatch must be charged before initial use. It takes up to 3 hours to be fully charged.

Connect and charge the watch with the image below as a reference, using 5V/2A adapter.



### TURNING THE WATCH ON/OFF


To turn the watch on, press the side button 1 time.

To restart or turn the watch off, long-press the side button for 2-3 seconds.

You can wake up the screen by lifting your wrist.

### CONNECTING TO THE APP

- Download the boAt Crest app on your phone.  
Available on both App Store (iOS 14.0 and above) and Google Play Store (Android 7.0 and above) OR
- Scan [QR CODE] (Also available on the watch)
- Connect the device with the boAt Crest app; ensure that the phone's Bluetooth, as well as the GPS functionalities, are turned on
- Select Enigma Ascend on the app's home screen and click pair to connect.
- Once connected, you will get an alert to connect with Ascend\_XXXX, click pair if you need to receive or make calls from the watch.
- To use all your Enigma Ascend features seamlessly, tap on 'yes' to the 'connection' and 'grant access' system prompt.
- Disable battery optimization



Note: To ensure connectivity throughout your journey, make sure the app is allowed to always run in the background of your phone.

### SYNCING YOUR SMARTWATCH TO THE APP


#### Data Synchronization

- Open the app on your phone.
- Make sure your Enigma Ascend is connected to the app.
- Synchronization will start automatically once you enter the app interface.

Note: Synchronize data at least once every day to avoid data loss in the watch.

### WATCH FACE SWITCH

To select a watch face, turn on the watch and rotate the side button to choose your preferred watch face from the options.



### NAVIGATING THROUGH THE FUNCTIONS

Short press the side button for the Main Menu. Swipe right to go back to previous tab.

**Call**

**Contacts**

Add up to 20 contacts from the boAt Crest app. You can select any contact to directly dial from the watch.

**Call History**

Add up to call recently received, missed, and outgoing call logs in the Call History of the watch.

**Dial**

You can use the dial pad to dial any number.

**Sports**

Choose from multiple sports modes like Running, Treadmill, Walking, Cycling, Badminton, Football, Basketball, Yoga, etc. The watch has 100+ sports modes. You can also add or replace the activities according to your preference.

Tap on any sports mode to start the activity and the watch will start recording the duration of the activity. Short press the side button to stop the activity. The activity will not be recorded if it is less than 3 mins.

**Sports Record**

Sync your smartwatch to the app to get a detailed record of your activities.

**Activity**

Click on this to check your daily activity data like step count, calories, and distance covered.

**Heart Rate Monitor**

Wear the watch on your wrist, then click on the icon to start measurements. You can also view the data on the app.

Note: Measurements are for reference only and not for medical purposes.

**SpO2 Monitoring**

Wear the watch on your wrist, then click on the icon to start measurements. You can also view the data on the app.

Note: Measurements are for reference only and not for medical purposes.

**Stress Monitor**

Click this option to start the stress monitoring. Make sure you wear your watch on your wrist properly to get the accurate results.

Analysis of the measurement is

Relax: 1-29

Normal: 30-59

Medium: 60-79

High: 80-99

Note: Measurements are for reference only and not for medical purposes.

**Stopwatch**

Click on this to start the stopwatch on your watch.

**Notifications**

You can check all the notifications from here.

**Sleep Monitor**

Tap on the icon to review the sleep data of the previous night. Once the asleep criteria are met, your smartwatch will start recording from 8 pm at night to 10 am in the morning the next day. Once you lie down and watch detects no movement for 30 minutes, it will start recording, and will stop recording if it detects excessive movements.

You can check the data on the app only after the awake criteria is met. You can also track sleep scores on the boAt Crest app.

Note: For accurate sleep data recording, the asleep criteria have to be met which includes limited movement, wrist positions and angles, and more.

\*The awake criteria will be met only after it records some noticeable movement.

**Weather**

Connect with the boAt Crest app to get daily weather updates on the watch.

**Breathing Exercise**

Click on the breathing exercises icon to regulate your breathing by doing breathing exercises. You can set the time and intensity level of the exercise.

**Alarm**

Tap on this to set an alarm on your watch.

**Camera Control**

Tap on the remote camera icon on your smartwatch to click a photo from your phone.

Note: Turn the camera on from your phone to use this feature.

**Music control**

Tap on the remote music control icon on your watch to play music from your phone.

Note: Some apps with different protocols might not work.

**Timer**

Tap on this to turn on the timer.

**Voice Assistant**

Tap on this to enable the voice assistant feature and give the command from the watch.

Note: Make sure the watch is connected with the app.

**Find My Phone**

Tap on this icon to find your phone. Once enabled, your phone will start ringing and vibrating. Tap again to stop it.

Note: Your smartwatch should be connected to your phone via Bluetooth and within its range for this feature to work.

**Calendar**

Click on calendar to check the date, day, and month.

**Games**

Tap on this to access the built-in games. You can select from 2048, AirSpace and Flappy Bird.

**World Clock**

Click on this to check the time across the globe.

**Calculator**

Tap on this icon to do all the calculations in your smartwatch.

**Flashlight**

Tap on this to turn your dial into a flashlight.

**App QR Code**

Tap on this and scan the QR Code from mobile to connect the smartwatch.

### SETTINGS

**Dial Setting**

Tap on this icon to change your watch face. You can choose from 5 default watch faces. Alternatively, you can long press the home screen or rotate the side button to switch between the watch faces.

**Wake Gesture**

Tap on this to enable wake gesture. You can also schedule the wake gesture feature.

**Do not Disturb**

Tap on this to turn on the Do Not Disturb mode.

**Password**

Tap on this to set or change the password on your smartwatch.

**Always on Display**

Click on this to enable always on display.

Note: The battery will drain quickly once this mode is enabled.

**Brightness**

Tap on this to adjust the brightness.

**Language**

Tap on this to set the language.

**Themes**

Tap on this icon to set the theme. There are 3 themes you can choose from.

**System Menu**

Tap on this to reboot, factory reset, or to power off the smartwatch.

**Standby Screen**


Tap on this and adjust the screen standby time.

**About**

Shows the device details.

### SWIPE UP FOR THE SHORTCUT MENU

You can access the Always on Display, Find My Phone, DND mode, Brightness, Enable Bluetooth Calling, and Settings.




### SWIPE RIGHT TO ACCESS THESE FUNCTIONS

You can access alarm, weather, activity records, settings, App QR code, and daily activity log.




### SWIPE LEFT TO ACCESS ALL DATA

You can access heart rate, daily activity record, stress level, SpO2, and customize shortcuts option.




### SWIPE DOWN TO ACCESS NOTIFICATIONS

You can access the Notifications by swiping down.



### SIDE BUTTON FUNCTIONALITY

Rotate the side button to navigate through the main menu and long-press the side button to turn off the watch.



## PRODUCT PARAMETERS

MODEL	boAt Enigma Ascend
SCREEN TYPE	1.76" TFT Display
BATTERY CAPACITY	300mAh
NET WEIGHT	168g
BLUETOOTH VERSION	Bluetooth v5.1
WORKING TEMPERATURE	-20°C-60°C
CHARGING TIME	3 hours
WORKING TIME	4-5 days
WATER RESISTANCE	IP67

## MAINTENANCE

Regularly clean your wrist and the strap of the smartwatch, especially after sweating during exercise or being exposed to substances such as soap or detergent, which may get stuck on the other end of the product.

Do not wash the strap with a household cleanser. Please use soap less detergent, rinse thoroughly and wipe with a piece of soft towel or napkin.

For spots or stains that are not easy to remove, scrub the area with rubbing alcohol and then follow the above procedure.

## FAQ

### Search for the app to connect keeps failing.

- Keep the boAt Crest app updated to the latest version
- Close all the programs on the watch → Stop and restart Bluetooth and GPS → Connect again
- Check and enable the notification functions of your phone and keep the phone and watch in close contact.

Note: Make sure your phone system meets Android 7.0 and above and iOS 14.0 and above.

### My Enigma Ascend is receiving no alerts, texts, or phone calls.

Make sure smart reminders on the app are on and synced to Enigma Ascend. Also make sure your notification center of the phone is displaying messages. Only then will your smartwatch also display those notifications.

Make sure app is running in the background and battery optimization feature on the phone is disabled.

### My Bluetooth keeps getting disconnected.

- Make sure there is not more than 7m distance between Bluetooth on the phone and the watch.
- There is no obstacle between the watch and the phone.
- Make sure the app is running in the background.

### Which functions of Enigma Ascend need Bluetooth to work?

Call & Text Notifications, Find My Phone, music control, camera control, weather forecast, cloud and custom watch faces and Bluetooth calling need Bluetooth connectivity to work.

### Will it be okay to take a bath wearing Enigma Ascend ?

The IP67 water resistance will only work under the following conditions:

- (1) Maximum depth of water: 1.5m (2) Maximum time for exposure to water: 10 minutes
- The watch isn't suitable for hot baths, hot springs, saunas, snorkeling, diving, water skiing and other wading or deep-water activities with high-speed water flow.

## SAFETY & PRODUCT INFORMATION

### Battery

- Do not disassemble, bore or damage the battery.
- Do not disassemble the built-in batteries of non-replaceable battery devices.
- Do not use sharp objects to remove the battery.

### Health Warning

- If you are wearing a pacemaker or other implanted electronic devices, please consult your doctor before using the heart rate monitor of the watch.
- The optical heart rate sensor will glow green. If you suffer from epilepsy or are sensitive to blinking light sources, please consult your physician before wearing this device.
- The device tracks your daily activities through sensors. This data is intended to tell you about your daily activities such as steps, sleep, distance, heart rate and calories, but may not be completely accurate.
- The device accessories, heart rate sensor, oxygen level monitor, and other relevant data is designed for fitness and not for medical purposes. They are not applicable to the diagnosis, monitoring, treatment or prevention of any diseases or symptoms. The heart rate, and blood oxygen are for reference only. We're not responsible for any deviation in data.
- Avoid wearing the watch too tight in daily use. Keep the parts of skin touching the watch dry. In contact with the watch. If symptoms such as redness or swelling appear on your skin, immediately stop using the watch and consult the doctor.

### Things to Keep in Mind

- Sync data everyday days to avoid data loss.
- Water Resistance will not work for seawater, acidic and alkaline solutions, chemical reagents and other corrosive liquid. The damage or defects caused by misuse or improper use are not covered by the warranty.
- Sports modes support up to 6 hours of exercise at a time.
- Avoid wearing the watch too tight in daily use. Keep the parts of skin touching the watch dry.
- Keep your arm still while measuring data for accurate measurement.

Disclaimer: This product is an electronic monitoring product and is not intended as a medical reference. We reserve the right to modify or improve any of the functions described in this manual without any prior notice. At the same time, we hold the right to continuously update the product content.

## CAUTION

RISK OF EXPLOSION IF BATTERY IS REPLACED BY AN INCORRECT SUBSTITUTE.

DISPOSE OF USED BATTERIES ACCORDING TO THE INSTRUCTIONS.

Old electrical appliances must not be disposed of together with the residual waste, but have to be disposed of separately. The disposal at the communal collecting point via private persons is free. The owner of old appliances is responsible to bring the appliances to these collecting points or to similar collection points. With this little personal effort, you contribute to recycle valuable raw materials and treatment of toxic substances.