

Earphone Function


Touch control area

The earphones are touch-controlled. After wearing them, touch the indication area to trigger the corresponding operations.

Status indicator

Charging port

Function button



Earphone Function Settings and Upgrades

OnePlus phone users

For OnePlus 6 and later models, please update the "Wireless Earphones" App (ColorOS 11 or later) or "OnePlus Buds" App (HydrogenOS 11) to the latest version in the app store. Then you can customize the earphone function in [Settings - Bluetooth], use the earphone features, and upgrade the earphone software version.

Other Android (and iOS) phone users

Please download and install the [HeyMelody] App. Customize the earphone function in the App, use the earphone features, and upgrade the earphone software version to have a better experience.



HeyMelody

※ Please download HeyMelody from Google Play Store or App Store.

Pairing and Connecting

Connection to OnePlus phone


For OnePlus 6 and later models, please enable Bluetooth on your phone, open the earphone charging box and get it close to the phone, and then follow the on-screen instructions.

Connection to other devices

Please put the earphones into the box and open the lid. Press and hold the function button for 2 seconds until the white indicator flashes, then enter the Bluetooth settings and select "OnePlus Buds 4".

Restoring factory settings

Put the earphones into the box and open the lid. Press and hold the function button for 15 seconds until the red indicator flashes to restore the earphones to factory settings.



Replacing Ear Caps

The proper size of ear caps is crucial to the noise reduction experience, sound quality, and wearing comfort. Please try on ear caps of different sizes and make the right choices. Please note that your left and right ears may need different sizes of ear caps.

※ Please use the ear caps with the earphone fit detection function. For details, see the instructions for the function. When replacing the ear caps, please keep the tuning hole unobstructed.

※ M size ear caps have been pre-installed on the earphones.



Touch Function

Earphone function	Left earphone	Right earphone
*Play/Pause	●	●
Answer/Hang up calls	● ●	● ●
Next track	● ●	● ●
Previous track	● ● ●	● ● ●
Noise reduction/ transparent mode switching	▬ 1s	▬ 1s
Volume "+"	↑	↑
Volume "-"	↓	↓

● Tap

● ● Double-tap

● ● ● Triple-tap

▬ Press and hold for 1 second

↑ ↓ Slide up and down

*Functions marked with an asterisk are disabled by default, and you will need to enable them in the App settings if necessary.



Charging

Put the earphones into the charging box and close the lid to charge them.

When the earphones are in the charging box, the indicator shows the battery level of the earphones.

When the earphones are not in the charging box, the indicator shows the battery level of the charging box.

Indicator color:


Green light indicates a high battery level, yellow light a medium battery level, and red light a low battery level.

Charging the charging box:

Charge the charging box with a USB-C charging cable.

● Charging: The yellow light is always on.

● Charging done: The green light is always on.



ईयरफोन फंक्शन

टच कंट्रोल वाली जगह

ये ईयरफोन टच से चलते हैं। इन्हें लगाने के बाद, दिखाई गई जगह पर संबंधित कार्य को ट्रिगर करने के लिए टच करें।



स्टेटस इंडिकेटर

चार्जिंग पोर्ट

फंक्शन बटन

ईयरफोन फंक्शन की सेटिंग्स और अपग्रेड

OnePlus फोन के उपयोगकर्ता

OnePlus 6 और इसके बाद के मॉडल्स के लिए, कृपया ऐप स्टोर में जाकर "Wireless Earphones" ऐप (ColorOS 11 या इसके बाद के वर्शन) या "OnePlus Buds" ऐप (HydrogenOS 11) को अपडेट करें। इसके बाद आप [सेटिंग्स - ब्लूटूथ] में जाकर ईयरफोन फंक्शन को कस्टमाइज़ कर सकते हैं, ईयरफोन के फीचर्स का उपयोग कर सकते हैं और ईयरफोन का सॉफ्टवेयर वर्शन अपग्रेड कर सकते हैं।

अन्य Android (और iOS) फोन उपयोगकर्ता

कृपया [HeyMelody] ऐप डाउनलोड और इंस्टॉल करें। बेहतर अनुभव के लिए ऐप में ईयरफोन फंक्शन को कस्टमाइज़ करें, ईयरफोन के फीचर्स का उपयोग करें और ईयरफोन का सॉफ्टवेयर वर्शन अपग्रेड करें।



HeyMelody

※ कृपया HeyMelody को Google Play Store या App Store से डाउनलोड करें।

कनेक्शन पेयर हो रहा है

OnePlus फोन से कनेक्ट करना


OnePlus 6 और इसके बाद के मॉडल्स के लिए, कृपया अपने फोन पर ब्लूटूथ चालू करें, ईयरफोन चार्जिंग बॉक्स खोलें और उसे फोन के पास रखें, इसके बाद स्क्रीन पर दिए गए निर्देशों का पालन करें।

अन्य डिवाइस से कनेक्ट करना

कृपया ईयरफोन को बॉक्स में रखें और ढक्कन खोलें। फंक्शन बटन को 2 सेकंड तक दबाकर रखें, जब तक सफेद रंग का इंडिकेटर चमकने न लगे, इसके बाद ब्लूटूथ सेटिंग्स पर जाएँ और "OnePlus Buds 4" चुनें।

फैक्टरी सेटिंग्स रीस्टोर करना

ईयरफोन को बॉक्स में रखें और ढक्कन खोलें। ईयरफोन की फैक्टरी सेटिंग्स रीस्टोर करने के लिए, फंक्शन बटन को 15 सेकंड तक दबाकर रखें, जब तक लाल रंग का इंडिकेटर चमकने न लगे।



ईयर कैप्स को बदलना

और आरामदायक एहसास के लिए सही आकार के ईयर कैप्स का होना ज़रूरी होता है। कृपया अलग-अलग आकार के ईयर कैप्स आजमाएँ और सही ईयरप्लग का उपयोग करें। कृपया ध्यान दें कि आपके बाएँ और दाएँ कान में अलग-अलग आकार के ईयर कैप्स लग सकते हैं।

※ कृपया ईयरफोन फिटि इंटिक्शन फंक्शन के साथ ईयर कैप का उपयोग करें।

विवरण के लिए, फंक्शन के लिए निर्देश देखें। ईयर कैप बदलते समय, कृपया ट्यूनिंग होल को बिना किसी बाधा के रखें।

※ M आकार के ईयर कैप्स, ईयरफोन में पहले से लगे हुए आते हैं।



टच फंक्शन

ईयरफोन फंक्शन	बायाँ ईयरफोन	दायाँ ईयरफोन
*चलाना/रोकना	●	●
कॉल उठाना/काटना	● ●	● ●
अगले ट्रैक पर जाना	● ●	● ●
पछिले ट्रैक पर जाना	● ● ●	● ● ●
शोर कम करना/ट्रांसपेरेंट मोड पर स्विच करना	1 सेकंड	1 सेकंड
वॉल्यूम "+"	↑	↑
वॉल्यूम "-"	↓	↓

● एक टैप

● ● दो टैप

● ● ● तीन टैप

1 सेकंड तक दबाए रखना

ऊपर और नीचे स्लाइड करें



*ऐस्ट्रॉनॉमिकल नोशन लगे फंक्शन डिफॉल्ट रूप से बंद रहते हैं और ज़रूरत पड़ने पर आपको उन्हें ऐप की सेटिंग्स में जाकर चालू करना होगा।

चार्ज करना

ईयरफोन को चार्ज करने के लिए चार्जिंग बॉक्स में रखें और ढक्कन बंद कर दें। जब ईयरफोन चार्जिंग बॉक्स में होते हैं, तब इंडिकेटर ईयरफोन का बैटरी लेवल दिखाता है।

जब ईयरफोन चार्जिंग बॉक्स में नहीं होते हैं, तब इंडिकेटर चार्जिंग बॉक्स का बैटरी लेवल दिखाता है।

इंडिकेटर का रंग:

हरे रंग की लाइट का मतलब है कि बैटरी लेवल अच्छा है, पीले रंग की लाइट का मतलब है कि बैटरी लेवल मीडियम है और लाल रंग की लाइट का मतलब है कि बैटरी लेवल कम है।

चार्जिंग बॉक्स को चार्ज करना:

चार्जिंग बॉक्स को USB-C चार्जिंग केबल से चार्ज करना।

• चार्ज करना: इसमें पीले रंग की लाइट चालू रहती है।

• चार्जिंग का पूरा होना: इसमें हरे रंग की लाइट चालू रहती है।

