

<div>ColorFit Icon Arc</div> <div>Please refer to this manual before using the product</div>	<div>TABLE OF CONTENT</div> <div><div><div><div>• What's in the Box</div><div>• Watch Overview</div><div>• Charging the Watch</div><div>• Turning the Watch On or Off</div><div>• Watch Navigation</div><div>• Home Screen Navigation</div><div>• App Setup</div><div>• Pairing the Watch</div><div>• BT Call Connectivity and Removal</div><div>• Watch Features</div><div>• General Device Information and Tips</div><div>• Disposal and Recycling Information</div><div>• Regulatory Information</div><div>• Maintenance Instructions</div><div>• Safety Instructions</div><div>• Customer Support</div></div><div><div>01</div><div>01</div><div>02</div><div>03</div><div>04</div><div>04</div><div>05</div><div>06</div><div>07</div><div>08-14</div><div>15-16</div><div>17</div><div>17-18</div><div>19</div><div>19-20</div><div>20</div></div></div></div>	<div>WATCH OVERVIEW</div> <div><div><div><div>• Noise Health</div><div>• Exercise</div><div>• Exercise record</div><div>• Activity</div><div>• Turners</div><div>• Heart Rate</div><div>• SpO2</div><div>• Sleep</div><div>• Stress</div><div>• Breathe</div><div>• Contacts</div><div>• Phone</div><div>• Alarm</div><div>• Stopwatch</div><div>• Timer</div></div><div><div>• World clock</div><div>• Weather</div><div>• Reminders</div><div>• Music</div><div>• Camera</div><div>• Calendar</div><div>• Calculator</div><div>• Flashlight</div><div>• Watch faces</div><div>• Settings</div></div></div></div>	<div>PACKAGE CONTAINS</div> <div><div><div><div>ColorFit Icon Arc smartwatch x 1</div><div>Charging cable x 1</div></div><div>01</div></div></div>	<div>USING COLORFIT ICON ARC SMARTWATCH</div> <div><div><div><div>• Plug the USB cable into a power adaptor. Plug the power adaptor into an electrical socket. (Power adaptor not included).</div><div>• Place the magnetic charger on the magnetic charging points of the watch.</div><div>• While your watch is charging, the screen will show its progress.</div><div>• Once the battery is fully charged, remove the charger.</div></div><div><div>02</div></div></div></div>	<div>POWER ON</div> <div><div><div><div>Press the side-upper button for a few seconds to turn on the watch.</div><div>POWER OFF</div><div>• Press and hold the side-upper button for 4-5 seconds.</div><div>• Select 'Power off'</div></div><div><div>03</div></div></div></div>	<div>WATCH NAVIGATION</div> <div><div><div><div>The ColorFit Icon Arc smartwatch has a 2.01" TFT Display. Navigate the watch by tapping on the screen, swiping side to side, up and down, and pressing the side button.</div><div>SIDE-UPPER BUTTON NAVIGATION</div><div>Press the side-upper button to turn on the watch display.</div><div>HOME SCREEN NAVIGATION</div><div>The home screen is the watch face. From the home screen:</div><div>• Swipe left to access widgets.</div><div>• Swipe right to access shortcut screens.</div><div>• Swipe up to access quick settings.</div><div>• Swipe down to access notifications.</div></div><div><div>04</div></div></div></div>	<div>APP SET-UP</div> <div><div><div><div>Before pairing, make sure that your smartphone and smartwatch are next to each other. The App will ask for personal information such as height, weight and sex to calculate your stride length, distance covered, calorie burn rate and metabolic rate. When you set up your account, your name and profile picture will be visible to other users.</div><div>• Turn on Bluetooth and the location on your mobile device.</div><div>• On your smartphone, download the NoiseFit app from the Play store or the App store and install it.</div><div>• Create an account or log in using an existing account.</div><div>Note: Ensure that your smartphone is running on Android 9.0+ or iOS 11 + and is connected to mobile data or a Wi-Fi network.</div></div><div><div>05</div></div></div></div>	<div>PAIRING THE WATCH</div> <div><div><div><div>• Open the NoiseFit app and turn on the Bluetooth and GPS positioning.</div><div>• Feed in your personal information and health goals in the App.</div><div>• Go to the 'Device' section in the App, tap on 'Add Device' then 'Search'. Select Noise ColorFit Icon Arc and link the watch.</div></div><div>Or you can follow the steps below:</div><div>• Turn on the watch.</div><div>• Scan the QR code on your watch using the NoiseFit App on your phone.</div><div>• Select 'Pair with device' and wait for it to pair.</div><div>• Select 'Add Device'. Choose your device from the range of devices.</div><div>On iOS: Choose Bluetooth pairing when you receive a pairing prompt.</div><div>On Android: Connect it directly.</div></div><div><div>06</div></div></div>
--	--	--	--	---	--	---	--	---

<div>NOISE BUZZ</div> <div>Noise ColorFit Icon Arc supports Bluetooth Calls. You can dial, answer, silence and reject calls from the smartwatch as long as the watch's Bluetooth is connected to the smartphone and is within Bluetooth range.</div> <div>CONTACTS</div> <div>You can choose to sync 10 contacts from your phone into the NoiseFit App which will be reflected on your watch. Choose from the list of saved contacts in your smartwatch to call.</div> <div>PHONE</div> <div>You can access the dial pad from here.</div> <div>CALL HISTORY</div> <div>Choose from the call logs to call any of the previously contacted numbers.</div> <div>ALARM</div> <div>You can set an alarm from the NoiseFit app.</div> <div>STOPWATCH</div> <div>A stopwatch can be set on the smartwatch. You can also set lap times on the stopwatch.</div>	<div>TIMER</div> <div>You can set a countdown with a pre-set duration on the watch or set your own timer. The watch will remind you when the time is up. Go to 'Clock', select 'Timer' and set it as per your requirement.</div> <div>WORLD CLOCK</div> <div>Choose from different time zones and have a look at world clocks.</div> <div>WEATHER</div> <div>Noise ColorFit Icon Arc supports 5-day weather viewing in a location of your choice as long as it is synced with the NoiseFit app. You can view today's current weather and for the next 4 days as well.</div> <div>FLASHLIGHT</div> <div>Use this feature to turn on the flashlight. Swipe up to turn on the SOS flashlight. For SOS flashlight, swipe right in the flashlight section to make the flashlight blink.</div> <div>REMINDERS</div> <div>Set reminders for important events.</div> <div>MUSIC</div> <div>You can control your favourite songs and podcasts that play from your phone, right on your wrist as long as the watch is connected with the NoiseFit app on your phone.</div> <div>You can play/pause music, go to the next/previous track and increase/decrease the volume.</div>	<div>CAMERA</div> <div>You can use this feature to use the smartwatch to click pictures from the phone remotely.</div> <div>CALENDAR</div> <div>Use this feature to check the calendar.</div> <div>FIND PHONE</div> <div>Use this feature to find your mobile device by making it ring. Just tap on 'Find my phone', and your phone will start to ring, even if it is on Silent mode.</div> <div>FLASHLIGHT</div> <div>Use this feature to turn on the flashlight. Swipe up to turn on the SOS flashlight. For SOS flashlight, swipe right in the flashlight section to make the flashlight blink.</div> <div>WATCH FACES</div> <div>Give your screen a personalised style by changing or customising the watch face from the NoiseFit app or the watch. Choose and download cloud-based watch faces or create custom watch faces using the NoiseFit app.</div> <div>• On the Watch</div> <div>Touch and hold the home screen. Swipe and choose from the watch faces.</div> <div>• In the App</div> <div>Go to 'Watch faces', select the watch face of your choice and tap save to change the watch face.</div>	<div>SETTINGS</div> <div>NOTIFICATIONS</div> <div>Select how you would want your notifications to appear.</div> <div>SOUND & VIBRATION</div> <div>• SILENT</div> <div>Choose to turn it on or off</div> <div>• RING</div> <div>Set the ringtone level as per your preference</div> <div>• ALARM</div> <div>Select high or low volume for your alarm from here</div> <div>• VIBRATION</div> <div>Choose to turn it on or off</div> <div>• VIBRATION INTENSITY</div> <div>Choose from none, weak or strong</div> <div>DISPLAY</div> <div>Choose brightness level, auto lock duration, schedule time for raise to wake, (cover to sleep), choose to turn on or off the always-on display and select the default theme.</div>	<div>DND</div> <div>Turn it on or off, select the duration and enable or disable smart DND.</div> <div>AUTO DETECT</div> <div>The watch supports auto-detection of three types of exercises. Enable or disable the auto detection of these exercises from here.</div> <div>LAYOUT</div> <div>Choose the layout of the menu from grid, list, wheel or honeycomb.</div> <div>CUSTOMISE DOWN BUTTON</div> <div>Choose what happens when you press the down button on the watch.</div> <div>BATTERY</div> <div>Check the battery level from here.</div> <div>SYSTEM</div> <div>Choose to reboot, power off or reset from here.</div>	<div>ABOUT WATCH</div> <div>DEVICE INFORMATION</div> <div>The ColorFit Icon Arc smartwatch contains the following</div> <div>• 2.01" TFT Display</div> <div>• 22mm strap</div> <div>• 1 ATM water resistance</div> <div>• Blood oxygen monitor</div> <div>• Heart rate monitor</div> <div>The ColorFit Icon Arc smartwatch stores your activity data for up to 7 days between the time you sync your watch to the ColorFit Icon Arc. Activity data includes your steps, distance, calories, active minutes, heart rate, sleep duration and workout data. We recommend syncing the watch to the app daily.</div> <div>How do I update my ColorFit Icon Arc ?</div> <div>• Go to 'My Profile' (the icon on the top left corner of the home page) on the NoiseFit App</div> <div>• Select 'About'</div> <div>• Choose 'Check for Updates'</div> <div>• Update if it's available</div> <div>How do I find my watch's current firmware version?</div> <div>You can find the watch's current firmware on the watch as well as on the ColorFit Icon Arc App. On your watch, go to 'Settings' and tap on 'System'. Scroll down and click on 'Firmware Upgrade' to view the current firmware version. On the NoiseFit app, go to 'My Device' and tap on 'Firmware update' to know your current firmware version.</div>	<div>How does the watch estimate how many calories have been burned?</div> <div>ColorFit Icon Arc estimates how many calories you've burned based on the physical activity data and your heart rate.</div> <div>How do I change my health goals?</div> <div>You can do it through the NoiseFit app. In the app, go to 'My Device' and tap on the profile icon in the top left corner. Tap on your ID in the top section to change your health goals.</div> <div>How do I log my weight?</div> <div>You can log in your weight the first time you set up your ColorFit Icon Arc smartwatch. However, you can update the weight later via the NoiseFit app. Go to 'My Device' and tap on the profile icon in the top left corner. Tap on your ID in the top section to update your weight. You can update your gender, birthday and height as well.</div>	<div>DISPOSAL AND RECYCLING INFORMATION</div> <div>Electrical and electronic devices may not be disposed of with domestic waste. Consumers are obliged by law to return the electrical and electronic devices at the end of their service lives to the public collectionpoints set up for this purpose or point of sale. Details of this are defined by the national law of the respective country. By recycling, reusing materials or other forms of utilizing old devices, you are making an important contribution to protecting our environment.</div> <div>REGULATORY INFORMATION</div> <div>USA: Federal Communications Commission (FCC) Statement</div> <div>This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:</div> <div>This device may cause harmful interference, and this device must accept any interference received, including interference that may cause undesired operation.</div> <div>Warning: Changes or modifications not expressly Approved by the party responsible for compliance could void the user's authority to operate the equipment.</div> <div>Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.</div> <div>If this 76 equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</div>	<div>• Reorient or relocate the receiving antenna.</div> <div>• Increase the separation between the equipment and the receiver.</div> <div>• Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.</div> <div>• Consult the dealer or an experienced radio/TV technician for help.</div> <div>The Noise ColorFit Icon Arc smartwatch is not a toy. The watch contains small components that could be a choking hazard and are not intended for use by small children or pets. Unless otherwise specified, devices and services are not medical devices and are not intended to diagnose, treat, cure or prevent any disease. We develop products and services to track daily activity and wellness information as accurately as possible. The accuracy of devices is not intended to be equivalent to medical devices or scientific measurement devices.</div> <div>In some cases, prolonged use of products may cause skin irritation. Prolonged contact may contribute to skin irritation or allergies in some users. To reduce the possibility of irritation, keep the watch and watch band clean and dry. Don't wear it too tight and give your wrist a rest by removing the watch after an extended period of wear. If you feel soreness, tingling, numbness, burning or stiffness in your hands or wrists while or after wearing the watch, please immediately discontinue use.</div>	<div>MAINTENANCE INSTRUCTIONS:</div> <div>• Keep the device dry and clean regularly especially after prolonged use as moisture and dirt can build up underneath the band and can cause skin irritation.</div> <div>• Do not wear the device too tight but make sure that the bottom sensor is lightly in contact with your skin and that there is a gap of about one finger's width between the wrist strap and your wrist.</div> <div>• Do not use household cleaners to clean the device. Use soap-free cleaners instead.</div> <div>• For stains that are difficult to remove, it is recommended to scrub with alcohol.</div> <div>• The device is not suitable for diving, swimming in the sea or sauna; it is suitable for swimmingpool, shower (cold water) and swimming in shallow.</div> <div>• Keep it away from direct sunlight, high temperatures or humid conditions as it may damage the band over time.</div> <div>SAFETY INSTRUCTIONS</div> <div>• Do not disassemble the battery on your own.</div> <div>• Do not expose Noise ColorFit Icon Arc to extremely high or low temperatures. Excessive temperature during charging could cause heat, smoke, fire or deformation of the battery or of the battery or even explosion.</div> <div>• Charge the battery in a cool, ventilated room.</div> <div>• Do not open, crush, bend, deform, puncture or shred secondary cells or batteries. In the event of a battery break or leak, prevent battery liquid contact with skin or eyes. If this happens, immediately flush the areas with water or seek medical help. (DO NOT RUB THE EYE).</div> <div>• Short-circuits may damage the battery. It can occur when a metallic object, such as a coin, causes the direct connection of positive and negative terminals of the battery.</div> <div>• Keep the batteries out of children's reach and in a safe place to prevent danger.</div> <div>• Do not place the batteries in the water.</div> <div>• Do not use your product in a sauna or steam room.</div>	<div>CUSTOMER SUPPORT</div> <div>If you experience any problem with the watch, it may be fixed by restarting your watch. For further assistance, please reach out to us at support.gonoise.in</div> <div>• Do not dispose off batteries in the fire as that may cause an explosion. Dispose off used batteries in accordance with your local regulations.</div> <div>• Do not dispose it as household waste.</div> <div>• Use only the charging cable supplied to charge the battery.</div> <div>• Do not charge for more than 24 hours.</div> <div>• Do not attempt to repair or maintain the watch yourself. Service and maintenance should be performed by authorized technicians only.</div> <div>• Any device failure should be referred to our after-sales service personnel.</div> <div>• To prevent device damage, accessory damage and device failure, always protect against strong impact or shock.</div> <div>• Do not use your product in a sauna or steam room.</div>
--	---	---	---	--	---	---	--	---	---	---