

Installation / Demo Report

Customer Copy

Customer's Name :.....
Address :.....
.....Telephone No :.....
Model / Serial No. :.....Comp.No.....
Installation Check Point
M/C Delivered on:.....M/c Installed on:.....

To be filled by Installation (Service Engineer)

CONTROL & ADJUSTMENT

1. Refrigerator kept in ventilated area?
क्या रेफ्रिजरेटर वायु प्रवाहित स्थान पर रखा हुआ है?

Yes☐No☐

2. Has Leg Adjustment / Leveling of Refrigerator being done?
क्या रेफ्रिजरेटर की लीग व्यवस्था / स्तर सेट कर दिया गया है?

Yes☐No☐

3. If the Condition of Voltage / Earthing / Plug Point are poor, has customer been advised?
यदि वोल्टेज स्थिति/अर्थिंग/प्लग पॉइंट खराब है तो क्या उनके बारे में ग्राहक को सलाह दे दी है?

Good☐Poor☐

4. Is the Door Alignment / Gasket Sealing proper ?
क्या डोर एलाइनमेंट/गैसकेट सीलिंग ठीक है?

Yes☐No☐

5. Is the LED / Fan Motor functioning properly?
क्या एलई.डी./फैन मोटर ठीक काम कर रहे है?

Yes☐No☐

6. Has the Knob Thermostat / Knob Shutter function been explained?
क्या थर्मोस्टैट नोब/शटर नोब का कार्य समझा दिया है?

Yes☐No☐

7. Is the refrigerator cooling properly? (Freezer Zone / Refrigerator Zone)
क्या रेफ्रिजरेटर ठीक से ठंडा कर रहा है? (फ्रीजर जोन/रेफ्रिजरेटर जोन)

Yes☐No☐

8. Is any abnormal sound / noise from the refrigerator?
क्या रेफ्रिजरेटर से कोई असामान्य आवाज/शोर आ रहा है?

Yes☐No☐

9. Is the power supply socket where REFRIGERATOR is to be fixed connected to inverter
Connection, if not please communicate to customer to get it connected??
क्या पावर सप्लाय सोकेट जिस पर ग्राहक रेफ्रिजरेटर मलाने वाला है, इन्वर्टर जुड़ा है?
अगर ऐसा नहीं है तो कृपया कस्टमर को कनेक्ट करने के लिए बोलिए।

Yes☐No☐

10. Is cycle parts properly routed in machine room area?
क्या मशीन रूम में साइकिल पार्ट्स ठीक से रूट किये गये है?

Yes☐No☐

SAFETY PRECAUTIONS

1. Are safety precautions explained as per usage guidelines?
क्या प्रयोग के मार्ग-निर्देश के अनुसार सुरक्षा सावधानियाँ समझा दी गई हैं?

Yes☐No☐

USP (Unique Selling Point)

1. Is the Double twist Ice Tray function explained?
क्या डबल ट्विस्ट आइस ट्रे का कार्य समझा दिया है?

Yes☐No☐

2. Is the Cell Fresh Crisper function explained?
क्या सेल फ्रेश क्रिस्पर का कार्य समझा दिया है?

Yes☐No☐

3. Is the Star Rating concept explained?
क्या स्टार रेटिंग के सम्बन्ध में बता दिया है?

Yes☐No☐

4. If applicable, is the Stabilizer Free Operation explained? (Operating Voltage Range - 100-310V)
यदि लागू है, तो क्या बिज स्टैबिलाइजर के ऑपरेशन के सम्बन्ध में बता दिया है? (ऑपरेटिंग वोल्टेज रेंज - 100-310V)

Yes☐No☐

Installed by :.....

Signature :.....

Customer's Response

1. I / We are satisfied with the Demonstration / installation.

2. I certify that the above information & checks have been done to my Satisfaction level & I am fully satisfied with the installation Performance of the Refrigerator.

Customer's signature :.....Date :..... Time :.....

Remarks:

For Free Demo, Call Toll Free Number

08069379999 / 1800-315-9999 WhatsApp- 9711709999

SAFETY INSTRUCTIONS

Before beginning installation, read these instructions carefully.

WARNING

- To reduce the risk of explosion, fire, death, electric shock, injury or scalding to persons when using this product, follow basic precautions, including the following:

Technical Safety

- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety. Children should be supervised to ensure that they do not play with the appliance.
- This appliance is intended to be used in household and similar applications such as:
 - staff kitchen areas in shops, offices and other working environments;
 - farm houses and by clients in hotels, motels and other residential type environments;
 - bed and breakfast type environments;
 - catering and similar non-retail applications.

This symbol alerts you to flammable materials that can ignite and cause a fire if you do not take care.

- This appliance contains a small amount of isobutane refrigerant (R600a), but it is also combustible. When transporting and installing the appliance, care should be taken to ensure that no parts of the refrigerating circuit are damaged.
- The refrigerant and insulation blowing gas used in the appliance require special disposal procedures. Consult with service agent or a similarly qualified person before disposing of them.
- Do not damage the refrigerant circuit.
- If the power cord is damaged or the hole of the outlet socket is loose, do not use the power cord and contact an authorized service centre.
- Do not locate multiple portable outlet sockets or portable power supplies at the rear of the appliance.
- Securely plug the power plug in the outlet socket after completely removing any moisture and dust.
- Never unplug the appliance by pulling on the power cable. Always grip the power plug firmly and pull straight out from the outlet socket.
- Keep ventilation openings, in the appliance enclosure or in the builtin structure, clear of obstruction.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- Do not tilt the appliance to pull or push it when transporting.
- When positioning the appliance, ensure the supply cord is not trapped or damaged.
- Do not use mechanical devices or other means to accelerate the defrosting process.
- Do not use a hair drier to dry the inside of the appliance or place a candle inside to remove the odours.
- Do not use electrical appliances inside the food storage compartments of the appliance, unless they are of the type recommended by the manufacturer.
- Make sure not to get a body part such as a hand or foot stuck while moving the appliance.
- Disconnect the power cord before cleaning the appliance interior or exterior.
- Do not spray water or inflammable substances (toothpaste, alcohol, thinner, benzene, flammable liquid, abrasive, etc.) over the interior or exterior of the appliance to clean it.
- Do not clean the appliance with brushes, cloths or sponges with rough surfaces or which are made of metallic material.
- Only qualified service personnel from LG Electronics service centre should disassemble, repair, or modify the appliance. Contact an LG Electronics customer information centre if you move and install the appliance in a different location.

Risk of Fire and Flammable Materials

- If a leak is detected, avoid any naked flames or potential sources of ignition and air the room in which the appliance is standing for several minutes. In order to avoid the creation of a flammable gas air mixture if a leak in the refrigerating circuit occurs, the size of the room in which the appliance is used should correspond to the amount of refrigerant used. The room must be 1 m² in size for every 8 g of R600a refrigerant inside the appliance.
- Refrigerant leaking out of the pipes could ignite or cause an explosion.
- The amount of refrigerant in your particular appliance is shown on the identification plate inside the appliance.

Installation

- This appliance should only be transported by two or more people holding the appliance securely.
- Install the appliance on a firm and level floor.
- Do not install the appliance in a damp and dusty place. Do not install or store the appliance in any outdoor area, or any area that is subject to weathering conditions such as direct sunlight, wind, rain, or temperatures below freezing.
- Do not place the appliance in direct sunlight or expose it to the heat from heating appliances such as stoves or heaters.
- Be careful not to expose the rear of the appliance when installing.
- Install the appliance in a place where it is easy to unplug the power plug of the appliance.
- Be careful not to let the appliance door fall during assembly or disassembly.
- Be careful not to pinch, crush, or damage the power cable during assembly or disassembly of the appliance door.
- Be careful not to point the power plug up or let the appliance lean against the power plug.
- Do not connect a plug adapter or other accessories to the power plug.
- Do not modify or extend the power cable.
- Ensure that the outlet socket is properly grounded, and that the earth pin on the power cord is not damaged or removed from the power plug. For more details on grounding, inquire at an LG Electronics customer information centre.

- This appliance is equipped with a power cord having an equipment grounding conductor and a grounding power plug. The power plug must be plugged into an appropriate outlet socket that is installed and grounded in accordance with all local codes and ordinances.
- Never start up an appliance showing any signs of damage. If in doubt, consult your dealer.
- Dispose of all packaging materials (such as plastic bags and styrofoam) away from children. The packaging materials can cause suffocation.
- Do not plug the appliance into a multi socket adapter which does not have a power cable (mounted).
- The appliance should be connected to a dedicated power line which is separately fused.
- Do not use a multi socket outlet which is not properly grounded (portable). In case of using a properly-grounded multi socket outlet (portable), use the multi socket outlet with the current capacity of the power cord rating or higher and use the multi socket outlet only for the appliance.

Operation

- Do not use the appliance for any purpose (storage of medical or experimental materials or shipping) other than any domestic household food storage use.
- If water penetrates electrical parts of the appliance, disconnect power plug and contact an LG Electronics customer information centre.
- Unplug the power plug during a severe thunderstorm or lightning or when not in use for a long period of time.
- Do not touch the power plug or the appliance controls with wet hands.
- Do not bend the power cable excessively or place a heavy object on it.
- Immediately unplug the power plug and contact an LG Electronics customer information centre if you detect a strange sound, odour, or smoke coming from the appliance.
- Do not place hands or metallic objects inside the area emitting the cold air, cover or heat releasing grille on the back.
- Do not apply excessive force or impact to the back cover of the appliance.
- Be careful of nearby children when you open or close the appliance door. The door may bump the child and cause injury.
- Avoid the danger of children getting trapped inside the appliance. A child trapped inside the appliance can cause suffocation.

- Do not put animals, such as pets into the appliance.
- Do not place heavy or fragile objects, containers filled with liquid, combustible substances, flammable objects (such as candles, lamps, etc.), or heating devices (such as stoves, heaters, etc.) on the appliance.
- Do not place any electronic appliance (such as heater and mobile phone) inside the appliance.
- If there is a gas leakage (isobutane, propane, natural gas, etc.), do not touch the appliance or power plug and ventilate the area immediately. This appliance uses a refrigerant gas (isobutane, R600a). Although it uses a small amount of the gas, it is still combustible gas. Gas leakage during appliance transport, installation or operation can cause fire, explosion or injury if sparks are caused.
- Do not use or store flammable or combustible substances (ether, benzene, alcohol, chemical, LPG, combustible spray, insecticide, air freshener, cosmetics, etc.) near the appliance.
- This appliance incorporates an earth connection for functional purposes.
- Connect to potable water supply only.
 - If connected to a water supply, connect to a potable water supply only.
- Fill with potable water only.
 - If using an icemaker or dispenser water tank, make sure to fill it with potable water only.

Disposal

- When discarding the appliance, remove the door gasket while leaving the shelves and baskets in place and keep children away from the appliance.

CAUTION

- To reduce the risk of minor injury to persons, malfunction, or damage to the product or property when using this product, follow basic precautions, including the following:

Installation

- After unpacking, check the appliance for any damage that may have occurred during transit.
- Wait for at least 3 to 4 hours in order to ensure the refrigerant circuit is fully efficient.
- This appliance does not require changes in installation or use based on altitude.

Operation

- Do not touch frozen food or the metal parts in the freezer compartment with wet or damp hands. It may cause frostbite.
- Do not place glass containers, bottles or cans (especially those containing carbonated drinks) in the freezer compartment, shelves or ice bin that will be exposed to temperatures below freezing.
- The tempered glass on the front side of the appliance door or the shelves can be damaged by an impact. If it is broken, do not touch it with hands.
- Do not hang from the appliance doors, storage room, shelf or climb up into it.
- Do not store an excessive amount of water bottles or containers for side dishes on the door baskets.
- Do not open or close the appliance door with excessive force.
- If the hinge of the appliance door is damaged or operates improperly, stop using the appliance and contact an authorized service centre.
- Prevent animals from nibbling on the power cable or water hose.
- Never eat frozen foods immediately after they have been taken out in the freezer compartment.
- Make sure not to get a hand or foot stuck upon opening or closing the appliance door or door in door.

Maintenance

- This appliance is equipped with maintenance-free LED interior light. Do not remove cover or LED lamp in any attempt to repair or change it. Contact an LG Electronics customer information centre.
- Do not clean glass shelves or covers with warm water when they are cold. They may shatter if exposed to sudden temperature changes.
- Do not insert the shelves upside down. The shelves may fall.
- To remove frost from the appliance, contact an LG Electronics customer information centre.
- Dispose of the ice inside the ice bin in the freezer compartment during an extended power outage.

LG is working to create a sustainable tomorrow by publishing parts of this manual online only.

Searching Online Manual

This abridged owner's manual addresses user safety, operation, maintenance, and etc. information.

To view the complete owner's manual, scan the QR code on the label.

FRIDGE & FREEZER

Simple Manual

- Before beginning installation, read these instructions carefully. This will simplify installation and ensure that the product is installed correctly and safely. Leave these instructions near the product after installation for future reference.
- This manual may contain images or content that may be different from the model you purchased.
- This manual is subject to revision by the manufacturer.

MBM67547901
Rev.03_051225

Disposal of Your Old Appliance (as per e-waste Rules)



- When this crossed out wheeled bin symbol is depicted on the product and its operator's manual, it means the product is covered by E-Waste Management Rules India published by MoEF & CC , Govt. of India and are meant to be recycled, dismantled, refurbished or disposed off.

- Do's
 - a. The product is required to be handed over only to the authorized recycler for disposal.
 - b. Keep the product in isolated area, after it becomes non-functional/unrepairable so as to prevent its accidental breakage.

Don'ts

- a. The product should not be opened by the user himself/herself, but only by authorized service personnel.
- b. The product is not meant for re-sale to any unauthorized agencies/scrap dealer/ kabariwala.
- c. The product is not meant for mixing into household waste stream.
- d. Do not keep any replaced spare part(s) from the product in exposed area.

- Any disposal through unauthorized agencies/person will attract action under Environment (Protection) Act 1986.

- Hazards of improper handling or accidental breakage :
 - a. The refrigerant (R134a) used, if overexposed, might cause dizziness and loss of concentration. Liquid contact can cause irritation and frostbite. The refrigerant (R600a), squirting out of the pipes could ignite or cause eye injury.
 - b. The blowing agent cyclopentane is highly flammable liquid and vapor. Harmful to aquatic life. Contact with liquid may cause cold burns/frost bites. Repeated exposure causes skin dryness.

- This product is complied with the requirement of Hazardous Substances as specified under E-Waste Management Rules India published by MoEF & CC , Govt. of India.
- To locate a nearest collection centre or call for pick-up (limited area only) for disposal of this appliance, please contact No. 08069379999, Toll Free No. 1800-315-9999 for details. All collection centre and pick up facilities are done by third parties with LG Electronics India Ltd. Merely as a facilitator. For more detailed information, please visit : <http://www.lg.com/in>.

LG Electronics India Ltd.

Phone	1800 315 9999 (Toll Free), 08069379999 24 hours, 7 days a week (except for national holidays)
WhatsApp No.	9711709999
Mobile Application	'LG Service India Mobile App' available at Google Play
SNS	www.facebook.com/LGIndiaPage www.twitter.com/LGIndia
Address	Regd. Office: LG Electronics India Ltd., A-24/6 Mohan Cooperative Industrial Estate, Mathura Road, New Delhi-110044 CIN No. U32107DL1997PLC220109

अपने पुराने उपकरण का निपटान (उत्पाद ई-अपशिष्ट के अनुसार)



- जब इस काटे गए पहिये वाले बिन का चिन्ह किसी उपकरण और इसके ऑपरेटर की पुस्तिका के साथ संलग्न होता है तो इसका मतलब है कि इसे "ई-अपशिष्ट" (प्रबंधन और हथालन) नियम के अंतर्गत सम्भालित किया गया है, और इसे नवीनीकरण, विघटन और निपटारण के लिए बनाया गया है। MoEF & CC भारत सरकार द्वारा प्रकाशित (भारतीय "ई-अपशिष्ट" (प्रबंधन और हथालन))

कई

क उपकरण को विश्व अधिकृत पुनः नवीनीकरणकर्ता को ही निपटारण करने हेतु हस्तांतरित करें।

ख जब उपकरण कार्यरत न हो इसे अलग क्षेत्र में रखें ताकि उपकरण से होने वाली दुर्घटनाओं से बचा जा सके।

या कई

क इस उपकरण को खराब/खुद नहीं खोलना चाहिए। उपकरण को केवल अधिकृत अधिकारी के द्वारा ही खोला जाना चाहिए।

ख इस उपकरण को पुनः चिह्न के लिए किसी भी कबाड़ीवाला/ भंगारवाला/अनाधिकृत संस्था को न दें।

ग इस उपकरण को किसी फोर्कलैफ्ट/अपशिष्ट सामन के साथ मिलाकर न रखें।

घ उपकरण के बदले हुए या आंतरिक पुर्जों को खुले क्षेत्र में न रखें।

च यदि किसी अनाधिकृत विभाग या व्यक्ति के द्वारा निपटारण किया जाता है तो यह पर्यावरण (सुरक्षा) धारा 1986 के अंतर्गत आता है।

4. दुर्घटनाग्रस्त टूट-फूट तथा अव्यवस्थित रख-रखाव से बचाव :

क रेफ्रिजरेट (R134a) यदि संपर्क में अधिक आता है तो, घक्कर आना व एकाग्रता में बाधा उत्पन्न हो सकती है, तरल पदार्थ का स्तंभा संपर्क, श्वेतदंश व जलन का कारण हो सकता है। इसी प्रकार रेफ्रिजरेट (R600a) का पाइपों से रिसाव होने से आग लग सकती है तथा आँखों की खरब हो सकती है।

ख साइकलोपेंटन अत्यंत ज्वलनशील तरल व वाष्पीय होने के कारण उद्दित जीवन के लिए काफी नुकसानदेह हो सकता है। तरल पदार्थ के संपर्क में आने पर ठंडी जलन तथा बार-बार संपर्क में आने से त्वचा सूख हो सकती है।

5. यह उत्पाद ई-अपशिष्ट (प्रबंधन और हथालन) नियम के तहत निर्दिष्ट खतरनाक पदार्थों की आवश्यकता का पालन करता है। MoEF & CC भारत सरकार द्वारा प्रकाशित (भारतीय "ई-अपशिष्ट" (प्रबंधन और हथालन))

6. उपरोक्त पदार्थों के निपटारण के लिए नवीनीकी निपटारण संस्थान (संकीर्ण क्षेत्र) में कोल करें। अधिक जानकारी के लिए हमारे टेलीफोन नंबर 08069379999 / टोल फ्री नंबर 1800-315-9999 पर कोल करें। सभी संछान केंद्र व फिस-अप की सुविधाएँ किसी चर्ब पार्टी जो LG Electronics India Ltd. को अपनी सेवाएँ प्रदान कर रही हों, से कराएँ। ज्यादा जानकारी के लिए देखें वेब साइट : <http://www.lg.com/in>

Brand Owner (LG Electronics India Ltd.) & Packaging Type Details as per PWM Rules

Packaging type	Company name	Registration number	Thickness
Plastic Sheet	LG Electronics India Ltd	BO-13-000-07-AAACL1745Q-22	0.05 mm and above
Multilayered bag	LG Electronics India Ltd		N/A

Warranty and Service Information

Warranty and Service Information

The LG Refrigerator (hereinafter referred as product) comes with 1 year warranty on all Parts (except Consumables, Bulb, Loose Plastic Parts, Glass) in the first year from the date of purchase on producing the tax paid invoice provided always that the warranty card bears the rubber stamp, date and signature of our Authorized Dealer showing the Additional warranty on compressor as specified below shall be on fulfilling the above mentioned conditions.

9 (SELECTED MODEL) YEAR ADDITIONAL WARRANTY ON COMPRESSOR

The 9 Year warranty (Selected Model) on Compressor will continue even after expiry of 1 year period from the date of purchase. This warranty covers Compressor only. Gas Charging related gas and applicable service charges will be charged to the customer. During the additional warranty period, it does not cover any part such as PCB assembly, condenser, freezer, capillary, suction line, overload protector, relay, thermostat etc., standard service charges will be applicable within the municipal limit of town where LG Electronics India Ltd. (LGEIL) has its Authorized Service center, service outside municipal limit will attract to and fro traveling, other incidental expenses in addition to standard service charges, as prevailing from time to time.

TERMS & CONDITIONS

- The warranty is confined to the first purchaser of the Refrigerator only & is non-transferable.

- Repairs & replacements will be carried out by the dealer from whom the product has been purchased, or through the Authorized Service Centers of LG Electronics. In case the customer shifts the place of residence during warranty period, it is advised to contact Authorized Service Centre directly or call our help line.

- Repairs under warranty shall be carried out by an authorized service personnel only. The details of centralized help lines are attached.

- For units installed beyond municipal limits of the jurisdiction of company's Authorized Service Center, it is responsibility of the purchaser to contact the nearest authorized service center and bring the unit to the authorized service center at its own cost and risk. All expenses incurred in collecting the units or parts thereof from the company's authorized service center, as well as expenses incurred with deputing of service personnel/technicians towards conveyance and other incidentals etc. will be borne by the customer. Local charges for transportation and handling charges may vary from location to location. Customers are advised to verify before. In case the customer desires to bring the unit on its own to the Authorized Service Centre, the same shall be at its own risks & consequences.

- The concerned authorized service center will advise the customer whether to effect the repairs at site or at the authorized service center.

- Call registered with the centralized helpline/Authorized service center, wherein only cleaning of the unit/parts in the unit due to dust accumulation on portions of the unit, general explanations/returning, are not to be considered as defects.

- In case of repairs or replacement of any part/s of the unit, this warranty will thereafter continue and remain in force only for the unexpired period of the warranty. Replacement of parts would be purely at the discretion of LGEIL alone. In case the replacement of the entire unit is being made, (subject to the sole discretion of LGEIL), the same model shall be replaced and in the event such model has been discontinued, it shall be replaced with the model of price equivalent at the time of purchase.

- In case of any damage to the product / customer abuse/ repairs by un-authorized personnel/ misuse detected/ by the Authorized Service Center personnel, the warranty conditions are not applicable and repairs will be done subject to availability of parts and on a chargeable basis only.

- This warranty shall not cover any consequential or resulting liability, damage or loss to property or life arising directly or indirectly out of any defect in the Refrigerator. The company's obligation under this warranty shall be limited to repair or providing replacement of defective parts only under the warranty period.

- The company or its Authorized Service Center reserves the right to retain any part/s or component replaced at its discretion, in the event of a defect being noticed in the equipment during warranty period.

- While the company will make every effort to carry out repairs at the earliest, it however is made expressly clear that the company is under no obligation to do so in a specified period of time.

- In the event of any unforeseen circumstance, and spares not being available, the company's prevailing depreciation rules may apply on the purchaser to accept as a commercial solution in lieu of repairs.

- Warranty does not cover accessories external to the equipment supplied by the dealer.

- If any coloured internal or external components are replaced, there will be commitment to ensure that the shades match with the original or other components. The replaced shades, patterns, tints may vary from the customer's unit due to continuous usage of the unit. Any matching components changed at customer's request will be on chargeable basis except the component which actually needed.

- Free Installation or Demo of the product, can be availed only once & within 3 months from the date of purchase.

- Any extended warranty offered by LGEIL has to be supported by relevant proof.

- This warranty will automatically terminate on the expiry of the warranty period of 12 months, even if the Refrigerator may not be in use for any time during the warranty period for any reason. The warranty on compressor will automatically terminate on expiry of 9*(Selected Model) years (after 1 year warranty period) even if the Refrigerator may not be in use for any time during the said period for any reason.

- Only courts in state of Delhi and places where LGEIL has its branch office shall have the jurisdiction for settling any claims, disputes arising under the warranty.

Warranty is not applicable in any of the following cases :

- The warranty card is not completed properly at the time of purchase.
- The completed warranty card is not presented to authorized service personnel at the time of service of the product.
- The product is not operated according to instructions given in the Operating Instruction Booklet.
- The product is used for commercial purposes.
- The product has failed under certain conditions like water logging, flood, fire, misuse etc.
- Defects are caused by improper or reckless use, which shall be determined by the company personnel.
- Any repair work is carried out by persons other than authorized service personnel.
- Defects are caused by due to causes beyond control like lightening, abnormal voltage, acts of God or while in transit to service center or purchaser's residence.
- Any issue is caused by usage of 3rd party product like voltage stabilizer, power outlet socket, MCB, extension board etc.
- Defects/malfunction caused while in transit to service centre or purchaser's residence.
- Defects caused by rodents bite or by pests and vermin ants/Insects/animals/birds etc.
- The warranty is not valid in case, the serial number is deleted, defected or altered.
- Damage to the product or any part/s due to transportation or shifting is not covered by warranty.
- Use of knife or sharp instrument is used to remove the ice trays or Ice from the freezer or to remove the frost mechanically and as a result Compressor, Evaporator, Condensers, capillary, suction line & other related items get spoiled.
- Any accessory external to the equipment are supplied by dealer or LG.
- Any issue of Wi-Fi connectivity or compatibility with other products or software's is there.
- Any loss of data.

CUSTOMER'S COPY

CUSTOMER'S COPY	
MODEL No. : UNIT SERIAL No. :	DATE OF PURCHASE :
CUSTOMER'S NAME & ADDRESS _____ _____ TEL. _____	DEALER'S NAME & ADDRESS _____ _____ TEL. _____
Customer's Signature	Dealer's Signature

This card is valid only if it is filled in and stamped by our authorised dealer on the date of purchase.

Installation / Demo Report

FF

ASC Copy

Customer's Name :	Telephone No.
Address :	
Model / Serial No. :	Comp.No.
Installation Check Point	
M/C Delivered on:	M/c Installed on:

To be filled by Installation (Service Engineer)

CONTROL & ADJUSTMENT	Yes	No
1. Refrigerator kept in ventilated area? क्या रेफ्रिजरेटर वायु प्रवाहित स्थान पर रखा हुआ है?	☐	☐
2. Has Leg Adjustment / Leveling of Refrigerator being done? क्या रेफ्रिजरेटर की टाँग व्यवस्था / स्तर सैट कर दिया गया है?	☐	☐
3. If the Condition of Voltage / Earthing / Plug Point are poor, has customer been advised? यदि वोल्टेज स्थिति/अर्थिंग/प्लग प्वाइंट खराब है तो क्या उनके बारे में ग्राहक को सलाह दे दी है?	Good ☐	Poor ☐
4. Is the Door Alignment / Gasket Sealing proper ? क्या डोर एलाइन्मेंट/गैसकेट सीलिंग ठीक है?	☐	☐
5. Is the LED / Fan Motor functioning properly? क्या एल.ई.डी./फैन मोटर ठीक काम कर रहे हैं?	☐	☐
6. Has the Knob Thermostat / Knob Shutter function been explained? क्या थर्मोस्टैट नोब/शटर नोब का कार्य समझा दिया है?	☐	☐
7. Is the refrigerator cooling properly? (Freezer Zone / Refrigerator Zone) क्या रेफ्रिजरेटर ठीक से ठंडा कर रहा है? (फ्रीजर ज़ोन/रेफ्रिजरेटर ज़ोन)	☐	☐
8. Is any abnormal sound / noise from the refrigerator? क्या रेफ्रिजरेटर से कोई असामान्य आवाज/शोर आ रहा है?	☐	☐
9. Is the power supply socket where REFRIGERATOR is to be fixed connected to inverter Connection, if not please communicate to customer to get it connected?? क्या पावर सप्लाय सॉकेट जहाँ रेफ्रिजरेटर लगाया जाना है, इन्वर्टर जुड़ा है? अगर ऐसा नहीं है तो कृपया कस्टमर को कनेक्ट करने के लिए बोलिए।	☐	☐
10. Is cycle parts properly routed in machine room area? क्या मशीन रूम में साइकिल पार्ट्स ठीक से रूट किये गये हैं?	☐	☐
SAFETY PRECAUTIONS		
1. Are safety precautions explained as per usage guidelines? क्या प्रयोग के मार्ग-निर्देश के अनुसार सुरक्षा सावधानियाँ समझा दी गई हैं?	☐	☐
USP (Unique Selling Point)		
1. Is the Double twist Ice Tray function explained? क्या डबल ट्विस्ट आइस ट्रे का कार्य समझा दिया है?	☐	☐
2. Is the Cell Fresh Crisper function explained? क्या सेल फ्रेश क्रिस्पर का कार्य समझा दिया है?	☐	☐
3. Is the Star Rating concept explained? क्या स्टार रेटिंग के सम्बन्ध में बता दिया है?	☐	☐
4. If applicable, is the Stabilizer Free Operation explained? (Operating Voltage Range - 100-310V) यदि लागू है, तो क्या स्टाबलाइजर के ऑपरेशन के सम्बन्ध में बता दिया है? (ऑपरेटिंग वोल्टेज रेंज - 100-310V)	☐	☐

Installed by :

Signature :

Customer's Response

- I / We are satisfied with the Demonstration / installation.
- I certify that the above information & checks have been done to my Satisfaction level & I am fully satisfied with the installation Performance of the Refrigerator.

Customer's signature :Date : Time :

Remarks:

For Free Demo, Call Toll Free Number
☎ 08069379999 / 1800-315-9999 📞 WhatsApp- 9711709999

ASC STAMP