









<div><div>ColorFit Pro 6 Max</div><div>Please refer to this user manual before using the product</div></div>	<div><div>TABLE OF CONTENT</div><div><ul style="list-style-type: none">• What's in the Box• Watch Overview• Charging the Watch• Turning the Watch On and Off• Watch Navigation• Side Button• Home Screen Navigation• Setup• App Setup• Pairing the Watch• Watch Features• Device Information and Tips• Disposal and Recycling Information• Regulatory Information• Maintenance Instructions• Safety Instructions• Customer Support</div></div> <div>User Manual for ColorFit Pro 6 Max</div>	<div><div>WATCH OVERVIEW</div><div><ul style="list-style-type: none">• Noise Health• Noise Buzz• Workouts• Sports Records• Clock• Weather• Music Control• Remote Camera• Water Intake Record and Reminders• Calculator• Voice Command• Voice Memo• Event Reminder• Compass• Find my Phone• Bluetooth Headset• Settings• Games• BBC News</div></div> <div><div>PACKAGE CONTAINS</div><div><div>ColorFit Pro 6 Max Smartwatch x 1</div><div>Charging Cable x 1</div></div></div> <div>User Manual for ColorFit Pro 6 Max01</div>	<div><div>USING THE COLORFIT PRO 6 MAX SMARTWATCH</div><div><p>Before using your ColorFit Pro 6 Max for the first time, charge the battery to its full capacity. Use the charging cable provided with the watch to charge. On a single charge, ColorFit Pro 6 Max can last up to 7 days. Note: The battery life and time to fully charge your device may vary as per usage and other factors.</p><p>CHARGING COLORFIT PRO 6 MAX SMARTWATCH</p><ul style="list-style-type: none">• Plug the USB cable into a power adaptor. Plug the power adaptor into an electrical socket. (Power adaptor not included).• Place the magnetic charger on the magnetic charging points of the watch.• While your watch is charging, the screen will show its progress.• Once the battery is fully charged, remove the charger.</div></div> <div><div>ColorFit Pro 6 Max Smartwatch x 1</div><div>Charging Cable x 1</div></div> <div>User Manual for ColorFit Pro 6 Max02</div>	<div><div>POWER ON</div><div><ul style="list-style-type: none">• Press the side button for a few seconds to turn on the watch.</div></div> <div><div>POWER OFF</div><div><ul style="list-style-type: none">• Press and hold the side button for 4-5 seconds.• Select 'Power off'</div></div> <div><div>WAKING UP THE WATCH</div><div><p>To preserve the battery, the watch screen turns off when not in use. To turn the screen back on by:</p><ul style="list-style-type: none">-Pressing side button-Turning on the 'Wrist Sense'</div></div> <div><div>ColorFit Pro 6 Max Smartwatch x 1</div><div>Charging Cable x 1</div></div> <div>User Manual for ColorFit Pro 6 Max03</div>	<div><div>WATCH NAVIGATION</div><div><p>The ColorFit Pro 6 Max smartwatch has an AMOLED touch screen. Navigate the watch by tapping on the screen, swiping side to side, up and down, and pressing the side button.</p></div></div> <div><div>SIDE BUTTON NAVIGATION</div><div><ul style="list-style-type: none">• Press the side button to turn on the watch display.</div></div> <div><div>HOME SCREEN NAVIGATION</div><div><p>The home screen is the watch face. From the home screen:</p><ul style="list-style-type: none">• Swipe left to access widgets.• Swipe right to access shortcut screens.• Swipe up to access quick settings.• Swipe down to access notifications.</div></div> <div><div>ColorFit Pro 6 Max Smartwatch x 1</div><div>Charging Cable x 1</div></div> <div>User Manual for ColorFit Pro 6 Max04</div>	<div><div>APP SETUP</div><div><p>Before pairing, make sure that your smartphone and smartwatch are next to each other. The app will ask for personal information such as height, weight and sex to calculate your stride length, distance covered and calorie burn rate and metabolic rate. When you set up your account, your name & profile picture will be visible to other users.</p><ul style="list-style-type: none">• Turn on Bluetooth and the location on your mobile device.• On your smartphone, download the NoiseFit app from the Play store or the App store and install it.• Create an account or log in using an existing account.<p>Note: Ensure that your smartphone is running on Android 9.0 & + or iOS 11.0 & + and is connected to mobile data or a Wi-Fi network.</p></div></div> <div><div>PAIR THE WATCH</div><div><ul style="list-style-type: none">• Open the NoiseFit app and allow the Bluetooth and GPS positioning.• Feed in your personal information and health goals in the app.• Go to the 'Device' section in the app, tap on 'Add Device' then 'Search'. Select ColorFit Pro 6 Max and link the watch.</div></div> <div>User Manual for ColorFit Pro 6 Max05</div>	<div><div>WATCH FEATURES</div><div><div>NOISE HEALTH</div><div><p>Activity Records</p><p>You can check your daily activity progress in terms of steps taken, distance covered, and calories burned.</p><p>Heart Rate</p><p>ColorFit Pro 6 Max supports 24/7 heart rate tracking. You can select the measurement frequency in app settings. To measure your heart rate go to 'Heart rate monitor'. Ensure that there is no gap between the back panel of the watch and the wrist. Hold still while it measures your heart rate.</p><p>SPO2</p><p>ColorFit Pro 6 Max supports viewing the highest and lowest values of blood oxygen levels throughout the day. Ensure that there is no gap between the back panel of the watch and the wrist. Hold still while it measures your blood oxygen level.</p><p>Sleep</p><p>Tap on 'Sleep' to view your previous sleep records. You can view your most recent sleep records and sleep quality in various sleep stages on the NoiseFit app.</p><p>Breathing Exercise</p><p>This feature helps you adjust your breathing rhythm as per your convenience.</p></div></div><div><div>Stress</div><div><p>You can choose from 3 speeds (fast, moderate and slow) to adjust your breathing duration. After the session you can also see the change in beats per minute. Go to the 'Breathr' feature and choose the time duration and speed. Tap on 'start' to enter the cycles of breathing and inhalation. During this period, if you swipe right or press a button, breathing is interrupted. You can choose to practice again or complete the cycle.</p></div></div><div><div>Stress</div><div><p>You can choose from 3 speeds (fast, moderate and slow) to adjust your breathing duration. After the session you can also see the change in beats per minute. Go to the 'Breathr' feature and choose the time duration and speed. Tap on 'start' to enter the cycles of breathing and inhalation. During this period, if you swipe right or press a button, breathing is interrupted. You can choose to practice again or complete the cycle.</p></div></div><div>User Manual for ColorFit Pro 6 Max06</div></div>	<div><div>Stress</div><div><p>You can choose from 3 speeds (fast, moderate and slow) to adjust your breathing duration. After the session you can also see the change in beats per minute. Go to the 'Breathr' feature and choose the time duration and speed. Tap on 'start' to enter the cycles of breathing and inhalation. During this period, if you swipe right or press a button, breathing is interrupted. You can choose to practice again or complete the cycle.</p></div></div> <div><div>Stress</div><div><p>You can choose from 3 speeds (fast, moderate and slow) to adjust your breathing duration. After the session you can also see the change in beats per minute. Go to the 'Breathr' feature and choose the time duration and speed. Tap on 'start' to enter the cycles of breathing and inhalation. During this period, if you swipe right or press a button, breathing is interrupted. You can choose to practice again or complete the cycle.</p></div></div> <div>User Manual for ColorFit Pro 6 Max07</div>	<div><div>Stress</div><div><p>You can choose from 3 speeds (fast, moderate and slow) to adjust your breathing duration. After the session you can also see the change in beats per minute. Go to the 'Breathr' feature and choose the time duration and speed. Tap on 'start' to enter the cycles of breathing and inhalation. During this period, if you swipe right or press a button, breathing is interrupted. You can choose to practice again or complete the cycle.</p></div></div> <div><div>Stress</div><div><p>You can choose from 3 speeds (fast, moderate and slow) to adjust your breathing duration. After the session you can also see the change in beats per minute. Go to the 'Breathr' feature and choose the time duration and speed. Tap on 'start' to enter the cycles of breathing and inhalation. During this period, if you swipe right or press a button, breathing is interrupted. You can choose to practice again or complete the cycle.</p></div></div> <div>User Manual for ColorFit Pro 6 Max08</div>
--	--	--	---	--	--	---	--	---	---

<div><div>REMOTE CAMERA</div><div><p>You can use this feature to use the smartwatch to click pictures from the phone remotely.</p></div></div> <div><div>DRINK WATER</div><div><p>Set your daily hydration target and set reminders for water intake.</p></div></div> <div><div>CALCULATOR</div><div><p>You can use this feature to do basic calculations.</p></div></div> <div><div>VOICE COMMAND</div><div><p>Use this feature to activate voice assistance and give commands.</p></div></div> <div><div>VOICE MEMO</div><div><p>Record anything you need.</p></div></div> <div><div>EVENT REMINDER</div><div><p>Set reminders for important events.</p></div></div> <div><div>COMPASS</div><div><p>Navigate and find out directions.</p></div></div> <div><div>FLASHLIGHT</div><div><p>You can use this feature to turn on the screen brightness and see your surroundings better. Go to the Flashlight. Tap to turn on.</p></div></div> <div><div>FIND MY PHONE</div><div><p>Use this feature to find your mobile device by making it ring. Just tap on 'Find my phone', and your phone will start to ring, even if it is on Silent mode.</p></div></div> <div>User Manual for ColorFit Pro 6 Max09</div>	<div><div>BLUETOOTH HEADSET</div><div><p>Pair your earbuds/headphone device from here.</p></div></div> <div><div>ALARM CLOCK</div><div><p>You can set an alarm from the NoiseFit app.</p></div></div> <div><div>STOPWATCH</div><div><p>A stopwatch can be set on the smartwatch. You can also set lap times on the stopwatch.</p></div></div> <div><div>TIMER</div><div><p>You can set a countdown with a pre-set duration on the watch or set your own timer. The watch will remind you when the time is up. Go to 'Clock', select 'Timer' and set it as per your requirement.</p></div></div> <div><div>SETTINGS</div><div><p>Watch face and home screen</p><p>You can switch between different watch faces. Choose and download cloud-based watch faces or create custom watch faces using the NoiseFit app.</p><p>Watch Faces</p><p>Give your screen a personalised style by changing or customising the watch face from the NoiseFit app or the watch.</p><p>On the Watch</p><p>Touch and hold the home screen. Swipe and choose from the watch faces.</p></div></div> <div>User Manual for ColorFit Pro 6 Max10</div>	<div><div>Always on Display</div><div><p>You can turn on the 'Always on Display' feature.</p></div></div> <div><div>Home Screen</div><div><p>Choose the appearance of the icons on the home screen</p></div></div> <div><div>Display and Brightness</div><div><p>Set the duration for your screen time starting from 5 sec to always-on. Enable or disable raise to wake. double-tap to light up the screen, cover the rest screen from here.</p></div></div> <div><div>Sound & Vibration</div><div><p>Ringtone Settings</p><p>Set the ringtone level as per your preference</p><p>DND</p><p>You can choose to turn on the DND</p><p>Silent Mode</p><p>Choose to turn it on or off</p><p>Vibration Intensity</p><p>Choose from none, weak or strong</p></div></div> <div>User Manual for ColorFit Pro 6 Max11</div>	<div><div>Preferences</div><div><p>Wrist detection lock</p><p>Turn it on to automatically lock the watch when it detects it's not your wrist.</p><p>Exercise settings</p><p>Select exercise prompt volume, enable or disable screen lit always and auto exercise recognition.</p><p>Custom key</p><p>Choose the function for the custom key (the one below the dial) from here.</p><p>Custom card</p><p>Select the widgets you want to be shown when you swipe right on the home screen.</p><p>Quick gestures</p><p>Enable or disable shake wrist to ignore incoming calls or messages. Get a tutorial for gesture controls and read the gesture control.</p><p>Sleep mode</p><p>Turn sleep mode on or off and schedule its activation from here.</p><p>Wear</p><p>Make your step counts and exercise stats more accurate when you select the wrist from here.</p></div></div> <div>User Manual for ColorFit Pro 6 Max12</div>	<div><div>Energy Saving Mode</div><div><p>Enter the energy-saving mode from here.</p></div></div> <div><div>SOS Call</div><div><p>Enable SOS call from here. In times of need, when you press the side button thrice, it will place an SOS call.</p></div></div> <div><div>OS & Update</div><div><p>Firmware Update</p><p>Check for updates from here</p><p>Power off</p><p>Reboot</p><p>Connect to a new phone</p><p>Factory reset</p><p>ABOUT</p><p>Check device name, bluetooth name, version number, model and other additional information about your device.</p><p>GAMES</p><p>Choose to play from Pixel Bird or Whack-A-Mole.</p><p>BBC NEWS</p><p>Stay updated with what's happening around the world.</p></div></div> <div>User Manual for ColorFit Pro 6 Max13</div>	<div><div>DEVICE INFORMATION AND TIPS</div><div><p>DEVICE INFORMATION</p><p>The ColorFit Pro 6 Max smartwatch contains the following:</p><ul style="list-style-type: none">• 1.96" AMOLED display• 22mm strap• 5 ATM water resistance• Blood oxygen monitor• Heart rate monitor<p>The ColorFit Pro 6 Max smartwatch stores your activity data for up to 7 days between the time you sync your watch to the NoiseFit app. Activity data includes your steps, distance, calories, active minutes, heart rate, sleep duration and workout data. We recommend syncing the watch to the app daily.</p><p>How do I update my ColorFit Pro 6 Max?</p><ul style="list-style-type: none">• Go to 'My Profile' (the icon on the top left corner of the home page) on the NoiseFit App• Select 'About'• Choose 'Check for Updates'• Update if it's available</div></div> <div>User Manual for ColorFit Pro 6 Max14</div>	<div><div>How do I find my watch's current firmware version?</div><div><p>You can log in your weight the first time you set up your NoiseFit app. However, you can update the weight later via the NoiseFit app. Go to 'Me', and tap on the section with your name on it to update your weight. You can update your nickname, birthday, sex and height as well.</p></div></div> <div><div>How does the watch estimate how many calories have been burned?</div><div><p>NoiseFit ColorFit Pro 6 Max estimates how many calories you've burned based on the physical activity data and your heart rate.</p></div></div> <div><div>How do I change my activity goals?</div><div><p>You can do it through the NoiseFit app. Go to 'My Profile', Go to 'Setup' and select 'My Objectives'. Change your goals and confirm.</p></div></div> <div>User Manual for ColorFit Pro 6 Max15</div>	<div><div>Disposal and Recycling Information</div><div><p>Electrical and electronic devices may not be disposed off with domestic waste. Consumers are obliged by law to return the electrical and electronic devices at the end of their service lives to the public collection points set up for this purpose or point of sale. Details of this are defined by the national law of the respective country. By recycling, reusing materials or other forms of utilizing old devices, you are making an important contribution to protecting our environment.</p><p>Regulatory Information</p><p>USA: Federal Communications Commission (FCC) Statement</p><p>This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions:</p><p>This device may cause harmful interference, and this device must accept any interference received, including interference that may cause undesired operation.</p><p>Warning: Changes or modifications not expressly Approved by the party responsible for compliance could void the user's authority to operate the equipment.</p><p>Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.</p></div></div> <div>User Manual for ColorFit Pro 6 Max16</div>	<div><div>If this 76 equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:</div><div><ul style="list-style-type: none">• Reorient or relocate the receiving antenna.• Increase the separation between the equipment and the receiver.• Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.• Consult the dealer or an experienced radio/TV technician for help.</div></div> <div><div>The NoiseFit ColorFit Pro 6 Max Watch is not a toy. The watch contains small components that could be a choking hazard and are not intended for use by small children or pets. Unless otherwise specified, devices and services are not medical devices and are not intended to diagnose, treat, cure or prevent any disease. We develop products and services to track daily activity and wellness information as accurately as possible. The accuracy of devices is not intended to be equivalent to medical devices or scientific measurement devices.</div><div><p>In some cases, prolonged use of products may cause skin irritation. Prolonged contact may contribute to skin irritation or allergies in some users. To reduce the possibility of irritation, keep the watch and watch band clean and dry. Don't wear it too tight and give your wrist a rest by removing the watch after an extended period of wear. If you feel soreness, tingling, numbness, burning or stiffness in your hands or wrists while or after wearing the watch, please immediately discontinue use.</p></div></div> <div>User Manual for ColorFit Pro 6 Max17</div>	<div><div>Maintenance Instructions:</div><div><ul style="list-style-type: none">• Keep the device dry and clean regularly especially after prolonged use as moisture and dirt can build up underneath the band and can cause skin irritation.• Do not wear the device too tight but make sure that the bottom sensor is lightly in contact with your skin and that there is a gap of about one finger's width between the wrist strap and your wrist.• Do not use household cleaners to clean the device. Use soap-free cleaners instead.• For stains that are difficult to remove, it is recommended to scrub with alcohol.• The device is not suitable for diving, swimming in the sea or sauna; it is suitable for swimming pool, shower (cold water) and swimming in shallows.• Keep it away from direct sunlight, high temperatures or humid conditions as it may damage the band over time.</div></div> <div><div>Safety Instructions</div><div><ul style="list-style-type: none">• Do not disassemble the battery on your own.• Do not expose NoiseFit ColorFit Pro 6 Max to extremely high or low temperatures. Excessive temperature during charging could cause heat, smoke, fire or deformation of the battery or even explosion.• Charge the battery in a cool, ventilated room.• Do not open, crush, bend, deform, puncture or shred secondary cells or batteries. In the event of a battery break or leak, prevent battery liquid contact with skin or eyes. If this happens, immediately flush the areas with water or seek medical help (DO NOT RUB THE EYE).</div></div> <div>User Manual for ColorFit Pro 6 Max18</div>	<div><div>Short-circuits may damage the battery. It can occur when a metallic object, such as a coin, causes the direct connection of positive and negative terminals of the battery.</div><div><ul style="list-style-type: none">• Keep the batteries out of children's reach and in a safe place to prevent danger.• Do not place the batteries in the water.• Do not use your product in a sauna or steam room.• Do not dispose off batteries in the fire as that may cause an explosion. Dispose off used batteries in accordance with your local regulations. Do not dispose it as household waste.• Use only the charging cable supplied to charge the battery. Do not charge for more than 24 hours.• Do not attempt to repair or maintain the watch yourself. Service and maintenance should be performed by authorised technicians only. Any device failure should be referred to our after-sales service personnel.• To prevent device damage, accessory damage and device failure, always protect the device against strong impact or shock.</div></div> <div><div>CUSTOMER SUPPORT</div><div><p>If you experience any problem with the watch, it may be fixed by restarting your watch. For any assistance, please reach out to us at support.gonoise.com</p></div></div> <div>User Manual for ColorFit Pro 6 Max19</div>
---	--	---	---	--	--	--	---	---	---	---