

Wireless Stereo Headset

Беспроводная стереофоническая гарнитура

Reference Guide
参考指南








참고 설명서
Справочник

https://rd1.sony.net/help/mdr/wfb700/h_zz/

WF-XB700



©2020 Sony Corporation
Printed in Vietnam
<https://www.sony.net/>



Note on static electricity
Static electricity accumulated in the body may cause mild tingling in your ears. To reduce the effect, wear clothes made from natural materials, which suppress the generation of static electricity.

Complies with
IMDA Standards
DB00353

Precautions

On splash proof performance of the unit

- The charging case is not splash proof.
- The splash proof specifications of this unit are equivalent to class II of the IPX4 standard of protection against ingress of water (IP Code), which specifies the degree of protection provided against the entry of water. The unit cannot be used in water. Unless the unit is used correctly, water may get into the unit and cause fire, electrocution, or malfunctions.
- Note the following cautions carefully and use the unit correctly.
IPX4: Protected against water splashing from any direction.

Liquids that the splash proof performance specifications apply to

Applicable: Fresh water, tap water, perspiration

Not applicable: Liquids other than those above (examples: soapy water, detergent water, water with bath agents, shampoo, hot spring water, pool water, seawater, etc.)

The splash proof performance of the unit is based on measurements performed by Sony under the conditions described above. Note that malfunctions resulting from water immersion caused by customer misuse are not covered by the warranty.

To maintain splash proof performance Carefully note the precautions below to ensure proper use of the unit.

- Do not wash the power bank when it has been wet or otherwise damaged, to prevent against electric shock, explosion and/or injury. Contact the dealer or authorized agent.
- Do not drop the power bank or subject it to mechanical shock such as crushing, bending, puncturing or shredding. Avoid dropping or placing heavy object on the power bank.
- Do not short-circuit the power bank or store it in a receptacle where it may be short-circuited by other metallic conductive objects.
- Do not damage the power bank if it has been wet or otherwise damaged, to prevent against electric shock, explosion and/or injury. Contact the dealer or authorized agent.
- Power bank usage by children should be supervised.
- Please read the operating instructions (including safety instructions and information on the minimum and maximum operating temperatures) supplied with this power bank.

Do not install the appliance in a confined space, such as a bookcase or built-in cabinet. Do not expose the batteries (battery pack or batteries installed) to excessive heat such as sunshine, fire or the like for a long time. Do not subject the batteries to extreme low temperature conditions that may result in overheating and thermal runaway. Do not dismantle, open or shred secondary cells or batteries. Do not expose cells or batteries to heat or fire. Avoid storage in direct sunlight. In the event of a cell leaking, do not allow the liquid to come in contact with the skin or eyes. If contact has been made, wash the affected area with copious amounts of water and seek medical advice.

Separate cells and batteries need to be charged before use. Always refer to the manufacturer's instructions or equipment manual for proper charging instructions. After extended periods of storage, it may be necessary to charge and discharge the cells or batteries several times to obtain maximum performance. Dispose of properly.

Replacement parts: Hybrid silicone rubber earbuds
Please consult your nearest Sony dealer for information about replacement parts.

Location of the serial number label

See Fig. F

Specifications

Headset

Power source:
DC 3.7 V: Built-in lithium-ion rechargeable battery
DC 5 V: When charged using USB

Operating temperature:
0 °C to 40 °C

Rated power consumption:
0.4 W (Headset),
2 W (Charging case)

Usage hours:
When connected via the Bluetooth device
Music playback time: Max 9 hours
Communication time: Max 5 hours
Standby time: Max. 200 hours
Note: Usage hours may be shorter depending on the Codec and the conditions of use.

Charging time:
Approx. 2.5 hours (Headset)
The sensitivity of music playback is possible after 10 minutes charging.)
Approx. 3 hours (Charging case)

Note: Charging and usage hours may be different depending on the conditions of use.

Bluetooth and Wi-Fi (IEEE802.11b/g/n) devices use the same frequency (2.4 GHz). When using the unit near Wi-Fi device, electromagnetic interference may occur, resulting in noise, audio dropout, or the inability to connect. If this happens, try performing the following steps:

- Establish a connection between the unit and the Bluetooth device when they are at least 10 m away from the Wi-Fi device.

- Turn off the Wi-Fi device when using the unit within 10 m of the Wi-Fi device.

- Position the unit and the Bluetooth device as near as possible in areas where there is no interference.

• Microphones emitting sound from a Bluetooth device may affect the operation of electronic medical devices. Turn off this unit and another Bluetooth device in the following locations, as it may cause an accident:

- in hospitals, near priority seating in trains, locations where inflammable gas is present, near air vents, or near electrical equipment.

• Separate cells and batteries need to be charged before use. Always refer to the manufacturer's instructions or equipment manual for proper charging instructions.

After extended periods of storage, it may be necessary to charge and discharge the cells or batteries several times to obtain maximum performance. Dispose of properly.

• If you are using the unit in a place subject to high amounts of humidity, dust, smoke, or steam, or in a place subject to high temperatures such as near a fire, a location subject to direct sunlight, in a car, etc.

High volume may affect your hearing.

• Do not use the unit while walking, driving or cycling. Doing so may cause traffic accidents.

• Do not use at a dangerous place unless the surrounding environment is safe.

If you are using the unit in a place subject to high amounts of humidity, dust, smoke, or steam, or in a place subject to high temperatures such as near a fire, a location subject to direct sunlight, in a car, etc.

High volume may affect your hearing.

• Do not use the unit while walking, driving or cycling. Doing so may cause traffic accidents.

• Do not use at a dangerous place unless the surrounding environment is safe.

If you are using the unit in a place subject to high amounts of humidity, dust, smoke, or steam, or in a place subject to high temperatures such as near a fire, a location subject to direct sunlight, in a car, etc.

High volume may affect your hearing.

• Do not use the unit while walking, driving or cycling. Doing so may cause traffic accidents.

• Do not use at a dangerous place unless the surrounding environment is safe.

If you are using the unit in a place subject to high amounts of humidity, dust, smoke, or steam, or in a place subject to high temperatures such as near a fire, a location subject to direct sunlight, in a car, etc.

High volume may affect your hearing.

• Do not use the unit while walking, driving or cycling. Doing so may cause traffic accidents.

• Do not use at a dangerous place unless the surrounding environment is safe.

If you are using the unit in a place subject to high amounts of humidity, dust, smoke, or steam, or in a place subject to high temperatures such as near a fire, a location subject to direct sunlight, in a car, etc.

High volume may affect your hearing.

• Do not use the unit while walking, driving or cycling. Doing so may cause traffic accidents.

• Do not use at a dangerous place unless the surrounding environment is safe.

If you are using the unit in a place subject to high amounts of humidity, dust, smoke, or steam, or in a place subject to high temperatures such as near a fire, a location subject to direct sunlight, in a car, etc.

High volume may affect your hearing.

• Do not use the unit while walking, driving or cycling. Doing so may cause traffic accidents.

• Do not use at a dangerous place unless the surrounding environment is safe.

If you are using the unit in a place subject to high amounts of humidity, dust, smoke, or steam, or in a place subject to high temperatures such as near a fire, a location subject to direct sunlight, in a car, etc.

High volume may affect your hearing.

• Do not use the unit while walking, driving or cycling. Doing so may cause traffic accidents.

• Do not use at a dangerous place unless the surrounding environment is safe.

If you are using the unit in a place subject to high amounts of humidity, dust, smoke, or steam, or in a place subject to high temperatures such as near a fire, a location subject to direct sunlight, in a car, etc.

High volume may affect your hearing.

• Do not use the unit while walking, driving or cycling. Doing so may cause traffic accidents.

• Do not use at a dangerous place unless the surrounding environment is safe.

If you are using the unit in a place subject to high amounts of humidity, dust, smoke, or steam, or in a place subject to high temperatures such as near a fire, a location subject to direct sunlight, in a car, etc.

High volume may affect your hearing.

• Do not use the unit while walking, driving or cycling. Doing so may cause traffic accidents.

• Do not use at a dangerous place unless the surrounding environment is safe.

If you are using the unit in a place subject to high amounts of humidity, dust, smoke, or steam, or in a place subject to high temperatures such as near a fire, a location subject to direct sunlight, in a car, etc.

High volume may affect your hearing.

• Do not use the unit while walking, driving or cycling. Doing so may cause traffic accidents.

• Do not use at a dangerous place unless the surrounding environment is safe.

If you are using the unit in a place subject to high amounts of humidity, dust, smoke, or steam, or in a place subject to high temperatures such as near a fire, a location subject to direct sunlight, in a car, etc.

High volume may affect your hearing.

• Do not use the unit while walking, driving or cycling. Doing so may cause traffic accidents.

• Do not use at a dangerous place unless the surrounding environment is safe.

If you are using the unit in a place subject to high amounts of humidity, dust, smoke, or steam, or in a place subject to high temperatures such as near a fire, a location subject to direct sunlight, in a car, etc.

High volume may affect your hearing.

• Do not use the unit while walking, driving or cycling. Doing so may cause traffic accidents.

• Do not use at a dangerous place unless the surrounding environment is safe.

If you are using the unit in a place subject to high amounts of humidity, dust, smoke, or steam, or in a place subject to high temperatures such as near a fire, a location subject to direct sunlight, in a car, etc.

High volume may affect your hearing.

• Do not use the unit while walking, driving or cycling. Doing so may cause traffic accidents.

• Do not use at a dangerous place unless the surrounding environment is safe.

If you are using the unit in a place subject to high amounts of humidity, dust, smoke, or steam, or in a place subject to high temperatures such as near a fire, a location subject to direct sunlight, in a car, etc.

High volume may affect your hearing.

• Do not use the unit while walking, driving or cycling. Doing so may cause traffic accidents.

• Do not use at a dangerous place unless the surrounding environment is safe.

If you are using the unit in a place subject to high amounts of humidity, dust, smoke, or steam, or in a place subject to high temperatures such as near a fire, a location subject to direct sunlight, in a car, etc.

High volume may affect your hearing.

• Do not use the unit while walking, driving or cycling. Doing so may cause traffic accidents.

• Do not use at a dangerous place unless the surrounding environment is safe.

If you are using the unit in a place subject to high amounts of humidity, dust, smoke, or steam, or in a place subject to high temperatures such as near a fire, a location subject to direct sunlight, in a car, etc.

High volume may affect your hearing.

• Do not use the unit while walking, driving or cycling. Doing so may cause traffic accidents.

• Do not use at a dangerous place unless the surrounding environment is safe.

If you are using the unit in a place subject to high amounts of humidity, dust, smoke, or steam, or in a place subject to high temperatures such as near a fire, a location subject to direct sunlight, in a car, etc.

High volume may affect your hearing.

• Do not use the unit while walking, driving or cycling. Doing so may cause traffic accidents.

• Do not use at a dangerous place unless the surrounding environment is safe.

If you are using the unit in a place subject to high amounts of humidity, dust, smoke, or steam, or in a place subject to high temperatures such as near a fire, a location subject to direct sunlight, in a car, etc.

High volume may affect your hearing.


• Do not use the unit while walking, driving or cycling. Doing so may cause traffic accidents.

• Do not use at a dangerous place unless the surrounding environment is safe.

If you are using the unit in a place subject to high amounts of humidity, dust, smoke, or steam, or in a place subject to high temperatures such as near a fire, a location subject

Русский

Беспроводная стереофоническая гарнитура



Не устанавливайте устройство в ограниченном пространстве, например в книжном шкафу или встроенным стеллаже.

Не подвергайте аккумуляторы (аккумуляторный блок или установленные аккумуляторы) воздействию высоких температур, например солнечных лучей, огня и др., в течение длительного времени.

Не подвергайте батареи воздействию чрезвычайно низких температур, поскольку это может привести к перегреву и тепловому ущербу.

Не разбирайте, не открывайте и не разрезайте вторичные элементы питания или аккумуляторы.

Не подвергайте элементы питания или аккумуляторы воздействию температуры или огня. Не храните устройство под прямыми солнечными лучами.

В случае протекания элементов питания не позволяйте жидкости вступать в контакт с кожей или глазами. При попадании жидкости промойте пораженную область обильным количеством воды и обратитесь за медицинской помощью.

Вторичные элементы питания и аккумуляторы не должны подвергаться воздействию излишним давлением.

Всегда соблюдайте инструкции по правильной зарядке, указанные в инструкциях изготовителя или руководстве, прилагаемом к устройству.

После длительного хранения, возможно, будет необходимо зарядить и разрядить элементы питания несколько раз для достижения максимального эффективности работы.

Утилизируйте правильно. Данное оборудование про тестировано на соответствие ограничениям, установленным нормативами IEC для использования кабеля подключения короче 3 метров.

В гарнитуре применяется беспроводная технология Bluetooth.

Батарея может использоваться для беспроводного прослушивания музыки со смартфона, мобильного телефона или ноутбука.

Кроме того, с помощью гарнитуры можно осуществлять или принимать телефонные вызовы.

Сделано во Вьетнаме. Производитель: Союз Корпорейшн, 1-1 Конан Минато-ку Токио, 108-0075 Япония.

Импортёр на территории стран Таможенного союза: АО «Сони Электроники», Россия, 123103, Москва, Караваевский проезд, 6

Дата изготовления устройства

Год и месяц изготовления: указана на упаковке: YY-MM, где MM – месяц, YYYY – год изготовления.

Условия хранения:

Храните в упакованном виде в темных, сухих, чистых, вентилируемых помещениях, изолированных от мест хранения кислот и щелочей. Хранить при температуре от -10°С до +40°С и относительной влажности не более ~75%, без образования конденсата. Срок хранения не установлен.

Транспортировать в оригинальной упаковке, во время транспортировки не бросать, оберегать от падений, ударов, не подвергать излишней вибрации.

Если неисправность не удаётся устранить следуя данной инструкции – обратитесь в ближайший авторизованный СОНУ ЦЕНТР по ремонту и обслуживанию.

Реализацию должна осуществляться в соответствии с действующими требованиями законодательства. Отслужившее изделие утилизировать в соответствии с действующими требованиями законодательства.

Запрещается использовать, хранить и оставлять в местах, подверженных воздействию высоких температур, например солнечными лучами, в автомобиле и др.

Высокий уровень громкости может повредить слух.

Не используйте устройство при ходьбе, управляя автомобилем или едве на велосипеде. Невыполнение этого требования может привести к дорожно-транспортному происшествию.

Не используйте устройство в опасных местах, если не слышны окружающие звуки.

Попадание воды или посторонних предметов может привести к короткому замыканию и/или вырыванию из-за воздействия электрическим током. При попадании воды или посторонних предметов в устройство немедленно прекратите его использование и обратитесь в ближайшему дилеру Sony. В частности, соблюдайте приведенные ниже предосторожности.

- Использование взрыво-раковины и т. п. Будьте осторожны, чтобы не уронить устройство в воду, например в контейнер, наполненный водой.

- Использование под дождем, снегом или в местах с повышенной влажностью

Подобную информацию о влиянии от контакта с человеческим телом мобильного телефона или других беспроводных устройств, подключенных к устройству, см. в инструкции беспроводного устройства.

Надежно устанавливаются вкладыши. В противном случае они могут отсоединиться и осться в ушах, что может привести к травме или заблуждению.

Запрещается вставлять USB-штекер, если основное устройство или кабель зарядки мокрые. Если USB-штекер вставлен, когда основное устройство или кабель зарядки мокрые, может произойти короткое замыкание из-за жидкости (беспроводная вода, морская вода, например из душа, основные устройства или кабели зарядки или из посторонних материалов), что может привести к чрезмерному перегреву или неисправности.

Данное изделие (включая аксессуары) оснащено магнитом(ами), который может влиять на работу кардиостимуляторов, программируемых шунтирующих клапанов для лечения гидроцефалии или других медицинских устройств. Не размещайте данное изделие вблизи людей, пользующихся такими устройствами.

Проконсультируйтесь с врачом перед использованием данного изделия, если вы пользуетесь любым медицинским устройством.

Данный продукт оснащен магнитами.

Размещение магнитных карт рядом с продуктом может повлиять на работу карт и сделает их непригодными для использования.

Данное изделие (включая аксессуары) оснащено магнитом(ами). Программирование магнитом(ами) может привести к серьезным последствиям, например, опасности удушения или повреждению желудочно-кишечного тракта. В случае проглатывания магнита(ов) немедленно проконсультируйтесь с врачом, чтобы избежание случайного проглатывания храните данное изделие в местах недоступных для детей или других лиц, находящихся под присмотром.

Следует избегать попадания воды или посторонних предметов в устройство.

Попадание воды или посторонних предметов может привести к короткому замыканию из-за жидкости (беспроводная вода, морская вода, например из душа, основные устройства или кабели зарядки или из посторонних материалов), что может привести к чрезмерному перегреву или неисправности.

Данное изделие (включая аксессуары) оснащено магнитом(ами), который может влиять на работу кардиостимуляторов, программируемых шунтирующими клапанами для лечения гидроцефалии или других медицинских устройств. Не размещайте данное изделие вблизи людей, пользующихся такими устройствами.

Проконсультируйтесь с врачом перед использованием данного изделия, если вы пользуетесь любым медицинским устройством.

Данный продукт оснащен магнитами.

Размещение магнитных карт рядом с продуктом может повлиять на работу карт и сделает их непригодными для использования.

Данное изделие (включая аксессуары) оснащено магнитом(ами). Программирование магнитом(ами) может привести к серьезным последствиям, например, опасности удушения или повреждению желудочно-кишечного тракта. В случае проглатывания магнита(ов) немедленно проконсультируйтесь с врачом, чтобы избежание случайного проглатывания храните данное изделие в местах недоступных для детей или других лиц, находящихся под присмотром.

Следует избегать попадания воды или посторонних предметов в устройство.

Попадание воды или посторонних предметов может привести к короткому замыканию из-за жидкости (беспроводная вода, морская вода, например из душа, основные устройства или кабели зарядки или из посторонних материалов), что может привести к чрезмерному перегреву или неисправности.

Данное изделие (включая аксессуары) оснащено магнитом(ами).

Программирование магнитом(ами) может привести к серьезным последствиям, например, опасности

удушения или повреждению желудочно-кишечного тракта. В случае проглатывания магнита(ов) немедленно проконсультируйтесь с врачом, чтобы избежание случайного проглатывания храните данное изделие в местах недоступных для детей или других лиц, находящихся под присмотром.

Следует избегать попадания воды или посторонних предметов в устройство.

Попадание воды или посторонних предметов может привести к короткому замыканию из-за жидкости (беспроводная вода, морская вода, например из душа, основные устройства или кабели зарядки или из посторонних материалов), что может привести к чрезмерному перегреву или неисправности.

Данное изделие (включая аксессуары) оснащено магнитом(ами).

Программирование магнитом(ами) может привести к серьезным

следствиям, например, опасности удушения или повреждению желудочно-кишечного тракта. В случае проглатывания магнита(ов) немедленно проконсультируйтесь с врачом, чтобы избежание случайного проглатывания храните данное изделие в местах недоступных для детей или других лиц, находящихся под присмотром.

Следует избегать попадания воды или посторонних предметов в устройство.

Попадание воды или посторонних предметов может привести к короткому замыканию из-за жидкости (беспроводная вода, морская вода, например из душа, основные устройства или кабели зарядки или из посторонних материалов), что может привести к чрезмерному перегреву или неисправности.

Данное изделие (включая аксессуары) оснащено магнитом(ами).

Программирование магнитом(ами) может привести к серьезным

следствиям, например, опасности удушения или повреждению желудочно-кишечного тракта. В случае проглатывания магнита(ов) немедленно проконсультируйтесь с врачом, чтобы избежание случайного проглатывания храните данное изделие в местах недоступных для детей или других лиц, находящихся под присмотром.

Следует избегать попадания воды или посторонних предметов в устройство.

Попадание воды или посторонних предметов может привести к короткому замыканию из-за жидкости (беспроводная вода, морская вода, например из душа, основные устройства или кабели зарядки или из посторонних материалов), что может привести к чрезмерному перегреву или неисправности.

Данное изделие (включая аксессуары) оснащено магнитом(ами).

Программирование магнитом(ами) может привести к серьезным

следствиям, например, опасности удушения или повреждению желудочно-кишечного тракта. В случае проглатывания магнита(ов) немедленно проконсультируйтесь с врачом, чтобы избежание случайного проглатывания храните данное изделие в местах недоступных для детей или других лиц, находящихся под присмотром.

Следует избегать попадания воды или посторонних предметов в устройство.

Попадание воды или посторонних предметов может привести к короткому замыканию из-за жидкости (беспроводная вода, морская вода, например из душа, основные устройства или кабели зарядки или из посторонних материалов), что может привести к чрезмерному перегреву или неисправности.

Данное изделие (включая аксессуары) оснащено магнитом(ами).

Программирование магнитом(ами) может привести к серьезным

следствиям, например, опасности удушения или повреждению желудочно-кишечного тракта. В случае проглатывания магнита(ов) немедленно проконсультируйтесь с врачом, чтобы избежание случайного проглатывания храните данное изделие в местах недоступных для детей или других лиц, находящихся под присмотром.

Следует избегать попадания воды или посторонних предметов в устройство.

Попадание воды или посторонних предметов может привести к короткому замыканию из-за жидкости (беспроводная вода, морская вода, например из душа, основные устройства или кабели зарядки или из посторонних материалов), что может привести к чрезмерному перегреву или неисправности.

Данное изделие (включая аксессуары) оснащено магнитом(ами).

Программирование магнитом(ами) может привести к серьезным

следствиям, например, опасности удушения или повреждению желудочно-кишечного тракта. В случае проглатывания магнита(ов) немедленно проконсультируйтесь с врачом, чтобы избежание случайного проглатывания храните данное изделие в местах недоступных для детей или других лиц, находящихся под присмотром.

Следует избегать попадания воды или посторонних предметов в устройство.

Попадание воды или посторонних предметов может привести к короткому замыканию из-за жидкости (беспроводная вода, морская вода, например из душа, основные устройства или кабели зарядки или из посторонних материалов), что может привести к чрезмерному перегреву или неисправности.

Данное изделие (включая аксессуары) оснащено магнитом(ами).

Программирование магнитом(ами) может привести к серьезным

следствиям, например, опасности удушения или повреждению желудочно-кишечного тракта. В случае проглатывания магнита(ов) немедленно проконсультируйтесь с врачом, чтобы избежание случайного проглатывания храните данное изделие в местах недоступных для детей или других лиц, находящихся под присмотром.

Следует избегать попадания воды или посторонних предметов в устройство.

Попадание воды или посторонних предметов может привести к короткому замыканию из-за жидкости (беспроводная вода, морская вода, например из душа, основные устройства или кабели зарядки или из посторонних материалов), что может привести к чрезмерному перегреву или неисправности.

Данное изделие (включая аксессуары) оснащено магнитом(ами).

Программирование магнитом(ами) может привести к серьезным

следствиям, например, опасности удушения или повреждению желудочно-кишечного тракта. В случае проглатывания магнита(ов) немедленно проконсультируйтесь с врачом, чтобы избежание случайного проглатывания храните данное изделие в местах недоступных для детей или других лиц, находящихся под присмотром.

Следует избегать попадания воды или посторонних предметов в устройство.

Попадание воды или посторонних предметов может привести к короткому замыканию из-за жидкости (беспроводная вода, морская вода, например из душа, основные устройства или кабели зарядки или из посторонних материалов), что может привести к чрезмерному перегреву или неисправности.

Данное изделие (включая аксессуары) оснащено магнитом(ами).

Программирование магнитом(ами) может привести к серьезным

следствиям, например, опасности удушения или повреждению желудочно-кишечного тракта. В случае проглатывания магнита(ов) немедленно проконсультируйтесь с врачом, чтобы избежание случайного проглатывания храните данное изделие в местах недоступных для детей или