

Manuals.plus / > Havells / > Havells Prolife VISTA 4.2 L Air Fryer Instruction Manual

Havells Prolife Vista

Sign in to save this manual Sign in to bookmark this manual and keep private notes.

Havells Prolife VISTA 4.2 L Air Fryer Instruction Manual

Model: Prolife Vista



Manuals+



- Always ensure the appliance is placed on a stable, heat-resistant surface, away from walls or other appliances to allow adequate air circulation.
- Do not immerse the main unit, cord, or plug in water or any other liquid to prevent electrical shock.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from the outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- The appliance surfaces become hot during use. Use oven mitts when handling hot components.
- Do not block any ventilation openings.
- Do not use accessories not recommended by the appliance manufacturer, as this may cause injuries.
- This appliance is for household use only. Do not use outdoors.
- The appliance features an automatic shut-off function for safety, preventing overheating.

2. PRODUCT OVERVIEW

The Havells Prolife VISTA Air Fryer utilizes Aero Crisp 360° air circulation technology to cook food with minimal oil. It features a 4.2 L capacity, a transparent see-through window, and a non-stick silicon-coated basket.

Components:

- Main Unit
- Frying Pan (4.2 L)
- Frying Plate



Image 2.1: Havells Prolife VISTA Air Fryer Main Unit with controls and basket.

Reliable, Durable & Long-Lasting



Non Stick Silicon
Coated Basket



Image 2.2: Close-up view of the non-stick silicon coated basket and frying plate.

Advertisements



Image 2.3: The air fryer showcasing its transparent see-through window for monitoring food.



Image 2.4: Illustration of the Aero Crisp 360° air circulation technology.

3. SETUP AND FIRST USE

3.1 Unpacking

- Remove all packaging materials, stickers, and labels from the appliance.
- Check that all components listed in Section 2 are present and undamaged.

Advertisements

3.2 Initial Cleaning

- Wash the frying pan and frying plate with hot water, dish soap, and a non-abrasive sponge. Rinse thoroughly and dry completely.
- Do not use abrasive cleaning agents or metal scouring pads, as this can damage the non-stick coating.

3.3 Placement

- Place the air fryer on a stable, level, and heat-resistant surface.
- Ensure there is at least 10 cm (4 inches) of free space around the back and sides of the appliance, and 10 cm (4 inches) above it, for proper ventilation.
- Do not place the appliance near flammable materials or heat sources.

3.4 Power Connection

- Plug the power cord into a grounded wall outlet.

Advertisements

4. OPERATING INSTRUCTIONS

4.1 Preparing for Cooking

- Place the frying plate into the frying pan.
- Place the ingredients into the frying pan. Do not overfill the basket beyond the MAX indication.
- Slide the frying pan back into the main unit until it clicks into place.

4.2 Setting Temperature and Time

Because Every Recipe Is Different



Up To 200°C
Temperature
Control



Upto 60
Minutes
Timer



Image 4.1: Close-up of the adjustable temperature and timer control knobs.

- Use the top knob to set the desired cooking temperature (up to 200°C).
- Use the bottom knob to set the cooking time (up to 60 minutes). The appliance will start cooking automatically once the timer is set.
- The power indicator light will illuminate, indicating the appliance is operating.

Advertisements

- The transparent see-through window allows you to monitor the cooking process without opening the frying pan, preserving heat and ensuring consistent results.
- For some recipes, it may be necessary to shake or turn the ingredients halfway through the cooking time. Carefully pull out the frying pan, shake the contents, and then slide it back in. The appliance will resume cooking.

4.4 Completing the Cooking Cycle

- When the set cooking time has elapsed, the timer will ring, and the appliance will automatically shut off.
- Carefully pull out the frying pan from the air fryer.
- Empty the contents into a serving dish. Use tongs to remove larger items.
- Allow the appliance to cool down completely before cleaning.

4.5 Multi-Functional Cooking Guide



Image 4.2: Visual guide for various cooking functions including Fry, Roast, Grill, and Bake.

Advertisements

The Havells Prolife VISTA Air Fryer can be used for various cooking methods. Refer to the table below for general guidelines. Cooking times and temperatures may vary based on food quantity and desired crispness.

Food Item	Temperature	Time	Notes
Frozen Fries (thin)	180°C	15-20 min	Shake halfway
Chicken Nuggets	180°C	10-15 min	Shake halfway
Fresh Chicken Drumsticks	180°C	20-25 min	Turn halfway
Vegetables (e.g., broccoli)	160°C	10-12 min	Toss with a little oil
Small Cakes/Muffins	160°C	15-20 min	Use oven-safe bakeware

5. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and extends the lifespan of your air fryer.

5.1 Cleaning After Each Use

- Unplug the air fryer and allow it to cool down completely before cleaning.
- Wipe the exterior of the main unit with a damp cloth. Do not use harsh abrasives.
- Remove the frying pan and frying plate. Wash them with hot water, dish soap, and a non-abrasive sponge. The non-stick coating is delicate; avoid metal utensils or harsh scrubbing.
- The frying pan and frying plate are **not dishwasher safe**. Hand wash only.
- Clean the interior of the appliance with a damp cloth. For stubborn residue, use a mild detergent.

Advertisements

5.2 Storage

- Ensure all parts are clean and dry before storing.
- Store the air fryer in a cool, dry place.

6. TROUBLESHOOTING

If you encounter issues with your air fryer, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Air fryer does not turn on	Appliance not plugged in. Frying pan not inserted	Ensure the power cord is securely plugged into a grounded outlet.

Problem	Possible Cause	Solution
Food is not cooked evenly.	Too much food in the basket. Food not shaken/turned.	Reduce the amount of food per batch. Shake or turn food halfway through cooking.
White smoke coming from the appliance.	Greasy residue from previous use. High-fat ingredients.	Clean the frying pan and frying plate thoroughly after each use. For high-fat foods, absorb excess oil with a paper towel before cooking.
Food is not crispy.	Temperature too low or time too short. Too much moisture in food.	Increase temperature or cooking time. Pat food dry before cooking. A light coating of oil can help.

7. SPECIFICATIONS

Detailed technical specifications for the Havells Prolife VISTA Air Fryer:

Advertisements

Feature	Specification
Model Name	Prolife Vista
Capacity	4.2 litres
Output Wattage	1350 Watts
Voltage	230 Volts
Max Temperature Setting	200 Degrees Celsius
Timer	Up to 60 minutes
Control Method	Push Button (Rotary Knobs)
Special Feature	Automatic Shut-Off, See-Through Window
Non-stick Coating	Yes
Product Dimensions (D x W x H)	29D x 30W x 29H Centimeters
Item Weight	3.4 Kilograms
Material	Acrylonitrile Butadiene Styrene (ABS)
Included Components	1 N Main Unit, 1 N Frying Pan (4.2 L), 1 N Frying Plate

8. WARRANTY AND SUPPORT

8.1 Warranty Information

The Havells Prolife VISTA Air Fryer comes with a **2-year Havells warranty**. This warranty assures reliable long-term performance and dependable after-sales support. Please retain your purchase receipt as proof of purchase for warranty claims.

8.2 Customer Support

For any queries, service requests, or technical assistance, please contact Havells customer support:

- **Website:** www.havells.com (Please visit the official Havells website for the most current contact information and support options.)
- **Customer Service Number:** Refer to the Havells official website or product packaging for regional contact numbers.
- **Email Support:** Refer to the Havells official website for email contact options.

Advertisements

When contacting support, please have your product model name (Prolife Vista) and purchase details ready.

© 2025 Havells. All rights reserved.

Advertisements

Related Documents - Prolife Vista

	Havells Domestic Appliances Price List - January 2024 Official price list for Havells domestic appliances, featuring a wide range of kitchen appliances, garment care products, and climate control solutions. Includes model numbers, item descriptions, and list prices effective January 1, 2024.
	Havells Sampark Retailer Bonus Points Scheme Information on the Havells Sampark retailer bonus points scheme for Q2 2025-26, including earning targets, bonus points, and terms and conditions for Havells, Reo, and Standard brands.
	Havells Sampark 2.0 Retailer Program Benefits and Community Tiers

	Havells Smart Home Appliances: Innovation and Elegance for Your Home Discover the extensive range of Havells Smart Home Appliances, from kitchen essentials like mixer grinders and air fryers to home comfort solutions like irons and heaters. Experience innovation, quality, and stylish design for modern living.
	Havells Sampark 2.0: Retailer Loyalty Program & Product Points Guide Discover the Havells Sampark 2.0 program for retailers, detailing how to earn and redeem points on a wide range of Havells electrical products. Includes product categories, SKU summaries, and associated points across Premium, Popular, Standard, and REO divisions.
	Havells Promotional Schemes and Product Offers Explore the latest Havells promotional schemes and offers across a wide range of products including consumer lighting, building segment products, fans, personal grooming, water heaters, and more. Find details on discounts, incentives, and special schemes for October and beyond.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

Question

Details

Submit question

HAVELLS PROLIFE VISTA

KEEP EXPLORING MANUALS, GUIDES, AND SUPPORT DOCS.

Search model numbers, browse help resources, and jump straight into the next PDF manual or troubleshooting page without losing your

Search Manuals+

EXPLORE

Deep Search

Upload

Login

MANUALS+

Home

About Us

Privacy Policy

Login

GUIDES

Amazon Manuals

AliExpress Manuals

Video Guides

Login

FOLLOW

@manualsplus

YouTube

LinkedIn

Facebook

Login

Manuals+

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners.

SAVE MANUALS, NOTES, UPLOADS, AND QUESTIONS

Sign in with Google, X, or a passkey to keep private notes on saved manuals, track public uploads, and revisit questions you posted.

Open login options

Privacy Policy · DMCA